

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
01A	tri	1	8	34	2			23	
0Z4	pl-1	-	24	4	4	8		3	
0Z4	pl-2	-	24	4	4			5	
1	rec	1	9	8	1	3		2	
10		1	10	18	1			23	
1005	pl-1	6	9	5	4			3	
1005	pl-2	6	9	5	4			5	
101F		1	8	20	1			23	
10AF11	pen	6	12	25	2	1		237	note(s)
10AF11	tri-1	1	12	24	2	5		68	
10AF11	tri-2	1	12	25	2	7		34	
10AL11	pen-1	1	12	18	3	4	3	5689	note(s)
10AL11	pen-2	5	12	18	3	2	7	134	
10BE8	pen	4	12	24	2	6		789	
10BE8	tri	4	12	23	2	1		23	
10BQ5		4	12	5	1	3	12	1+279	
10C8	pen	4	12	23	2	9		678	
10C8	tri	4	12	23	2	3		12	
10CW5		4	12	21	2	3	123678	1+23+7+89	note(s)
10DE7	tri-1	4	12	9	1	8	23	67	
10DE7	tri-2	4	12	3	1	9		12+3	
10DR7	tri-1	4	12	28	2	8		67	
10DR7	tri-2	4	12	23	2	9	23	12+3	
10DX8	pen	4	12	23	2	7		689	
10DX8	tri	4	12	23	2	3		12	
10EG7	tri-1	7	12	26	2	6		45	
10EG7	tri-2	7	12	22	2	3		12	
10EM7	tri-1	7	12	26	2	6		45	
10EM7	tri-2	7	12	22	2	3		12	
10EW7	sec-1	4	12	27	2	8		67	
10EW7	sec-2	4	12	23	2	9	23	12+3	
10FD12	di-1	4	16	21	3			7	
10FD12	di-2	4	16	21	3			8	
10FD12	pen	4	16	24	2	3		1269	
10FD7	tri-1	4	12	8	1	8		67	
10FD7	tri-2	4	12	22	2	9	23	12+3	
10FR7	tri-1	4	12	7	1	8	23	67	
10FR7	tri-2	4	12	20	2	9		12+3	
10GF7	tri-1	4	12	29	2	1		89	
10GF7	tri-2	4	12	23	2	3		26	
10GH8	pen	4	12	23	2	7		236	
10GH8	tri	4	12	22	2	8		19	
10GK6		4	12	23	2	1	39	23+79	
10GN8	pen	4	12	22	2	6		789	
10GN8	tri	4	12	24	2	1		23	
10GV8	pen	4	12	22	2	8		679	
10GV8	tri	4	12	24	2	3		12	
10HA6		4	12	22	2	1	3689	26+87	
10HF8	pen	4	12	22	2	6		789	
10HF8	tri	4	12	24	2	1		23	
10JA5		1	12	21	2	6	0	4580	note(s)
10JA8	tet	4	12	24	2	6		789	
10JA8	tri	4	12	24	2	1		23	
10JT8	pen	4	12	21	2	6		789	
10JT8	tri	4	12	23	2	1		23	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
10JY8	pen	4	12	18	3	6		789	
10JY8	tri	4	12	18	3	1		23	
10KR8	pen	4	12	20	2	6		789	
10KR8	tri	4	12	20	2	1		23	
10KU8	di-1	4	12	25	3	1	5	3	
10KU8	di-2	4	12	25	3	1		2	
10KU8	pen	4	12	22	2	6		789	
10L14	tri-1	4	18	22	2	8		67	
10L14	tri-2	4	18	22	2	3		12	
10LB8	pen	4	12	22	2	6		789	
10LB8	tri	4	12	29	2	1		23	
10LD12	di-1	4	18	25	3			6	
10LD12	di-2	4	18	17	3	3		2	
10LD12	di-3	4	18	17	3			1	
10LD12	tri	4	18	25	2	7		89	
10LD13	di-1	4	13	26	3			8	
10LD13	di-2	4	13	26	3			6	
10LD13	tri	4	13	8	1	3	79	12	
10LD6		4	12	20	2	1	3689	26+87	
10LE8	pen-1	4	12	22	2	3		189	
10LE8	pen-2	4	12	22	2			689	
10LM8	pen	4	12	23	2	7		236	
10LM8	tri	4	12	23	2	8		19	
10LW8	pen	4	12	20	2	6		789	
10LW8	tri	4	12	21	2	1		23	
10LY8	pen	4	12	20	2	6		789	
10LY8	tri	4	12	22	2	1		23	
10LZ8	pen	4	12	20	2	6		789	
10LZ8	tri	4	12	22	2	1		23	
10P18		4	19	23	2	3	12689	1+26+8+97	
10T10	pen-1	5	12	19	3	2		134	note(s)
10T10	pen-2	1	12	19	3	4		5789	
10Z10	pen-1	0	12	26	4	8		4567	note(s)
10Z10	pen-2	5	12	18	3	9	7	248	
117L7	amp	2	22	7	1	8		345	
117L7	rec	2	22	4	1	1		6	
117N7	amp	2	22	5	1	6		345	
117N7	rec	2	22	4	1	8			note(s)
117P7	amp	2	22	6	1	6		345	
117P7	rec	2	22	4	1	8			note(s)
117Z3		3	22	5	1	6		5	
117Z4		2	22	5	1	8		5	
117Z6	pl-1	2	22	5	1	4		3	
117Z6	pl-2	2	22	5	1	8		5	
11AF9	pen-1	5	12	20	2	7		890	note(s)
11AF9	pen-2	5	12	20	2	2		134	
11AR11	pen-1	9	12	21	2	6		2345	
11AR11	pen-2	3	12	21	2	8		4567	
11BM8	pen	4	13	23	2	2		367	
11BM8	tri	4	13	23	2	8		19	
11BN11	pen-1	6	12	20	2	2		135	note(s)
11BN11	pen-2	1	12	20	2	4		567	note(s)
11BQ11	pen-1	9	12	19	2	6		345	
11BQ11	pen-2	3	12	19	2	8		457	
11BT11	pen	5	12	21	2	1		348	note(s)

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
11BT11	tri-1	1	12	23	2	8		79	note(s)
11BT11	tri-2	4	12	21	2	9		18	
11C5		3	13	5	1	1	25	2+567	
11CA11	pen	7	12	21	2	4		356	note(s)
11CA11	tri-1	1	12	21	2	5		46	note(s)
11CA11	tri-2	1	12	24	2	7		23	note(s)
11CF11	sec-1	1	12	20	2	6		345	
11CF11	sec-2	6	12	20	2	0		37	
11CF11	sec-3	7	12	22	2	1		23	
11CH11	pen	5	12	21	2	1		348	note(s)
11CH11	tri-1	1	12	22	2	8		79	note(s)
11CH11	tri-2	4	12	21	2	9		18	note(s)
11CY7	tri-1	4	12	28	2	8		67	
11CY7	tri-2	4	12	23	2	9	23	12+3	
11DS5		3	12	25	2	2	17	1+756	
11FY7	tri-1	4	12	8	1	1		23	note(s)
11FY7	tri-2	1	12	22	2	9		57	note(s)
11HM7		6	8	20	2	1	3459	278	
11JE8	pen	4	12	23	2	6		789	
11JE8	tri	4	12	23	2	1		23	
11KV8	pen	4	12	23	2	1		23	
11KV8	tri	4	12	23	2	1		23	
11LQ8	pen	4	12	20	2	6		789	
11LQ8	tri	4	12	20	2	1		23	
11LT8	di-1	4	12	16	3	7		8	note(s)
11LT8	di-2	4	12	16	3	7		6	
11LT8	pen	4	12	19	2	1		239	
11LY6		4	12	21	2	1	39	2789	note(s)
11MS8	pen	4	12	22	2	8		679	
11MS8	tri	4	12	24	2	3		12	
11R3		4	12	22	2	0		29	note(s)
11Y9	pen-1	5	12	20	2	7		890	
11Y9	pen-2	5	12	20	2	2		134	
1201		2	9	5	1	46	134567	1+53+7	
1203		1	9	21	3	7		4	
1206	sec-1	1	9	7	1	6		357	
1206	sec-2	1	9	6	1			234	
1221		1	9	10	1	5		2340	
1222A		1	9	5	1	7		234	
1223		1	9	10	1	8		3450	
1229		1	3	21	1			230	
1231		1	9	4	1	7		2346	
1232	pen	1	9	4	1	7		6,3,(4),2	
1273		1	9	8	1	7		2346	
1276		1	8	8	1			23	
1280		1	13	8	1	7		2346	
1282		1	9	4	1	47	47	2356	
1291	tri-1	4	2	29	2		18	23	
1291	tri-2	4	2	29	2			67	
1299		7	2	28	2		18	236	
12A	tri	1	8	9	1			23	
12A4		3	9	22	2	1	2457	2+79	
12A5		6	9	10	1	5	17	234	
12A6		2	13	10	1	8		345	
12A7	pen	1	13	16	1	6		230	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
12A7	rec	1	13	7	1	4		5	
12A8	tot	2	13	9	1	8		34560	
12A8	tri	2	13	12	1			56	
12AB5		4	13	8	1	7	1368	1+83+69	
12AC10	tri-1	4	13	21	2	9		12	note(s)
12AC10	tri-2	1	13	21	2	6		57	
12AC10	tri-3	4	13	21	2	6		15	
12AC5		1	13	25	2	37	37	256	
12AC6		3	13	7	1	7		1256	
12AD6	tot	3	13	5	1	2		1567	
12AD6	tri	3	13	5	1			16	
12AD7	tri-1	9	9	8	1	8	45	67	
12AD7	tri-2	9	9	8	1	3		12	
12AE10	pen-1	5	13	16	3	2		134	note(s)
12AE10	pen-2	1	13	16	3	4		5789	
12AE6	di-1	3	13	28	3			5	
12AE6	di-2	3	13	28	3			6	
12AE6	tri	3	13	15	1	2		17	
12AE7	tri-1	9	9	23	2	8	45	67	
12AE7	tri-2	9	9	23	2	3		12	
12AF11	pen	6	13	25	2	1		237	note(s)
12AF11	tri-1	1	13	24	2	5		68	
12AF11	tri-2	1	3	25	2	7		34	
12AF3		4	13	18	3	0	29	2+9	
12AF4		3	13	23	2	5	1267	1+72+6	
12AF6	pen	4	13	24	2	7		1625	
12AG6	tot	4	13	24	2			1567	
12AG6	tri	4	13	24	2	2		16	
12AH7	tri-1	7	13	10	1	2		13	
12AH7	tri-2	7	13	10	1	4		56	
12AJ6	di-1	3	13	24	3			6	
12AJ6	di-2	3	13	26	3			5	
12AJ6	tri	3	13	26	2	2		17	
12AJ7	hep	4	13	23	2	3		126	
12AJ7	tri	4	13	25	2	3		89	
12AL11	pen-1	1	13	18	3	4	3	5689	
12AL11	pen-2	5	13	18	3	2	7	134	
12AL5	di-1	3	13	17	3	1		7	
12AL5	di-2	3	13	17	3	5		2	
12AL8	tet	4	13	6	1	7		236	
12AL8	tri	4	13	17	1	9		18	
12AQ5		3	13	7	1	2	17	1+756	
12AQ6	di-1	3	13	27	3			5	
12AQ6	di-2	3	13	27	3			6	
12AQ6	tri	3	13	28	2	2		17	
12AS5		3	13	6	1	1	25	2+567	
12AT6	di-1	3	13	26	3			5	
12AT6	di-2	3	13	26	3			6	
12AT6	tri	3	13	8	1	2		17	
12AT7	tri-1	9	9	4	1	8	45	67	
12AT7	tri-2	9	9	4	1	3		12	
12AU6	pen	3	13	4	1	7		1625	
12AU7	tri-1	9	9	8	1	8	45	67	
12AU7	tri-2	9	9	8	1	3		12	
12AU8	pen	4	13	24	2	6		789	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
12AU8	tri	4	13	24	2	1		23	
12AV5		2	13	5	1	3		158	
12AV6	di-1	3	13	27	3			6	
12AV6	di-2	3	13	27	3			5	
12AV6	tri	3	13	27	2	2		17	
12AV7	tri-1	9	9	22	2	8	45	67	
12AV7	tri-2	9	9	22	2	3		12	
12AW6		3	13	22	2	2		156	
12AW6		3	13	4	1	2		1675	
12AX12		7	13	23	2	0	28	281	
12AX3		6	13	24	2	0	29	2+9	note(s)
12AX4		7	13	7	1	3		5	
12AX7	tri-1	9	9	27	2	8	45	67	
12AX7	tri-2	9	9	27	2	3		12	
12AY3		4	13	24	2	9	27	2+7	
12AY7	tri-1	9	9	28	2	8	45	67	
12AY7	tri-2	9	9	28	2	3		12	
12AZ7	tri-1	9	9	3	1	8	45	67	
12AZ7	tri-2	9	9	3	1	3		12	
12B4	tri	3	9	23	2	1	2457	2+79	
12B7	pen	1	13	9	1	7		6342	
12B8	pen	2	13	4	1	1		340	
12B8	tri	2	13	7	1	6		58	
12BA6		3	13	4	1	7		1256	
12BA7	tot	4	13	4	1	3		12679	
12BA7	tri	4	13	4	1			12	
12BB14		4	13	20	2	38	123678	1+26+70	
12BD6		3	13	8	1	7		1256	
12BE3		1	13	23	2	9	60	60	note(s)
12BE6	tot	3	13	4	1	2		1567	
12BE6	tri	3	13	4	1			16	
12BF11	pen-1	1	13	28	2	2		3567	note(s)
12BF11	pen-2	7	13	23	2	4		356	
12BF6	di-1	3	13	27	3			6	
12BF6	di-2	3	13	27	3			5	
12BF6	tri	3	13	11	1	2		17	
12BH7	tri-1	9	9	4	1	8	45	67	
12BH7	tri-2	9	9	4	1	3		12	
12BK5		4	13	24	2	6	37	3+718	
12BK6	di-1	3	13	23	3			6	
12BK6	di-2	3	13	23	3			5	
12BK6	tri	3	13	7	1	2		17	
12BL6		3	13	24	2	7		1256	
12BN6		3	13	41	3	1		2567	
12BQ6		2	13	5	1	8		450	
12BR3		4	13	18	3	0	29	2+9	
12BR7	di-1	9	9	18	3	8		7	
12BR7	di-2	9	9	18	3			6	
12BR7	tri	9	9	23	2	3	45	12	
12BS3		4	13	16	3	9	27	2+7	
12BT3	di-2	3	13	26	3			6	note(s)
12BT3		1	13	2	4	7		4	
12BT6	di-1	3	13	26	3			5	
12BT6	tri	3	13	24	2	2		17	
12BU6	di-1	3	13	23	3			6	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
12BU6	di-2	3	13	23	3			5	
12BU6	tri	3	13	10	1	2		17	
12BV11	pen-1	6	13	21	2	2		134	note(s)
12BV11	pen-2	1	13	21	2	7		568	
12BV7		6	9	23	2	1	3459	3+927	
12BW4	pl-1	4	13	14	1	9		7	
12BW4	pl-2	4	13	14	1			1	
12BX6		4	13	22	2	13	13	278	
12BY7		6	9	22	2	1	3459	278	
12BZ6		3	13	23	2	2		1567	
12BZ7	tri-1	9	9	22	2	8	45	67	
12BZ7	tri-2	9	9	22	2	3		12	
12C5		3	13	3	1	1	25	2+567	
12C8	di-1	2	13	27	3			4	
12C8	di-2	2	13	27	3			5	
12C8	pen	2	13	17	1	8		360	
12CA5		3	13	5	1	1	25	2+567	
12CD6		2	13	4	1	3		580	
12CK3		4	13	20	2	9	27	2+7	
12CL3		4	9	20	2	9	27	2+7	
12CM6		4	13	25	2	7	36	3+619	
12CN5		3	13	4	1	1	25	2+567	
12CR6	di	3	13	26	3	1		2	
12CR6	pen	3	13	26	2			567	
12CS6	tot	3	13	24	2			156?	
12CS6	tri	3	13	24	2	2		16	
12CT3		4	13	23	2	9	26	2+6	
12CT8	pen	4	13	25	2	9		678	
12CT8	tri	4	13	25	2	3		12	
12CU5	pen	3	13	4	1	1	25	2+567	
12CU6	pen	2	13	4	1	8		459	
12CX6	pen	3	13	23	2	7		1256	
12D4		7	13	4	1	3		5	
12DA6		4	13	24	2	3	16	278	
12DB5	pen	4	13	6	1	27	2367	13+69	
12DE8	di	4	13	19	3	2		3	
12DE8	pen	4	13	26	2	9		1678	
12DF5	di-1	9	9	19	3	8	45	?	
12DF5	di-2	9	9	19	3	3		?	
12DF7	tri-1	9	9	8	1	3	45	?	
12DF7	tri-2	9	9	8	1	8		?	
12DJ8	tri-1	4	13	21	2	8		?	
12DJ8	tri-2	4	13	21	2	3		?	
12DK6		3	13	23	2	2		1567	
12DK7	di-1	4	13	22	3			?	note(s)
12DK7	di-2	4	13	23	3			?	
12DK7	tet	4	13	23	2	2		?1+?	
12DL8	di-1	4	13	46	2	8		?	
12DL8	di-2	4	13	46	2			?	
12DL8	tet	4	13	23	2	2		?	
12DM4		7	13	24	2	3		5	
12DM7	tri-1	9	9	27	2	8	45	67	
12DM7	tri-2	9	9	27	2	3		12	
12DN6		2	13	23	2	3		?	
12DQ4		7	13	18	3	3		5	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
12DQ5		2	13	2	1	36	?	?1+?4+?	
12DQ6	pen	2	13	4	1	8		450	
12DQ7	pen	6	9	22	2	1	39	2389	
12DS7	di-1	4	13	25	3			?	
12DS7	di-2	4	13	25	3			?	
12DS7	tet	4	13	22	2	8		?	
12DT5	pen	4	13	22	2	7	36	13+69	
12DT6		3	13	24	2	2		1567	
12DT7	tri-1	9	9	27	2	8	45	67	
12DT7	tri-2	9	9	27	2	3		12	
12DT8	tri-1	4	13	23	2	8		67	
12DT8	tri-2	4	13	23	2	3		12	
12DU7	di-1	4	13	29	3			?	
12DU7	di-2	4	13	29	3			?	
12DU7	tet	4	13	21	2	2		?	
12DV7	di-1	9	9	31	3	1		?	
12DV7	di-2	9	9	31	3			?	
12DV7	tri	9	9	28	2	8	459	?	
12DV8	di-1	4	13	43	2	8		?	
12DV8	di-2	4	13	43	2			?	
12DV8	tet	4	13	23	2	2		?	
12DW4		4	13	4	1	9	27	2	note(s)
12DW5		4	13	24	1	7	36	?3+?	
12DW7	tri-1	9	9	24	2	8	45	67	
12DW7	tri-2	9	9	26	2	3		12	
12DW8	di	4	13	28	2	8		?	
12DW8	tri-1	4	13	22	2	8		?	
12DW8	tri-2	4	13	22	2	3		?	
12DY8	tet	4	13	21	2	2		136	
12DY8	tri	4	13	24	2	7		89	
12DZ6	pen	3	13	23	2	7		1625	
12DZ7	pen-1	2	13	5	1	8		456	
12DZ7	pen-2	2	13	5	1			134	
12DZ8	pen	4	13	23	2	2		367	
12DZ8	tri	4	13	28	2	8		19	
12E13		2	9	24	2	8		345	
12E14	pen	2	9	<26	2	8		5,4,6,3	
12E5	tri	2	13	13	1	8		63	
12EA6	pen	3	13	22	2	7		1625	
12EC8	pen	4	13	21	2	8		97 6	
12EC8	tri	4	13	22	2	3		12	
12ED5	pen	3	13	23	2	1		2+567	
12EG6	amp	3	13	42	2	2		1567	
12EG6	osc	3	13	23	2			16	
12EH5	pen	3	13	24	2	1	25	2+567	
12EH8	pen	4	13	2	1	16	?	?	
12EH8	tri	4	13	0	1			?	
12EK6	pen	3	13	23	2	7		1625	
12EL6	di-1	3	13	27	3	7		5	
12EL6	di-2	3	13	27	3			6	
12EL6	tri	3	13	26	2			12	
12EM6	di	4	13	23	3			?	
12EM6	tet	4	13	24	2	2		?	
12EN6	pen	7	13	24	2	8		54 3	
12EQ7	di	4	13	29	3	3		8	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
12EQ7	pen	4	13	23	2			2617	
12EZ6		4	13	23	2	7		?	
12F5	tri	2	13	8	1	8		04	
12F8	di-1	4	13	27	3			1	
12F8	di-2	4	13	27	3			6	
12F8	pen	4	13	7	1	7		8293	
12FK6	di-1	3	13	25	2			5	
12FK6	di-2	3	13	25	2			6	
12FK6	tri	3	13	25	2	2		17	
12FM6	di-1	3	13	45	1			? {5or6}	
12FM6	di-2	3	13	33	1			? {5or6}	
12FM6	tri	3	13	25	2	2		17	
12FQ7	tri-1	4	13	7	1	8		67	
12FQ7	tri-2	4	13	7	1	3		12	
12FQ8	pen-1	4	13	25	2	9		?	
12FQ8	pen-2	4	13	25	2			?	
12FR8	di	4	13	28	3	?			
12FR8	pen	4	13	22	2	?			
12FR8	tri	4	13	25	2	?			
12FS5		3	13	22	2	27	27	156	
12FV7	tri-1	5	9	18	3	8	49	67	
12FV7	tri-2	4	9	18	3	3	59	12	
12FX5		3	13	17	3	1	25	267	note(s)
12FX8	hep	4	13	23	2	?			
12FX8	tri	4	13	25	2	?			
12FY8	pen	4	13	22	2	?			
12FY8	tri	4	13	24	2	?			
12G11	pen-1	7	13	23	2	2		134	note(s)
12G11	pen-2	1	13	25	2	4		5689	
12G4		3	13	7	1	?		?+?	
12G8	tri-1	9	9	23	2	?			
12G8	tri-2	9	9	23	2	?			
12GA6	tot	3	13	24	2	2		1567	
12GA6	tri	3	13	24	2	2		16	
12GB3		2	13	20	2	8		450	
12GB7		2	13	4	1	8		450	
12GC5		4	13	23	2	7	1368	1+83+69	
12GC6	pen	2	13	23	2	3		58 9 ?+?	
12GE5			13	23	2	?		?+?	
12GJ5		4	13	24	2	3	1267	670	note(s)
12GK17		7	13	7	1	3		5	
12GN7		6	9	21	2	1	39	278	
12GT5		4	13	23	2	3	1267	1+2+679	
12GV5		3	13	24	2	18	1278	2790	note(s)
12GW6		2	13	18	2	8		450	
12H4		2	9	7	1	?		?+?	
12H6	di-1	2	13	18	3	4		3	
12H6	di-2	2	13	18	3	8		5	
12HB25		4	13	21	2	9	123678	1+26+70	
12HE7	di	1	13	16	3	4		2	note(s)
12HE7	pen	7	13	16	2	3		46	
12HG7		6	9	20	2	1	39	278	
12HL5		4	13	21	2	3	12	1+279	
12HL7		6	9	20	2	1	3459	3+9278	
12HU8	pen-1	4	13	22	2	7		123	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
12HU8	pen-2	4	13	22	2			689	
12J5	tri	2	13	9	1	8		53	
12J7	pen	2	13	11	1	8		0453	
12J8	di-1	4	13	17	3	7		8	
12J8	di-2	4	13	17	3			9	
12J8	tet	4	13	4	1	2		136	
12JB6		4	13	18	3	3	1267	670	note(s)
12JF5		4	13	20	2	29	2389	3780	note(s)
12JM6		2	13	21	2	5		680	note(s)
12JN6		6	13	21	2	7	29	380	note(s)
12JN8	pen	4	13	23	2	8		679	
12JN8	tri	4	13	22	2	3		12	
12JQ6	di	4	13	21	3			6	
12JQ6	pen	4	13	22	2	9	2378	12378	
12JS6		4	13	20	2	5	16	1+680	note(s)
12JT6		4	13	23	2	3	17	279	note(s)
12JZ8	pen	9	13	23	2	4	12	1+230	note(s)
12JZ8	tri	6	13	26	2	3		27	
12K5	pen	3	13	3	1	1		5+627	
12K7	pen	2	13	11	1	8		0453	
12K8	hex	2	13	5	1			3450	
12K8	tri	2	13	5	1	8		56	
12KA8	pen	4	13	22	2	3		6789	
12KA8	tri	4	13	24	2	3		12	
12KL8	di	4	13	28	3			8	
12KL8	pen	4	13	24	2	3		1267	
12L6	pen	2	13	5	1	8		54 3	
12L8	Pen-1	6	13	10	1	2		15 8	
12L8	Pen-2	6	13	10	1			15 4	
12MD8	tri-1	4	13	22	2	7		36	
12MD8	tri-2	4	13	22	2			28	
12MD8	tri-3	4	13	22	2			19	
12MX8	pen	4	13	21	2	3		267	
12MX8	tri	4	13	25	2	1		89	
12Q7	di-1	2	13	27	3			4	
12Q7	di-2	2	13	27	3			5	
12Q7	tri	2	13	10	1	8		03	
12R5	pen	3	13	4	1	1		2+567	
12RK19		4	13	17	3	0	29	2+9	
12RLL3	tri-1	9	9	22	2	8	45	67	
12RLL3	tri-2	9	9	22	2	3		12	
12RLL5	tri-1	4	13	7	1	8		67	
12RLL5	tri-2	4	13	7	1	3		12	
12S8	di-1	7	13	27	3			1	note(s)
12S8	di-2	7	13	27	3			4	
12S8	di-3	7	13	27	3	5		3	
12S8	tri	7	13	10	1	2		06	
12SA7	tot	2	13	7	1	6		54813	
12SA7	tri	2	13	7	1			54	
12SC7	tri-1	7	13	12	1	6		32	
12SC7	tri-2	7	13	12	1			45	
12SF5	tri	7	13	9	1	2		35	
12SF7	di	7	13	27	3			5	
12SF7	pen	7	13	12	1	3		24 6	
12SG7	pen	2	13	5	1	35		46 8	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
12SH7	pen	2	13	5	1	35		46 8	
12SJ7	pen	2	13	7	1	5		4638	
12SK7	pen	2	13	9	1	5		4638	
12SL7	tri-1	7	13	11	1	6		45	
12SL7	tri-2	7	13	11	1	3		12	
12SN7	tri-1	7	13	8	1	6		45	
12SN7	tri-2	7	13	8	1	3		12	
12SQ7	di-1	7	13	26	3			4	
12SQ7	di-2	7	13	26	3			5	
12SQ7	tri	7	13	11	1	3		26	
12SR7	di-1	7	13	27	3			4	
12SR7	di-2	7	13	27	3			5	
12SR7	tri	7	13	12	1	3		26	
12SW7	di-1	7	13	27	3			4	
12SW7	di-2	7	13	27	3			5	
12SW7	tri	7	13	12	1	3		26	
12SX7	tri-1	7	13	8	1	3		12	
12SX7	tri-2	7	13	8	1	6		45	
12SY7	tot	2	13	7	1	6		54813	
12SY7	tri	2	13	7	1			54	
12T10	pen-1	5	13	19	3	2		134	note(s)
12T10	pen-2	1	13	19	3	4		5789	
12U7	tri-1	9	9	8	1	8		76	
12U7	tri-2	9	9	8	1	3		21	
12V6	pen	2	13	8	1	8		54 3	
12W6	pen	2	13	4	1	8		54 3	
12X4	pl-1	3	13	11	1	7		1	
12X4	pl-2	3	13	11	1			6	
12Z3		1	13	5	1	3		2	
12Z5	pl-1	4	9	8	1	3		2	
12Z5	pl-2	4	9	8	1	5		6	
13CM5		2	13	23	2	38	1348	459	note(s)
13CW4	tri	4	13	17	3	3		2,1	
13CW9		4	12	17	3	3		27	
13DE7	tri-1	4	13	9	1	8		76	
13DE7	tri-2	4	13	3	1	9		2+31	
13DF7	tri-1	4	13	8	1	8		76	
13DF7	tri-2	4	13	22	2	9		2+31	
13DR7	tri-1	4	13	28	2	8		76	
13DR7	tri-2	4	13	23	2	9		2+31	
13EM7	tri-1	7	13	26	2	6		45	
13EM7	tri-2	7	13	22	2	3		12	
13FM7	tri-1	6	13	19	3	3		45	note(s)
13FM7	tri-2	1	13	19	3	9		57	
13FR7	tri-1	4	13	7	1	8	23	67	
13FR7	tri-2	4	13	20	2	9		12+3	
13GB5		4	13	22	2	38	123678	160	note(s)
13GF7	tri-1	4	13	29	2	1		89	
13GF7	tri-2	4	13	23	2	3		26	
13J10	pen-1	0	13	26	4	8	1	4567	note(s)
13J10	pen-2	5	13	18	3	9	7	248	
13JT8	pen	4	13	21	2	6		789	
13JT8	tri	4	13	23	2	1		23	
13JZ8	pen	1	13	22	2	9	67	4678	note(s)
13JZ8	tri	3	13	28	2	2		16	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
13V10	pen-1	1	13	22	2	2		367	note(s)
13V10	pen-2	7	13	21	2	4		356	
13Z10	pen-1	0	13	26	4	8	1	4567	note(s)
13Z10	pen-2	5	13	18	3	9	7	248	
14A4	tri	1	13	8	1	7		62	
14A5	pen	1	13	10	1	7		63 2	
14A7	pen	1	13	9	1	7		6342	
14AF7	tri-1	1	13	10	1	7		56	
14AF7	tri-2	1	13	10	1	2		43	
14B6	di-1	1	13	26	3			5	
14B6	di-2	1	13	26	3			6	
14B6	tri	1	13	11	1	47		32	
14B8	tot	1	13	6	1	7		43562	
14B8	tri	1	13	8	1			43	
14BF11	pen-1	1	13	28	2	2		3567	note(s)
14BF11	pen-2	7	13	23	2	4		356	
14BL11	pen	6	14	20	2	2		459	note(s)
14BL11	tri-1	1	14	22	2	6		57	
14BL11	tri-2	4	14	20	2	9		18	
14BQ11	pen-1	9	14	19	2	6		345	note(s)
14BQ11	pen-2	3	14	19	2	8		457	
14BR11	pen	4	14	21	2	9		378	note(s)
14BR11	tri-1	1	14	23	2	5		68	
14BR11	tri-2	4	14	23	2	0		12	
14C5	pen	1	13	6	1	7		63 2	
14C7	pen	1	13	8	1	7		6342	
14E6	di-1	1	13	27	3			5	
14E6	di-2	1	13	27	3			6	
14E6	tri	1	13	11	1	47		32	
14E7	di-1	1	13	27	3			3	
14E7	di-2	1	13	27	3			4	
14E7	pen	1	13	13	1	7		65 2	
14F7	tri-1	1	13	10	1	7		56	
14F7	tri-2	1	13	10	1	2		43	
14F8	tri-1	2	13	24	2	5		86	
14F8	tri-2	2	13	24	2	4		13	
14GJ8	di-1	4	14	18	3	3		2	
14GJ8	di-2	4	14	18	3	1		6	
14GJ8	tri	4	14	3	7			89	
14GT8	di-1	4	13	18	3	3		2	
14GT8	di-2	4	13	18	3	1		6	
14GT8	tri	4	13	28	2	7		89	
14GW8	pen	4	14	23	2	7		368	
14GW8	tri	4	14	26	2	2		19	
14H7	pen	1	13	24	2	7		6342	
14J7	hex	1	13	7	1			256	
14J7	tri	1	13	13	1	7		34	
14K7	hex	1	13	24	2			2456	
14K7	tri	1	13	26	2	7		34	
14L7	di-1	1	13	27	3			6	
14L7	di-2	1	13	27	3			5	
14L7	tri	1	13	26	2	7		23	
14N7	tri-1	1	13	8	1	7		56	
14N7	tri-2	1	13	8	1	2		34	
14Q7	tot	1	13	5	1	7		23456	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
14Q7	tri	1	13	5	1			34	
14R7	di-1	1	13	26	3			4	
14R7	di-2	1	13	26	3			3	
14R7	pen	1	13	6	1	7		256	
14S7	hep	1	13	6	1			256	
14S7	tri	1	13	12	1	7		34	
14W7		1	13	4	1	47	47	2356	
14X7	di-1	1	13	26	3			5	
14X7	di-2	1	13	26	3	7		6	
14X7	tri	1	13	10	1	4		23	
14Y4	pl-1	1	13	10	1	7		3	
14Y4	pl-2	1	13	10	1			6	
15		1	3	34	2	4		230	
15A6		4	14	25	2	3		1267	
15AF11	di-1	1	14	19	3	9		56	note(s)
15AF11	di-2	1	14	19	3	5		68	
15AF11	pen	6	14	19	3	3		459	
15BD11	pen	4	14	25	2	1		237	note(s)
15BD11	tri-1	1	14	24	2	5		68	
15BD11	tri-2	1	14	25	2	7		34	
15CW5		4	14	21	2	3		1+26+97	note(s)
15DQ8	pen	4	14	24	2	7		689	
15DQ8	tri	4	14	23	2	3		12	
15EA7	tri-1	7	14	26	2	6		45	
15EA7	tri-2	7	14	3	1	3		12	
15EW6		3	14	20	2	2		156	
15EW7	tri-1	4	14	27	2	8		67	
15EW7	tri-2	4	14	23	2	9	23	12+3	
15FM7	tri-1	6	14	19	3	3		45	note(s)
15FM7	tri-2	1	14	19	3	9		57	
15FO7		5	14	19	2	0		12	
15FY7	tri-1	4	14	8	1	1		23	note(s)
15FY7	tri-2	1	14	22	2	9		57	
15HA6		4	14	22	2	1	3689	26+87	
15HB6		4	14	22	2	1	3689	23+6+789	
15KY8	pen	4	14	21	2	3		267	
15KY8	tri	4	14	25	2	1		89	
15LE8	pen-1	4	14	22	2	3		189	
15LE8	pen-2	4	14	22	2			689	
15MF8	pen	9	14	22	2	4	12	1+230	note(s)
15MF8	tri	9	14	21	2	3		27	
15MX8	pen	4	14	21	2	3		267	
15MX8	tri	4	14	25	2	1		89	
1602		1	10	18	1			23	
1603		1	9	10	1	5		2340	
1609		1	2	19	1			234	
1610		1	4	12	1			234	
1611		2	9	11	1	8		345	
1612		2	9	8	1	8		3450	
1613		2	9	11	1	8		345	
1614		2	9	7	1	8		345	
1619		2	4	9	1			3458	
1620		2	9	11	1	8		3450	
1621		2	9	11	1	8		345	
1622		2	9	7	1	8		345	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
1624		1	4	9	1			230	
1625		1	13	7	1			340	
1626		2	13	13	1	8		35	
1629	eye	2	13	0	4			34	note(s)
1629	tri	2	13	19	1	8		35	
1631		2	13	7	1	8		345	
1632		2	13	5	1	8		345	
1633	tri-1	7	18	8	1	6		45	
1633	tri-2	7	18	8	1	3		12	
1634	tri-1	7	13	13	1	6		23	
1634	tri-2	7	13	13	1			45	
1635	tri-1	2	9	11	1	8		56	
1635	tri-2	2	9	11	1			34	
1639	di-1	2	9	21	3			5	
1639	di-2	2	9	21	3			4	
1639	tri	2	9	7	1	8		30	
1644	pen-1	6	13	10	1	2		345	
1644	pen-2	6	13	10	1			158	
1650		1	9	8	1	5		23	
1655	tri-1	7	9	12	1	6		45	
1655	tri-2	7	9	12	1			23	
1657		2	9	3	1	8	14	35	
1659	di-1	1	4	27	3			3	
1659	di-2	1	4	27	3			4	
1659	tri	1	4	10	1	5		20	
1662		5	2	30	1		1267	2+634	
16A5		4	15	21	2	3		279	
16A8	pen	4	15	21	2	2		367	
16A8	tri	4	15	24	2	8		19	
16AK9	pen	1	10	22	2	2	79	34	note(s)
16AK9	tri-1	6	10	26	2	7	10	23	
16AK9	tri-2	1	10	24	2	2		56	
16AQ3		4	14	23	2	0	1236789	+9	note(s)
16BQ11	pen-1	3	15	22	2	8		457	note(s)
16BQ11	pen-2	9	15	22	2	6		345	
16BX11	pen	5	15	23	2	1		267	note(s)
16BX11	tri-1	1	15	22	2	9		78	
16BX11	tri-2	1	15	22	2	4		56	
16CB28		3	14	17	3	6	1278	2790	note(s)
16GK6		4	15	23	2	1	39	278	
16GY5		3	14	22	2	18	1278	2790	note(s)
16HB5		1	14	22	2	4		237	note(s)
16KA6		3	14	20	2	1	28	790	note(s)
16KH8		4	13	23	2	7		12	
16KH8		4	13	23	2			239	
16KH8		4	13	23	2			689	
16LD6		4	14	20	2	1	3689	26+87	
16LU8	pen	9	15	21	2	4	12	1+230	note(s)
16LU8	tri	6	15	21	2	3		27	
16MY8	pen	9	15	21	2	4	12	1+230	note(s)
16MY8	tri	6	15	21	2	3		27	
16Y9	pen-1	5	15	20	2	7		890	
16Y9	pen-2	5	15	20	2	2		134	
17		1	13	12	1	4		23	
17A8	pen	4	15	24	2	7		236	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
17A8	tri	4	15	24	2	8		19	
17AB10	pen-1	5	15	20	2	9		248	note(s)
17AB10	pen-2	0	15	24	2	8		4567	
17AV5		2	16	5	1	3		158	
17AX3		6	15	24	2	0	29	2+9	note(s)
17AX4		7	17	7	1	3		5	
17AY3		4	15	24	2	9	27	2+7	
17B4		2	15	8	1			35	
17BB14		4	15	20	2	38	123678	1+26+70	
17BD11	pen	4	15	25	2	1		237	note(s)
17BD11	tri-1	1	15	24	2	5		68	
17BD11	tri-2	1	15	25	2	7		34	
17BE3		1	15	23	2	9	60	60	note(s)
17BF11	pen-1	1	15	28	2	2		3567	note(s)
17BF11	pen-2	7	15	23	2	4		356	
17BH3		4	15	24	2	9	27	2+7	
17BJ6		3	15	23	2	2		1567	
17BQ6		2	16	5	1	8		450	
17BR3		4	15	23	2	0	29	2+9	
17BS3		4	15	16	3	9	27	2+7	
17BW3		1	15	17	3	7		4	note(s)
17BZ3		1	15	16	3	7		4	note(s)
17C5		3	16	3	1	1	25	2+567	
17C8	di-1	4	15	25	3			8	
17C8	di-2	4	15	25	3			7	
17C8	pen	4	15	25	2	3		2169	
17C9	tet-1	1	15	24	2	6		789	
17C9	tet-2	4	15	24	2	0		123	
17CA5		3	16	5	1	1	25	2+567	
17CK3		4	15	20	2	9	27	2+7	
17CL3		4	14	20	2	9	27	2+7	
17CT3		4	15	23	2	9	26	2+6	
17CU5		3	16	4	1	1	25	2+567	
17D4		7	16	4	1	3		5	
17DE4		7	15	4	1	3		5	
17DG6		2	15	5	1	8		345	
17DM4		7	15	24	2	3		5	
17DQ4		7	15	18	3	3		5	
17DW4		4	15	4	1	9	27	2	note(s)
17EW8	tri-1	5	15	22	2	8		67	
17EW8	tri-2	5	15	22	2	3		12	
17FQ6		2	16	4	1	8		450	
17FY7	tri-1	4	15	8	1	1		23	note(s)
17FY7	tri-2	1	15	22	2	9		57	
17GE5		6	15	23	2	29	2389	73+80	note(s)
17GJ5		4	15	24	2	3	1267	670	note(s)
17GT5		4	15	23	2	3	1267	1+2+679	
17GT6		1	15	28	2	2		3567	
17GV5		3	15	24	2	18	1278	2790	note(s)
17GW6		2	15	18	3	8		450	
17GY5		3	15	22	2	18	1278	2790	note(s)
17H3		4	16	7	1	1	38	3+8	
17HB25		4	15	21	2	9	123678	1+26+70	
17HC8	pen	4	15	18	3	2		367	
17HC8	tri	4	15	18	3	8		19	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
17HG8	pen	4	15	22	2	1		289	
17HG8	tri	4	15	23	2	3	13	67	
17JB6		4	15	18	3	3	1267	670	note(s)
17JF6		4	15	20	2	3	1267	1+2+3+70	
17JG6		4	15	17	3	3	17	279	note(s)
17JK8	tri-1	4	15	18	3	8		67	
17JK8	tri-2	4	15	18	3	3		12	
17JM6		2	15	21	2	5		680	note(s)
17JN6		6	15	21	2	7	29	380	note(s)
17JQ6	di	4	15	21	3			6	
17JQ6	pen	4	15	22	2	9	2378	12378	
17JR6		4	15	28	3	3	17	279	note(s)
17JS6		4	15	20	2	5	16	1+680	note(s)
17JT6		4	15	23	2	3	17	279	note(s)
17JU6		4	15	20	2	5	16	1+680	note(s)
17JZ8	pen	9	15	23	2	4	12	1+230	note(s)
17JZ8	tri	6	15	26	2	3		27	
17KV6		4	15	20	2	3	17	279	note(s)
17L6		2	16	5	1	8		345	
17LD8	pen	4	15	21	2	3		267	
17LD8	tri	4	15	25	2	1		89	
17R5		3	16	4	1	1	25	2+567	
17RHH2	tri-1	5	15	22	2	8		67	
17RHH2	tri-2	5	15	22	2	3		12	
17RK19		4	15	23	2	0	29	2+9	
17W6		2	15	24	2	8		345	
17X10	pen-1	0	15	20	4	8	1	4567	note(s)
17X10	pen-2	5	15	17	3	9	7	248	
17Y9	pen-1	5	15	20	2	7		890	
17Y9	pen-2	5	15	20	2	2		134	
17Z3		4	15	2	4	0		9	
18		1	13	11	1	5		234	
18042	pen	4(5)	15	<23	2	3		2,1,(9),6	
1805	pl-1	2(3)	6	<18	1			1	
1805	pl-2	2(3)	6	<18	1			4	
1851		2	9	3	1	8		3450	
1852		2	9	3	1	5		3468	
1853		2	9	5	1	5		3468	
1875	rec	2(3)	7	<32	3			0	
1876	rec	2(3)	6	<30	1			8	
18A5		2	16	5	1	3		158	
18AJ10	pen-1	3	16	23	2	4		578	note(s)
18AJ10	pen-2	5	16	23	2	2		134	
18DZ8	pen	4	16	23	2	2		367	
18DZ8	tri	4	16	28	2	8		19	
18FW6		3	16	23	2	7		1256	
18FX6	tot	3	16	23	2	2		1567	
18FX6	tri	3	16	23	2			16	
18FY6	di-1	3	16	28	3			6	
18FY6	di-2	3	16	28	3			5	
18FY6	tri	3	16	25	2	2		17	
18GB5		4	16	22	2	38	123678	160	note(s)
18GD6		3	16	23	2	7		156	
18GV5		3	16	24	2	18	1278	2790	note(s)
18GV8	pen	4	16	22	2	8		679	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
18GV8	tri	4	16	24	2	3		12	
18HB6	pen	4	16	24	2	8		679	
18HB8	tri	4	16	23	2	2		13	
18RAL1	tri-1	4	16	25	2	8	23	67	
18RAL1	tri-2	4	16	21	2	9		12+3	
19	tri-1	1	3	17	1			23	
19	tri-2	1	3	17	1			45	
19A3		6	9	22	2	7	346	5	
19AJ8	hep	4	16	23	2	3		126	
19AJ8	tri	4	16	24	2			89	
19AQ5		3	16	7	1	2	17	1+756	
19AU4		7	16	22	2	3		5	
19BG6		2	16	6	1	3		580	
19BR5	eye	4	16	0	4			7369	note(s)
19BR5	tri	4	16	7	1	2	369	17	
19BX6		4	16	21	2	13	13	2897	
19BY7		4	16	23	2	13	13	2789	
19C8	di-1	4	16	17	3			6	
19C8	di-2	4	16	17	3	3		2	
19C8	di-3	4	16	17	3			1	
19C8	tri	4	16	26	2	7		89	
19CG3		1	16	16	3	7		4	note(s)
19CL8A	tet	4	16	23	2	8		679	
19CL8A	tri	4	16	23	2	3		12	
19D8	hep	4	16	23	2	3		126	
19D8	tri	4	16	24	2			89	
19DE3		6	16	20	2	0		4	note(s)
19DE7	tri-1	4	16	9	1	8	23	67	
19DE7	tri-2	4	16	3	1	9		12+3	
19DK3		4	16	23	2	0	27	2+7+	
19DQ3		1	16	16	3	7		4	note(s)
19EA8	pen	4	16	22	2	7		236	
19EA8	tri	4	16	23	2	8		19	
19EW3	tri-2	4	16	23	2	9	23	12+3	
19EW7	tri-1	4	16	27	2	8		67	
19EZ8	tri-1	4	16	27	2			89	
19EZ8	tri-2	4	16	27	2			67	
19EZ8	tri-3	4	16	23	2	1		23	
19FL8	di-1	4	16	21	3			7	
19FL8	di-2	4	16	21	3			8	
19FL8	pen	4	16	24	2	3		1269	
19FX5		3	16	17	3		25	267	note(s)
19GQ7	di-1	4	16	17	3	9		8	
19GQ7	di-2	4	16	17	3	7		6	
19GQ7	di-3	4	16	17	3	1		2	
19HR6		3	16	21	2	7		156	
19HS6		3	16	22	2	7		1256	
19HV8	pen	4	16	22	2	8		679	
19HV8	tri	4	16	26	2	3		12	
19J6	tri-1	3	16	23	2	7		25	
19J6	tri-2	3	16	23	2			16	
19JC6		4	16	22	2	13	13	278	
19JN8	pen	4	16	23	2	8		679	
19JN8	tri	4	16	22	2	3		12	
19KF6		4	16	20	2	3	17	1+6+79	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
19KG8	pen	2	16	22	2	8		679	
19KG8	tri	2	16	22	2	3		12	
19MR9		3	16	23	2	7		156	
19Q9	pen	4	16	20	2	0		123	
19Q9	tri	4	16	21	2	7		89	
19T8	di-1	4	16	16	3			6	
19T8	di-2	4	16	16	3	3		2	
19T8	di-3	4	16	16	3			1	
19T8	tri	4	16	10	1	7		89	
19U3		4	16	3	1	3		9	
19V8	di-1	4	16	24	3			9	
19V8	di-2	4	16	16	3	3		7	
19V8	di-3	4	16	16	3			2	
19V8	tri	4	16	26	2	8		16	
19W3		4	16	3	1	3		9	
19X3		4	16	3	1	3		9	
19X8	pen	4	16	24	2			1789	
19X8	tri	4	16	24	2	6		23	
19Y3		4	13	3	1	3		9	
1A3	di	1	2	27	3	3	26	2+6	note(s)
1A4		1	3	34	2			230	
1A5		2	2	32	2			345	
1A6	tot	1	3	34	2			23450	
1A6	tri	1	3	39	2			34	
1A7	tot	2	2	33	2			34560	
1A7	tri	2	2	38	2			56	
1AB5		1	2	30	2		78	236	
1AB6		7	2	20	1			23456	
1AC5		4	2	31	2			278	
1AC6	amp	7	2	12	1			23456	
1AC6	osc	7	2	29	2			345	
1AD4		5	2	26	2			124	
1AD5		4	2	32	2			278	
1AE4		7	2	11	1		15	236	
1AF4		7	2	29	2		15	236	
1AF5		1	2	31	2			3456	
1AG4		3	2	30	2			124	
1AG5	di	4	2	25	3			3	
1AG5	pen	4	2	34	2			125	
1AH4		3	2	29	2			124	
1AH5	di	7	2	30	3			3	
1AH5	pen	7	2	44	2			456	
1AJ4		7	2	32	2		15	632	
1AJ5	di	4	2	24	3			3	
1AJ5	pen	4	2	36	2			125	
1AK4		3	2	32	3			124	
1AK5	di	4	2	29	3			3	
1AK5	pen	4	2	35	3			125	
1AN5		7	2	17	1		15	2346	
1AU2		4	2	324			19	19	note(s)
1AX2		258	2	45	4		1469	0	
1AY2		1	2	20	4			0	
1B3		2	2	26	4			0	
1B4		1	3	34	2			230	
1B5	di-1	1	3	27	3			3	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
1B5	di-2	1	3	27	3			4	
1B5	tri	1	3	34	2			25	
1B7	tot	2	2	31	2			34560	
1B7	tri	2	2	35	2			56	
1B8	di	2	2	27	3			8	
1B8	pen	2	2	31	2			345	
1B8	tri	2	2	35	2			60	
1BC2		258	2	25	4		169	0	
1BG2		1	2	17	4			0	note(s)
1BK2		258	2	21	4		1469	0	
1BQ2		258	2	26	4		1469	0	
1BX2		258	2	24	4		1245689	0	
1BY2		1	2	25	4			0	note(s)
1C2	amp	7	2	12	1			23456	
1C2	osc	7	2	29	2			345	
1C21			24	14	1	2		5	
1C3		1	2	32	2		26	2+64	
1C5		2	2	30	2			345	
1C6	tot	1	3	32	2			23450	
1C6	tri	1	3	36	2			34	
1C7	tot	2	3	33	2			34560	
1C7	tri	2	3	37	2			56	
1C8	tot	4	2	36	2			2678	
1C8	tri	4	2	36	2			27	
1D13	di	1	2	27	3	3	26	2+6	note(s)
1D3		4	2	26	2			18	
1D5		2	3	33	2			340	
1D6		2	3	33	2			340	
1D7	tot	2	3	35	2			34560	
1D7	tri	2	3	40	2			56	
1D8	di	2	2	27	3			8	
1D8	pen	2	2	32	2			345	
1D8	tri	2	2	38	2			60	
1DG3		35	2	47	4		3456	0	
1DK1		1	1	38	4			0	note(s)
1DK29		1	2	17	4			0	note(s)
1DN5	di	1	2	38	3			4	
1DN5	pen	1	2	36	2			236	
1E4		2	2	31	2			35	
1E5		2	3	34	2			340	
1E7	pen-1	2	3	30	2			348	
1E7	pen-2	2	3	30	2			568	
1E8	tot	4	2	33	2			2678	
1E8	tri	4	2	33	2			27	
1F4		1	3	31	2			234	
1F5		2	3	31	2			345	
1F6	di-1	1	3	27	3			4	
1F6	di-2	1	3	27	3			5	
1F6	pen	1	3	35	2			230	
1F7	di-1	2	3	27	3			4	
1F7	di-2	2	3	27	3			5	
1F7	pen	2	3	35	2			360	
1G3		2	2	26	4			0	
1G4		2	2	32	2			35	
1G5		2	3	30	2			345	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
1G6	tri-1	2	2	32	2			34	
1G6	tri-2	2	2	32	2			56	
1H2		258	2	39	3		124589	0	note(s)
1H35		7	2	20	1			23456	
1H4		2	3	34	2			35	
1H5	di	2	2	27	3			5	
1H5	tri	2	2	35	2			30	
1H6	di-1	2	3	30	3			4	
1H6	di-2	2	3	30	3			5	
1H6	tri	2	3	34	2			36	
1J3		2	2	35	4			0	note(s)
1J5		2	3	31	2			345	
1J6	tri-1	2	3	31	2			34	
1J6	tri-2	2	3	31	2			56	
1K3		2	2	35	4		7	0	note(s)
1L4		7	2	32	2		15	236	
1L6	tot	1	2	35	2			23456	
1L6	tri	1	2	39	2			34	
1LA4		1	2	32	2			236	
1LA6	tot	1	2	34	2			23456	
1LA6	tri	1	2	39	2			34	
1LB4		1	2	31	2			236	
1LC5		1	2	31	2		58	2346	
1LC6	tot	1	2	36	2			23456	
1LC6	tri	1	2	42	2			34	
1LD5	di	1	2	27	3			4	
1LD5	pen	1	2	34	2			236	
1LE3		1	2	32	2			26	
1LF3		1	2	32	2			26	
1LG5		1	2	31	2		58	2346	
1LH4	di	1	2	27	3			4	
1LH4	tri	1	2	35	2			26	
1LN5		1	2	31	2		58	2346	
1M3	eye	4	2	0	3			18	note(s)
1N2		2	2	45	3			0	
1N3	eye	4	2	0	3			18	note(s)
1N5		2	2	31	2			340	
1N6	di	2	2	37	3			6	
1N6	pen	2	2	33	2			345	
1P5		2	2	32	2			340	
1Q5		2	2	29	2			345	
1Q6	di	4	2	27	3			6	
1Q6	pen	4	2	35	2			278	
1R5	tot	7	2	32	2		15	2346	
1R5	tri	7	2	32	2			34	
1RK23		258	2	20	4		1469	0	
1RK41		258	2	21	4		1469	0	
1S2		258	2	20	4		1469	0	
1S4		7	2	29	2		1256	2+634	
1S5	di	1	2	29	3			3	
1S5	pen	1	2	34	2			456	
1SA6		2	2	31	2			3468	
1SB6	di	2	2	32	3			5	
1SB6	pen	2	2	37	2			348	
1T4		7	2	31	2		15	236	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
1T5		2	2	31	2			345	
1T6	di	4	2	28	3			6	
1T6	pen	4	2	33	2			138	
1U4		7	2	31	2		15	236	
1U5	di	1	2	29	3			4	
1U5	pen	1	2	34	2			236	
1U6	tot	1	2	35	2			23456	
1U6	tri	1	2	40	2			34	
1V		1	9	8	1	3		2	
1V2		4	1	40	4			9	note(s)
1V5		4	3	33	2			278	
1V6	pen	4	2	30	2			123	
1V6	tri	4	2	35	2			56	
1W4		1	2	33	2			236	
1W5		4	2	32	2			278	
1X2		258	2	24	2		1245689	0	
1Z2		257	2	32	4		1234567	0	
20		1	5	35	2			23	
2050		2	9	3	1	8		356	
2051		2	9	4	1	8		356	
20AQ3		4	16	23	2	0	1236789	9+	note(s)
20D4	hep	5	9	24	2	3		1267	
20D4	tri	5	9	27	2			89	
20EQ7	di	4	16	29	3	3		8	
20EQ7	pen	4	16	23	2			1267	
20EW7	tri-1	4	16	27	2	8		67	
20EW7	tri-2	4	16	23	2	9	23	12+3	
20EZ7	tri-1	3	12	26	2	9		78	
20EZ7	tri-2	12	26	2	4		56		
20LF6		3	16	21	2	6	1278	2+790	note(s)
21A6		4	17	21	2	3	12789	280	note(s)
21AK6		3	17	10	1	7		1256	
21EX6		2	17	22	2	3		580	
21GY5		3	17	22	2	18	1278	2790	note(s)
21HB3		2	22	18	2			2790	
21HB5		1	17	22	2	4		237	note(s)
21HD5		1	17	20	2	4	59	357	note(s)
21HJ5		1	17	20	2	4	59	35+7+9	note(s)
21JV6		6	17	21	2	7	29	2+3+8+90	note(s)
21JZ6		2	17	20	2	5		780	note(s)
21KA4		3	17	20	2	1	28	790	note(s)
21KQ6		4	17	20	2	9	123678	1+30	note(s)
21LG6		3	17	22	2	18	1278	790	note(s)
21LR8	pen	4	17	20	2	3		267	
21LR8	tri	4	17	21	2	1		89	
21LU8	pen	9	17	21	2	4	12	1+230	note(s)
21LU8	tri	6	17	21	2	3		27	
21MY8	pen	9	17	21	2	4	12	1+230	note(s)
21MY8	tri	6	17	21	2	3		27	
21SJ6		4	17	20	2	5	16	1+680	note(s)
22		1	5	42	2			230	
22AL3		4	17	24	3	0		9	note(s)
22BH3		4	17	24	2	9	27	2+7	
22BW3		1	17	17	3	7		4	note(s)
22DE4		7	17	4	1	3		5	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
22JF6		4	17	20	2	3	1267	1+2+6+70	
22JG6		4	17	17	3	3	17	279	note(s)
22JR6		4	17	28	3	3	17	279	note(s)
22JU6		4	17	20	2	3	1267	1+2+6+70	
22KM6		4	17	21	2	3	1267	670	note(s)
22KV6		4	17	20	2	3	17	279	note(s)
22SJ6		4	17	20	2	5	16	1+680	note(s)
23MB6		5	17	19	3	7	2389	123890	note(s)
23Z9	pen	6	17	21	2	1		230	note(s)
23Z9	tri-1	4	17	27	2	0		78	
23Z9	tri-2	4	17	24	2			23	
24		1	4	12	1	4		230	
24AX4		7	18	7	1	3		5	
24BF11	pen-1	1	18	28	2	2		3567	note(s)
24BF11	pen-2	7	18	23	2	4		356	
24GA7	di	3	18	24	2	0		2	note(s)
24GA7	pen	1	18	35	2	5	10	237	
24JE6		4	18	23	2	3	1267	1+2+6780	
24JZ8	pen	9	18	23	2	4	12	1+230	note(s)
24JZ8	tri	6	18	26	2	3		27	
24LQ6		4	18	23	2	3	1267	1+2+6780	
24LZ6		4	18	23	2	3	1267	1+2+679	
25A6		2	18	7	1	8		345	
25A7	pen	2	18	10	1	8		345	
25A7	rec	2	18	5	1	1		6	
25AC5		2	18	10	1	8		35	
25AV5		2	18	5	1	3		158	
25AX4		7	18	7	1	3		5	
25B5		1	18	13	1	5		234	
25B6		2	18	5	1	8		345	
25B8	pen	2	18	4	1	1		340	
25B8	tri	2	18	7	1	6		58	
25BB14		4	18	20	2	38	123678	1+2+6+70	
25BK5		4	18	24	2	6	37	3+718	
25BQ6		2	18	5	1	8		450	
25C5		3	18	3	1	1	25	2+567	
25C6		2	18	5	1	8		345	
25CA5		3	18	5	1	1	25	2+567	
25CD6		2	18	4	1	3		580	
25CG3		1	18	16	3	7		4	note(s)
25CK3		4	18	20	2	9	27	2+7	
25CM3		4	18	23	2	9	27	2+7	
25CT3		4	18	23	2	9	26	2+6	
25CU6		2	18	4	1	8		450	
25D8	di	2	18	26	3			8	
25D8	pen	2	18	8	1			340	
25D8	tri	2	18	15	1	1		56	
25DK3		4	18	23	2	0	27	2+7	
25DK4		3	18	23	2	7	46	5	
25DL3		4	18	21	2	0	27	27	
25DN6		2	18	23	2	3		580	
25DQ6		2	18	4	1	8		450	
25DT5		4	18	28	2	7	36	13+69	
25E5		2	17	2	4	38	1348	1+450	
25EC6		2	18	3	1	3		580	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
25EH5		3	18	24	2	1	25	2+567	
25F5		3	18	5	1	1	25	2+567	
25FY8	pen	4	18	22	2	2		367	
25FY8	tri	4	18	24	2	8		19	
25GB6		2	18	18	3	8		450	
25HX5		4	18	18	3	23	1237	1679	note(s)
25JQ6	di	4	18	21	3			6	
25JQ6	pen	4	18	22	2	9	2378	12378	
25JZ8	pen	9	18	23	2	4	12	1+230	note(s)
25JZ8	tri	6	18	26	2	3		27	
25L6		2	18	5	1	8		345	
25MP20		3	18	25	2	2		156	
25N6		2	18	13	1	8		345	
25RK19		4	18	23	2	0	29	2+9	
25W4		7	18	4	1	3		5	
25W6		2	18	4	1	8		345	
25X6	pl-1	2	18	5	1	4		3	
25X6	pl-2	2	18	5	1	8		5	
25Y4		2	18	5	1	8		5	
25Y5	pl-1	1	18	10	1	4		5	
25Y5	pl-2	1	18	10	1	3		2	
25Z3		1	18	5	1	3		2	
25Z4		2	18	5	1	8		5	
25Z5	pl-1	1	18	6	1	4		5	
25Z5	pl-2	1	18	6	1	3		2	
25Z6	pl-1	2	18	5	1	8		5	
25Z6	pl-2	2	18	5	1	4		3	
26		1	2	17	1			23	
262B		1	12	16	1	3		20	
264C		1	2	24	1			23	
26A6		3	18	5	1	7		1256	
26A7	pen-1	6	18	4	1	2		158	
26A7	pen-2	6	18	4	1			345	
26AQ8	tri-1	4	18	22	2	8		67	
26AQ8	tri-2	4	18	22	2	3		12	
26BK6	di-1	3	18	23	3			6	
26BK6	di-2	3	18	23	3			5	
26BK6	tri	3	18	7	1	2		17	
26C6	di-1	3	18	27	3			6	
26C6	di-2	3	18	27	3			5	
26C6	tri	3	18	11	1	2		17	
26D6	tot	3	18	6	1	2		1567	
26D6	tri	3	18	6	1			16	
26DQ5		2	18	23	2	36	134568	14580	
26E6		2	18	6	1	8		345	
26HU5		7	18	21	2	26	1256	130	
26HV5		1	18	20	2	4		27	note(s)
26JG6		4	18	17	3	3	17	279	note(s)
26LW6		7	18	21	2	26	1256	1+350	
26LX6		4	18	23	2	5	16	1+680	note(s)
26Z5	pl-1	9	13	9	1	8	45	6	
26Z5	pl-2	9	13	9	1	3		1	
27		1	4	14	1	4		23	
271A		1	8	9	1	4		23	
272A		1	12	15	1	4		23	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
274A	pl-1	1	8	15	1			2	
274A	pl-2	1	8	15	1			3	
27GB5		4	18	22	2	38	123678	160	note(s)
27KG6		4	18	20	2	9	123678	680	note(s)
27LF6		3	18	21	2	6	1278	2+790	note(s)
28D7	sec-1	1	18	4	1	6		357	
28D7	sec-2	1	18	4	1			234	
28GB5		4	18	22	2	38	123678	160	note(s)
28HA6		4	19	22	2	1	3689	26+87	
28HD5		1	19	20	2	4	59	357	note(s)
28Z5	pl-1	4	13	15	1	7	18	6	
28Z5	pl-2	4	13	15	1			3	
29GK6		4	19	23	2	1	39	278	
29KQ6		4	19	20	2	9	123678	1+30	note(s)
29LE6		4	18	19	3	9	123678	1230	note(s)
2A3		1	4	7	1			23	
2A4		2	4	9	1			35	
2A5		1	4	11	1	5		234	
2A6	di-1	1	4	27	3			3	
2A6	di-2	1	4	27	3			4	
2A6	tri	1	4	10	1	5		20	
2A7	tot	1	4	8	1	6		23450	
2A7	tri	1	4	11	1			45	
2AF4		3	4	23	2	5	1267	1+72+6	
2AH2		1	4	26	4			0	note(s)
2AS2		4	4	27	4		17	0	note(s)
2AV2		4	3	29	4		1236789	9	note(s)
2AZ2		5	3	20	4		1469	0	note(s)
2B5	tri-1	27	2	14	1		45	68	
2B5	tri-2	27	2	14	1			13	
2B7S	di-1	1	4	27	3			4	
2B7S	di-2	1	4	27	3			5	
2B7S	pen	1	4	19	1	6		230	
2BA2		4	3	15	4		19	1+9	
2BJ2		5	3	44	3	1469	1469	0	note(s)
2BN4		3	3	23	2	16	1267	2+75	
2BU2		4	4	17	4	1467	1467	0	note(s)
2C50	tri-1	7	13	24	2	3		12	
2C50	tri-2	7	13	24	2	6		45	
2C51	tri-1	1	9	24	2	2		34	
2C51	tri-2	1	9	24	2	8		67	
2C52	tri-1	7	13	8	1	3		12	
2C52	tri-2	7	13	8	1	6		45	
2C53		2	9	17	1	8		50	
2CN3		2	2	17	4		35	0	
2CW4		4	3	17	3	3		12	
2CY5		3	4	23	2	27	27	156	
2D21	thy	3	9	3	1	2	57	1,5+7,6	
2DL4		4	3	21	2	2	13679	18	note(s)
2DS4		4	3	18	3	3		12	
2DV4		3	3	19	2	7	1246	1+24+6	
2DZ4		3	4	24	2	5		1267	note(s)
2E24		27	4	7	1		146	350	
2E25		2	8	12	1			4580	
2E26		2	9	5	1	146	146	350	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
2E30		7	5	9	1		34	156	
2E31		3	2	29	2			124	
2E32		3	2	29	2			124	
2E35		3	2	32	2			124	
2E36		3	2	32	2			124	
2E41	di	4	2	45	3			3	
2E41	pen	4	2	33	2			125	
2E42	di	4	2	45	3			3	
2E42	pen	4	2	33	2			125	
2E5	eye	1	4	0	4			24	note(s)
2E5	tri	1	4	24	1	5		23	
2EA5		3	4	23	2	27	27	156	
2EG4		4	2	42	3	3		1	
2EN5	di-1	3	3	17	3	5		7	
2EN5	di-2	3	3	17	3			2	
2ER5		3	4	22	2	17	17	256	
2ES5		3	3	22	2	17	17	256	
2EV5		3	3	18	3	27	27	156	
2F7	pen	1	4	15	1			230	
2F7	tri	1	4	30	1	6		45	
2FH5		3	4	23	2	17	17	25	
2FQ5		3	4	22	2	17	17	25	
2FS5		3	4	22	2	27	27	156	
2FV6		3	4	23	2	7		156	
2FY5		3	4	22	2	17	17	25	
2G21	tot	4	2	30	2			12356	
2G21	tri	4	2	32	2			13	
2G22	tot	4	2	30	2			12356	
2G22	tri	4	2	32	2			13	
2G5	eye	1	4	0	4			24	note(s)
2G5	tri	1	4	21	1	5		23	
2GK5		3	4	22	2	17	17	25	
2GU5		3	4	21	2	27	27	156	
2GW5		3	4	20	2	5	26	12+6	
2HA5		3	3	21	2	27	27	15	note(s)
2HK5		3	3	21	2	27	27	15	
2HM5		3	4	22	2	27	27	15	note(s)
2HQ5		3	3	20	2	27	27	15	
2HR8		4	4	23	2	3	27	169	
2T4		3	4	22	2	5	1267	1+72+6	
2W3		2	4	18	1			4	
2X2	rec	1	4	17	4			0	
2X3		2	4	16	1			4	
2Y3		2	4	15	1			4	
2Z2		1	4	23	1			2	
30		1	3	34	2			23	
300B		1	8	7	1			23	
307A		1	8	8	1			2340	
30A5		3	19	21	2	1	25	2+567	
30AE3		4	19	23	2	0	1236789	3+8+9	
30AG11	di-1	9	19	24	2	6		5	note(s)
30AG11	di-2	3	19	24	2	4		5	
30AG11	tri-1	9	19	22	2	4		23	
30AG11	tri-2	3	19	22	2	6		78	
30BM6		6	19	19	3	7	2389	123890	note(s)

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
30C18	pen	4	10	19	2			237	note(s)
30C18	tri	4	10	21	2	68	68	19	
30CW5		4	19	21	2	3		1+26+7+89	note(s)
30HD5		1	19	20	2	4	59	357	note(s)
30HJ5		1	19	20	2	4	59	35+7+9	
30JZ6		2	19	20	2	5		780	note(s)
30KD6		3	19	20	2	6	1278	2+790	
30KG6		4	19	20	2	9	123678	680	note(s)
30LW6		7	19	21	2	26	1256	1+350	
30MP23		3	19	18	3	1	25	2567	
30MP27		3	19	18	3	1	25	2567	
30PL12	pen	4	15	21	2	2		367	
30PL12	tri	4	15	24	2	8		19	
31		1	3	19	1			23	
310A		1	12	10	1	5		2340	
313C			10	13	4	1		2	
31A3		1	19	3	4	7		2	note(s)
31AL10	pen	5	14	22	2	7	19	458	note(s)
31AL10	tri-1	0	14	24	2	3	57	24	
31AL10	tri-2	6	14	25	2	7		23	
31LQ6		4	19	23	2	3	1267	1+2+6780	
31LR8	pen	4	18	20	2	3		267	
31LR8	tri	4	18	21	2	1		89	
31LZ6		4	19	23	2	3	1267	1+2+679	
31SJ6		4	19	20	2	5	16	1+680	note(s)
32		1	3	21	1			230	
328A		1	10	10	1	5		2340	
329A		1	10	9	1	4		230	
32A8	pen	4	19	23	2	2		367	
32A8	tri	4	19	23	2	8		19	
32ET5		3	19	25	2	1	25	2+567	
32GA7	di	3	19	24	2	0		2	note(s)
32GA7	pen	1	19	35	2	5	10	237	
32HQ7	di	1	19	16	3	4		2	note(s)
32HQ7	pen	7	19	16	2	3		46	
32L7	amp	2	19	5	1	8		345	
32L7	rec	2	19	5	1	1		6	
33		1	3	15	1			234	
331B		1	12	26	2	4		230	
336A		1	12	9	1	5		234	
33GT7	di	3	19	18	3	8		6	note(s)
33GT7	pen	3	19	24	2	0		129	
33GY7	di	2	19	18	3	7		5	
33GY7	pen	3	19	23	2	0		12	
33HE7	di	1	19	16	3	4		2	note(s)
33HE7	pen	7	19	16	2	3		46	
33JR6		4	19	28	3	3	17	279	note(s)
33JV6		6	19	21	2	7	29	2+3+8+90	note(s)
34		1	3	21	-		230		
345A	pl-1	1	9	5	1	4		2	
345A	pl-2	1	9	5	1			3	
347A		2	9	16	1	8		40	
348A		2	9	9	1	8		3450	
349A		2	9	7	1	8		345	
34CD3		1	19	20	2	7		4	note(s)

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
34CE3		1	19	20	2	7		4	note(s)
34CM3		4	19	23	2	9	27	2+7	
34DK3		4	19	23	2	0	27	2+7+	
34GD5		3	19	24	2	1	25	2+567	
34R3		4	19	22	2	0	29	2+9	
35		1	4	12	1	4		230	
350A		1	9	4	4	4		230	
350B		2	9	4	4	8		345	
351A	pl-1	2	9	6	1	8		3	
351A	pl-2	2	9	6	1			5	
352A	di-1	1	12	23	3			3	
352A	di-2	1	12	23	3			4	
352A	tri	1	12	15	1	5		20	
35A5		1	19	5	1	7		236	
35B5		3	19	6	1	2	17	1+756	
35C3		3	19	3	1	7		5	
35C5		3	19	5	1	1	25	2+567	
35CD6		2	19	4	1	3		580	
35DZ8	pen	4	19	23	2	2		367	
35DZ8	tri	4	19	28	2	8		19	
35EH5		3	19	24	2	1	25	2+567	
35GL6		3	19	25	2	1	46	257	
35HB8	pen	4	19	24	2	8		679	
35HB8	tri	4	19	23	2	2		13	
35L6		2	19	6	1	8		345	
35LR6		4	19	22	2	5	16	1+680	note(s)
35W4		3	19	4	1	7	46	5	note(s)
35Y4		8	19	4	1	7	14	2	
35Z3		1	19	4	1	7		2	
35Z4		2	19	4	1	8		5	
35Z5		7	19	4	1	8	23	5	
35Z6	pl-1	2	19	4	1	4		3	
35Z6	pl-2	2	19	4	1	8		5	
36		1	9	13	1	4		230	
36AM3		3	19	5	1	7	46	5	note(s)
36KD6		3	19	22	2	6	1278	2+790	note(s)
36MC6		4	19	20	2	3	1267	120	note(s)
37		1	9	17	1	4		23	
38		1	9	17	1	4		230	
38A3		4	19	24	2	3	169	1+6+9	
38HE7	di	1	19	16	3	4		2	note(s)
38HE7	pen	7	19	16	2	3		46	
38HK7	di	1	19	16	3	4		2	note(s)
38HK7	pen	7	19	26	2	3		46	
39		1	9	14	1	4		230	
396A	tri-1	1	9	24	2	2		34	
396A	tri-2	1	9	24	2	8		67	
398A		2	9	7	1			3468	
3A2		258	5	20	4			0	note(s)
3A3		2	5	31	4			0	
3A4		5	2	30	2		1267	2+634	
3A5	tri-1	4	2	28	2		17	23	
3A5	tri-2	4	2	28	2			56	
3A8	di	1	2	27	3		27	8	
3A8	pen	1	2	32	2			340	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
3A8	tri	1	2	36	2			56	
3AF3		4	8	18	3	0	29	2+9	
3AF4		3	5	23	2	5	1267	1+72+6	
3AJ3	tri	5	5	24	2			89	
3AJ8	hep	5	5	24	2	3		1267	
3AL5	di-1	3	5	17	3	1		7	
3AL5	di-2	3	5	17	3	5		2	
3AT2		5	4	21	4		28	0	note(s)
3AU6		3	5	5	1	7		1256	
3AV6	di-1	3	5	27	3			5	
3AV6	di-2	3	5	27	3			6	
3AV6	tri	3	5	27	2	2		17	
3AW2		4	5	15	4		17	0	note(s)
3AW3		2	5	48	3		378	0	
3B2		2	5	33	4			0	note(s)
3B4		26	2	10	1		45	137	
3B5		8	2	29	2		27	345	
3B7	tri-1	4	2	29	2		18	67	
3B7	tri-2	4	2	29	2			23	
3BA6		3	5	5	1	7		1256	
3BC5		3	5	23	2	27	27	156	
3BE6	tot	3	5	24	2	2		1567	
3BE6	tri	3	5	25	2			16	
3BH2		248	4	20	4		12589	0	
3BL2		4	5	16	4		167	0	note(s)
3BL2		4	5	16	4		167	0	
3BM2		4	5	12	4		167	0	note(s)
3BN2		5	4	21	4		28	0	note(s)
3BN4		3	4	23	2	16	1267	2+75	
3BN6		3	5	41	3	1		2567	
3BS2		4	5	15	4		17	0	note(s)
3BT2		4	5	17	4	1467	1467	0	note(s)
3BU8	sec-1	4	5	24	2	1		2789	
3BU8	sec-2	4	5	24	2			2367	
3BW2		4	5	17	4	1467	1467	0	note(s)
3BX6		4	5	22	2	13	13	278	
3BY6	sec-1	3	5	5	1	2		16	
3BY6	sec-2	3	5	5	1			1567	
3BY7		4	5	22	4	13	13	278	
3BZ6		3	5	23	2	2		1567	
3C4		5	2	28	2		17	236	
3C5		8	2	30	2		27	345	
3C6	tri-1	7	2	33	2		18	56	
3C6	tri-2	7	2	33	2			34	
3CA3		2	5	26	4			0	
3CB6		3	5	23	2	2		1567	
3CE5		3	5	23	2	27	27	156	
3CF6		3	5	23	2	2		1567	
3CN3		2	5	17	4		35	0	
3CS6	tot	3	5	24	2			1567	
3CS6	tri	3	5	24	2	2		16	
3CU3		2	5	14	4		8	0	
3CV3A		2	5	23	4		1357	0	
3CX3		35	5	17	4		34568	0	
3CY3		2	5	20	4	12357	12357	0	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
3CY5		3	4	23	2	27	27	156	
3CZ3		2	5	48	3		78	0	
3D6		7	2	28	2		18	236	
3DA3		35	5	17	4		34568	0	
3DB3		2	5	27	4	17	12357	0	
3DC3		2	5	13	4		12357	0	
3DF3		35	5	20	4		23468	0	
3DG4	pl-1	1	5	25	2			7	
3DG4	pl-2	1	5	25	2			5	
3DH3		3	5	21	4		34568	0	note(s)
3DJ3		2	5	27	4		12357	0	
3DK6		3	5	23	2	2		1567	
3DR3		35	5	18	4		23568	0	
3DS3		35	5	18	4		268	0	note(s)
3DT6		3	5	24	2	2		1567	
3DZ11		5	7	21	3	7	71	15	
3DZ4		3	5	24	2	5		1267	note(s)
3E6		5	2	28	2		18	2346	
3EA5		3	4	23	2	27	27	156	
3EH7		4	5	22	2	13	13	2789	
3EJ7		4	5	21	2	13	13	2789	
3ER5		3	4	22	2	17	17	256	
3ES3		3	5	22	2	17	17	256	
3EV5		3	4	18	3	27	27	156	
3FH5		3	5	23	2	17	17	25	
3FQ5		3	4	22	2	17	17	25	
3FS5		3	4	22	2	27	27	156	
3FY5		3	5	22	2	17	17	25	
3GK5		3	4	22	2	17	17	25	
3GK6		4	5	23	2	1	39	23+79	
3GS8	sec-1	4	5	24	2	1		2789	
3GS8	sec-2	4	5	24	2			2367	
3GU5		3	5	21	2	27	27	156	
3GW5		3	5	20	2	5	26	12+6	
3HA5		3	4	21	2	27	27	15	note(s)
3HE7	di	1	5	16	3	4		2	note(s)
3HE7	pen	7	5	16	2	3		46	
3HF5		3	5	23	2	18	1278	2790	note(s)
3HK5		3	4	21	2	27	27	15	
3HM5		3	4	22	2	27	27	15	note(s)
3HM6		4	5	20	2	13	13	278	
3HQ5		3	5	20	2	27	27	15	
3HS8	pen-1	4	5	23	2	1		2789	
3HS8	pen-2	4	5	23	2			2367	
3HT6		4	5	22	2	13		278	note(s)
3JC6		4	5	22	2	13	13	278	
3JD6		4	5	22	2	13	13	278	
3KF8	pen-1	4	5	21	2	1		278	
3KF8	pen-2	4	5	21	2			237	
3KT6		4	5	21	2	13	13	278	
3LF4		7	2	28	2		18	236	
3MP26		3	4	22	2	2		156	
3MR24		3	5	21	2	2		1567	
3MV7		3	5	21	2	2		1567	
3Q4		5	2	29	2		1267	2+634	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
3Q5		8	2	28	2		27	345	
3S4	pen	1&7(5)	2	29	2		1267	3,4,(5),2+6	
3V4		5	2	28	2		17	236	note(s)
40		1	8	15	1			23	
401A		3	9	27	2	27	27	156	
403B		3	9	25	2	27	27	156	
407A	tri-1	5	16	24	2	2	19	34	
407A	tri-2	5	16	24	2	8		67	
408A		3	16	25	2	27	27	156	
40FR5		3	19	24	2	1	25	2+567	
40KD6		3	19	20	2	6	1278	2+790	note(s)
40KG6		4	19	20	2	9	123678	680	note(s)
41		1	9	8	1	5		234	
412A	pl-1	4	9	5	1	7		9	
412A	pl-2	4	9	5	1	3		1	
417A		3	9	23	2	6	4578	14+5+7+8	
42		1	9	9	1	5		234	
42CE4		4	19	22	2	0	278	2+7+8	
42KN6		5	19	20	2	8	49	24+90	note(s)
43		1	18	7	1	5		234	
45		1	4	13	1			23	
45A5		1	20	23	2	37	37	256	
45B5		4	19	23	2	3	12689	1+26+8+97	
45Z3		1	20	6	1	4	26	2+6	
45Z5		7	20	3	1	8	23	5	
46		1	4	11	1			234	
4636	pen	2(3)	6	<27	2	5		4,1,,0	
4652	pl-1	2	6	7	1			1	
4652	pl-2	2	6	7	1			4	
4699	pen	2	9	<4	1	4		6,7,(k),8	
47		1	4	12	1			234	
48		1	19	6	1	5		234	
49		1	3	32	2			234	
4A6	tri-1	8	3	17	1		27	34	
4A6	tri-2	8	3	17	1			56	
4AB8	pen	4	6	22	2			689	
4AB8	tri	4	6	25	2	3		12	
4AF4		3	6	23	2	5	1267	1+72+6	
4AU6		3	6	5	1	7		1256	
4AV6	di-1	3	6	27	3			5	
4AV6	di-2	3	6	27	3			6	
4AV6	tri-1	3	6	27	2	2		17	
4BA6		3	6	5	1	7		1256	
4BC5		3	6	23	2	27	27	156	
4BC8	tri-1	4	6	23	2	8		67	
4BC8	tri-2	4	6	23	2	3		12	
4BE6	tot	3	6	24	2	2		1567	
4BE6	tri	3	6	25	2			16	
4BL8	pen	4	7	22	2	7		236	
4BL8	tri	4	7	23	2	8		19	
4BN4		3	6	23	2	16	1267	2+75	
4BN6		3	6	48	3	1		2567	
4BQ7	tri-1	4	6	23	2	8		67	
4BQ7	tri-2	4	6	23	2	3		12	
4BS8	tri-1	4	6	24	2	8		67	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
4BS8	tri-2	4	6	24	2	3		12	
4BU8	sec-2	4	6	24	2			2367	
4BU8	sec-2	4	6	24	2	1		2789	
4BX8	tri-1	4	6	24	2	8		67	
4BX8	tri-2	4	6	24	2	3		12	
4BZ6		3	6	23	2	2		1567	
4BZ7	tri-1	4	6	23	2	8		67	
4BZ7	tri-2	4	6	23	2	3		12	
4BZ8	tri-1	4	6	22	2	8		12	
4BZ8	tri-2	4	6	22	2	3		67	
4CB6		3	6	23	2	2		1567	
4CE5		3	6	23	2	27	27	156	
4CM4		4	5	22	2	37	1236789	1+2+6+8+9	
4CS6	tot	3	6	24	2			1567	
4CS6	tri	3	6	24	2	2		16	
4CY5		3	7	23	2	27	27	156	
4DE6		3	6	22	2	2		156	
4DK6		3	6	23	2	2		1567	
4DL4		4	6	20	2	2	13679	1+3+6+7+98	
4DT6		3	6	24	2	2		1567	
4EH7		4	6	22	2	13	13	2789	
4EJ7		4	6	21	2	13	13	2789	
4ER5		3	5	20	2	17	17	25	
4ES8	tri-1	4	6	22	2	8		67	
4ES8	tri-2	4	6	22	2	3		12	
4EW6		3	6	20	2	2		156	
4GJ7	pen	4	6	20	2		267		
4GJ7	tri	4	6	21	2	13	13	89	
4GK5		3	6	22	2	17	17	25	
4GM6		3	6	21	2	2		1567	
4GS7	pen	4	6	19	2			679	
4GS7	tri	4	6	21	2	38	38	12	
4GS8	sec-1	4	6	24	2	1		2789	
4GS8	sec-2	4	6	24	2			2367	
4GW5		3	6	20	2	5	26	12+6	
4GX6		3	6	23	2	2		1567	
4GX7	pen	4	6	20	2			267	
4GX7	tri	4	6	21	2	13	13	89	
4GZ5		3	6	22	2	1	25	2+567	
4HA5		3	6	21	2	27	27	15	note(s)
4HA7	tri-1	2	7	26	2	6		15	note(s)
4HA7	tri-2	4	7	26	2	9		12	
4HC7	tri-1	1	6	26	2	4		79	note(s)
4HC7	tri-2	7	6	26	2	9		48	
4HG8	pen	4	7	23	2	3	13	67	
4HG8	tri	4	7	23	2	3	13	67	
4HK5		3	6	21	2	27	27	15	
4HM5		3	6	22	2	27	27	15	note(s)
4HM6		4	6	20	2	13	13	278	
4HQ5		3	6	20	2	27	27	15	
4HR8		4	7	23	2	3	27	169	
4HS8	pen-1	4	6	23	2	1		2789	
4HS8	pen-2	4	6	23	2			2367	
4HT6		4	6	22	2	13		278	note(s)
4JC6		4	7	22	2	13	13	278	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
4JD6		4	7	22	2	13	13	278	
4JH6		3	6	22	2	2		156	
4JK6		3	5	21	2	2		156	
4JL6		3	5	22	2	2		156	
4JW8	pen	4	6	21	2	7		236	
4JW8	tri	4	6	22	2	8		19	
4KE8	pen	4	6	23	2	7		236	
4KE8	tri	4	6	24	2	8		19	
4KF8	pen-1	4	6	21	2	1		278	
4KF8	pen-2	4	6	21	2			237	
4KN8	tri-1	4	6	20	2	8		67	
4KN8	tri-2	4	6	20	2	3		12	
4KT6		4	6	21	2	13	13	278	
4LJ8	pen	4	6	20	2			679	
4LJ8	tri	4	6	21	2	38	38	12	
4LU8		4	6	20	2	2		1567	
4MK8	pen-1	4	6	22	2	1		237	
4MK8	pen-2	4	6	22	2			278	
4MP12		3	7	22	2	2		156	
4MP26		3	6	22	2	2		156	
4RHH15	tri-2	4	6	22	2	3		12	
4RHH16	tri-1	4	6	22	2	8		67	
4RHH2	tri-1	4	6	23	2	8		67	
4RHH2	tri-2	4	6	23	2	3		12	
4RHH8	tri-1	4	6	20	2	8		67	
4RHH8	tri-2	4	6	20	2	3		12	
50		1	10	18	1			23	
502A		2	9	4	1	8		356	
50A5		1	20	4	1	7		236	
50B5		3	20	4	1	2	17	1+756	
50BK5		4	20	24	2	6	37	3+718	
50BM8	pen	4	20	19	3	8		19	
50BM8	tri	4	20	19	3	8		19	
50C5		3	20	3	1	1	25	2+567	
50C6		2	20	5	1	8		345	
50CA5		3	20	5	1	1	25	2+567	
50DC4		3	20	18	3	7		5	note(s)
50EH5		3	20	24	2	1	25	2+567	
50FA5		3	20	24	2	1	25	2+567	
50FE5		2	20	23	2	8		345	
50FK5		3	20	23	2	1	25	2+567	
50FY5	pen	4	20	22	2	2		367	
50FY5	tri	4	20	24	2	8		19	
50GY7	di	2	20	18	3	7		5	note(s)
50GY7	pen	3	20	23	2	0		12	
50HB26	pen	4	20	<24	2	23		1+7,6,,9	
50HC6		3	20	22	2	1	46	257	note(s)
50HK6		3	20	23	2	1	46	257	
50HN5		4	20	22	2	3	12	1+279	
50JY6		2	20	20	2	8	14	450	note(s)
50L6		2	20	4	1	8		345	
50X6	pl-1	1	20	5	1	2		3	
50X6	pl-2	1	20	5	1	7		6	
50Y6	pl-1	2	20	5	1	4		3	
50Y6	pl-2	2	20	5	1	8		5	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
50Y7	pl-1	2	20	5	1	4	67	3	
50Y7	pl-2	2	20	5	1	8		5	
50Z7	pl-1	2	20	6	1	4	67	3	
50Z7	pl-2	2	20	6	1	8		5	
52		1	9	8	1			234	
53	tri-1	1	4	11	1	4		23	
53	tri-2	1	4	11	1			56	
53HK7	di	1	20	16	3	4		2	note(s)
53HK7	pen	7	20	16	2	3		46	
55	di-1	1	4	26	3			3	
55	di-2	1	4	26	3			4	
55	tri	1	4	15	1	5		20	
5516		27	4	8	1		146	350	
5590		3	9	27	2	27	27	156	
56		1	4	12	1	4		23	
5603		2	9	7	1			3648	
5610		3	9	25	2	2	15	1+56	
5618		5	4	6	1		17	236	
5636		3	9	25	2	28	28	1457	
5642		2	2	18	4			0	note(s)
5654	pen	3	9	25	2	27	27	1,6,(k),5	
5663		3	9	4	1	2		157	
5670	tri-1	1	9	24	2	8		67	
5670	tri-2	1	9	24	2	2		34	
5672		3	2	32	2			124	
5676		2	2	27	2			13	
5678		3	2	28	2			124	
5679	di-1	4	5	18	3	7	18	6	
5679	di-2	4	5	18	3	2		3	
5686		4	9	8	1	138	13869	26+97	
5687	tri-1	8	9	23	2	6	45	79	
5687	tri-2	8	9	23	2	3		12	
5691	tri-1	7	9	11	1	3		12	
5691	tri-2	7	9	11	1	6		45	
5692	tri-1	7	9	9	1	3		12	
5692	tri-2	7	9	9	1	6		45	
5693		2	9	8	1	5		3468	
5695		1	4	4	4			2	
5696		3	9	29	2	2	57	15+76	
56A		1	9	12	1	4		23	
57		1	4	10	1	5		2340	
5702		3	9	22	2	6		1257	
5703		3	9	5	1	6		15	
5710		3	9	6	1	5		18	
5719		3	9	25	2	5		18	
5725		3	9	4	1	2		1567	
5726	di-1	3	9	17	3	1		7	
5726	di-2	3	9	17	3	5		2	
5727		3	9	3	1	2	57	15+76	
5744		2	9	26	2	5		14	
5749		3	9	5	1	7		1256	
5750	tot	3	9	24	2	2		1567	
5750	tri	3	9	25	2			16	
5751	tri-1	9	9	27	2	8	45	67	
5751	tri-2	9	9	27	2	3		12	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
5755	tri-1	9	9	19	3	7		68	
5755	tri-2	9	9	19	3	2		13	
5763		4	9	4	1	7	89	1368+9	
5784		3	9	24	2	6		1257	
57A		1	9	10	1	5		2340	
58		1	4	10	1	5		2340	
5812		7	5	6	1	2	34	156	
5814	tri-1	9	9	8	1	3	45	12	
5814	tri-2	9	9	8	1	8		67	
5823			24	11	4	37	37	1	
5824		2	18	5	1	8		345	
5840		3	9	24	2	248	248	156	
5842		3	9	23	2	6	4567	14+5+7+8	
5844	tri-1	3	9	22	2	7		25	
5844	tri-2	3	9	22	2			16	
5845	di-1	3	6	50	3			5	note(s)
5845	di-2	3	6	50	3		34	1	
5847		3	9	22	2	4		168	
5879		4(5)	9	11	1	3		1,7,(9),8	
5881		2	9	5	1	8		345	
5896	di-1	3	9	6	1	7		5	
5896	di-2	3	9	6	1	2		1	
5899		3	9	25	2	248	248	157	
58A		1	9	10	1	5		2340	
58HE7	di	1	20	16	3	4		2	note(s)
58HE7	pen	7	20	16	2	3		46	
59		1	4	7	1	6		2345	
5902A		3	9	25	2	248	248	157	
5915	tot	3	9	5	1	2		1567	
5915	tri	3	9	5	1			16	
5931	pl-1	2	8	12	1			4	
5931	pl-2	2	8	12	1			6	
5932		2	9	7	1	8		345	
5933		1	9	18	3	4	5	230	
5963	tri-1	9	9	8	1	3	45	12	
5963	tri-2	9	9	8	1	8		67	
5964	tri-1	3	9	23	2	7		25	
5964	tri-2	3	9	23	2			16	
5965	tri-1	9	9	22	2	8	45	67	
5965	tri-2	9	9	22	2	3		12	
5A6		9	4	8	1		4538	13+867	
5AF11	di-1	1	7	19	3	9		56	note(s)
5AF11	di-2	1	7	19	3	5		68	
5AF11	pen	6	7	19	3	3		459	
5AF4		3	7	23	2	5	1267	1+72+6	
5AM8	di	4	7	17	3	7		8	
5AM8	pen	4	7	23	2	1		2369	
5AN8	pen	4	7	26	2	9		678	
5AN8	tri	4	7	27	2	3		12	
5AQ4	pl-1	2	8	6	1			4	
5AQ4	pl-2	2	8	6	1			6	
5AQ5		3	7	7	1	2	17	1+756	
5AR4	pl-1	2	8	3	1			4	
5AR4	pl-2	2	8	3	1			6	
5AS4	pl-1	2	7	12	1			4	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
5AS4	pl-2	2	7	12	1			6	
5AS8	di	4	7	17	3	8		6	
5AS8	pen	4	7	23	2	3		129	
5AT8	pen	4	7	23	2			6789	
5AT8	tri	4	7	24	2	3		12	
5AU4	pl-1	2	8	9	1			4	
5AU4	pl-2	2	8	9	1			6	
5AV8	pen	4	7	26	2	7		689	
5AV8	tri	4	7	26	2	1		23	
5AW4	pl-1	2	8	11	1			4	
5AW4	pl-2	2	8	9	1			6	
5AX4	pl-1	2	8	18	1			4	
5AX4	pl-2	2	8	18	1			6	
5AZ4	pl-1	2	8	19	1			4	
5AZ4	pl-2	2	8	19	1			6	
5B8	pen	4	7	23	2			689	note(s)
5B8	tri	4	7	24	2	17		23	
5BC3	di-1	1	8	12	1			89	note(s)
5BC3	di-2	1	8	10	1			56	
5BC8	tri-1	4	8	23	2	8		67	
5BC8	tri-2	4	8	23	2	3		12	
5BE8	pen	4	7	23	2	8		679	
5BE8	tri	4	7	22	2	3		12	
5BK7	tri-1	4	7	22	2	8		67	
5BK7	tri-2	4	7	22	2	3		12	
5BQ7	tri-1	4	9	24	2	8		67	
5BQ7	tri-2	4	9	24	2	3		12	
5BR8	pen	4	7	23	2	8		679	
5BR8	tri	4	7	23	2	3		12	
5BS8	tri-1	4	9	24	2	8		67	
5BS8	tri-2	4	9	24	2	3		12	
5BT8	di-1	4	7	20	3	3		2	
5BT8	di-2	4	7	20	3			1	
5BT8	pen	4	7	23	2	9		678	
5BW8	di-1	4	7	18	3	2		3	note(s)
5BW8	di-2	4	7	18	3			1	
5BW8	pen	4	7	23	2	7		689	
5BZ7	tri-1	4	9	23	2	8		67	
5BZ7	tri-2	4	9	23	2	3		12	
5CG8	pen	4	7	23	2			679	
5CG8	tri	4	7	24	2	38	38	12	
5CL8	tet	4	7	23	2	8		679	
5CL8	tri	4	7	23	2	3		12	
5CM6		4	7	25	2	7	36	13+69	
5CM8	pen	4	7	23	2	3		267	
5CM8	tri	4	7	26	2	8		19	
5CQ8	tet	4	7	24	2	7		236	
5CQ8	tri	4	7	24	2	8		19	
5CR8	pen	4	7	21	2	3		267	
5CR8	tri	4	7	22	2	8		19	
5CX8	pen	4	8	24	2	6		789	
5CX8	tri	4	8	25	2	1		23	
5CZ5		4	7	9	1	7	36	13+69	
5DG4	pl-1	1	8	25	2			7	
5DG4	pl-2	1	8	25	2			5	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
5DH8	pen	4	8	4	1	8		679	
5DH8	tri	4	8	5	1	3		12	
5DJ4	pl-1	12	8	9	2		3456	34	
5DJ4	pl-2	12	8	9	2			56	
5EA8	pen	4	7	22	2	7		236	
5EA8	tri	4	7	23	2	8		19	
5EH8	pen	4	7	2	1	16	16	789	
5EH8	tri	4	7	0	1			23	
5ES3	tri-2	4	8	22	2	3		12	
5ES8	tri-1	4	8	22	2	8		67	
5EU8	pen	4	7	22	2	8		179	
5EU8	tri	4	7	22	2	6		23	
5EW6		3	8	20	2	2		156	
5FG7	tri	4	8	22	2	38	38	12	
5FG8	pen	4	8	22	2			679	
5FV8	pen	4	7	22	2	8		679	
5FV8	tri	4	7	22	2	3		12	
5GH8	pen	4	7	22	2	7		236	
5GH8	tri	4	7	22	2	8		19	
5GJ7	pen	4	9	20	2			267	
5GJ7	tri	4	9	21	2	13	13	89	
5GM6		3	8	21	2	2		1567	
5GS7	pen	4	8	21	2	38	38	12	
5GS7	tri	4	8	21	2	38	38	12	
5GX6		3	7	23	2	2		1567	
5GX7	pen	4	8	20	2			267	
5GX7	tri	4	8	21	2	13	13	89	
5HA7	?-1	2	6	26	2	6		15	
5HA7	?-2	4	6	26	2	9		12	
5HB7	pen	4	7	24	2	13	13	267	note(s)
5HB7	tri	4	7	23	2	13	13	89	
5HC7	tri-1	1	8	26	2	4		79	note(s)
5HC7	tri-2	7	8	26	2	9		48	
5HG8	pen	4	8	22	2	1	13	289	
5HG8	tri	4	8	23	2	3	13	67	
5HZ6		4	8	17	3	2		156	
5J6	tri-1	3	7	24	2	7		25	
5J6	tri-2	3	7	24	2			16	
5JK6		3	8	21	2	2		156	
5JL6		3	8	22	2	2		156	
5JW8	pen	4	7	21	2	7		236	
5JW8	tri	4	7	22	2	8		19	
5KD6	pen	4	8	22	2	7		236	
5KD6	tri	4	8	22	2	8		19	
5KE8	pen	4	8	23	2	7		236	
5KE8	tri	4	8	24	2	8		19	
5KZ8	pen	4	7	22	2	3		267	
5KZ8	tri	4	7	22	2	8		19	
5LJ8	pen	4	8	20	2			679	
5LJ8	tri	4	8	21	2	38	38	12	
5MB8	pen	4	8	19	2	8		679	
5MB8	tri	4	8	20	2	3		12	
5MF8	pen	9	8	22	2	4	12	1+230	note(s)
5MF8	tri	6	8	21	2	3		27	
5MHH3	tri	3	7	23	2	7		16	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
5MHH3	tri	3	7	23	2	7		25	
5MK9		3	7	11	1		4	5	
5MQ8	pen	4	8	23	2	7		236	
5MQ8	tri	4	8	24	2	8		19	
5P29		2	8	3	1	8		450	
5R4	pl-1	2	8	15	1			4	
5R4	pl-2	2	8	15	1			6	
5RDDH1	di-1	4	6	23	2	2		1	
5RDDH1	di-2	4	6	23	2	3		6	
5RDDH1	tri	4	6	25	2	9		78	
5RHP1	pen	4	7	22	2	7		236	
5RHP1	tri	4	7	23	2	8		19	
5RHR1	pen	4	8	21	2			236	
5RHR1	tri	4	8	23	2	8		19	
5RK16	pl-1	4	7	27	2			1	
5RK16	pl-2	4	7	27	2			8	
5T4	pl-1	2	8	10	1			4	
5T4	pl-2	2	8	10	1			6	
5T8	di-1	4	7	16	3			6	
5T8	di-2	4	7	16	3	3		2	
5T8	di-3	4	7	16	3			1	
5T8	tri	4	7	10	1	7		89	
5U4	pl-1	2	8	12	1			4	
5U4	pl-2	2	8	12	1			6	
5U8	pen	4	7	24	2			236	
5U8	tri	4	7	24	2	8		19	
5U9	pen	5	9	20	2	2		378	
5U9	tri	5	9	22	2	1		90	
5V3	pl-1	2	8	9	1			4	
5V3	pl-2	2	8	9	1			6	
5V4	pl-1	2	8	6	1			4	
5V4	pl-2	2	8	6	1			6	
5V6		2	7	8	1	8		345	
5V9	hep	5	8	21	2	1		347	
5V9	tri	5	8	20	2	9		80	
5W4	pl-1	2	8	20	1			4	
5W4	pl-2	2	8	20	1			6	
5X4	pl-1	7	8	11	1			3	
5X4	pl-2	7	8	11	1			5	
5X8	pen	4	7	24	2			1789	
5X8	tri	4	7	24	2	6		23	
5X9	pen	5	9	20	2	2		378	
5X9	tri	5	9	22	2	1		90	
5Y3	pl-1	2	8	18	1			4	
5Y3	pl-2	2	8	18	1			6	
5Y4	pl-1	7	8	20	1			3	
5Y4	pl-2	7	8	20	1			5	
5Z3	pl-1	1	8	13	1			2	
5Z3	pl-2	1	8	13	1			3	
5Z4	pl-1	2	8	6	1			4	
5Z4	pl-2	2	8	6	1			6	
6005		3	9	7	1	2	17	1+756	
6012		2	9	29	2	1		358	
6021	tri-1	3	9	24	2	5		78	
6021	tri-2	3	9	24	2	4		12	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
6028		3	16	25	2	27	27	156	
6029		2	2	28	2			13	
6046		2	18	5	1	8		345	
6072	tri-1	9	9	28	2	8	45	67	
6072	tri-2	9	9	28	2	3		12	
6080	Tri-1	7	9	22	2	6		45	
6080	Tri-2	7	9	22	2	3		12	
6084		4	9	25	2	3	27	1689	
6085	tri-1	9	9	7	1	3	45	12	note(s)
6085	tri-2	9	9	7	1	8		67	
6087	pl-1	2	8	18	1			4	
6087	pl-2	2	8	18	1			6	
6088		3	2	32	2			124	
6094		3	9	19	3	4	1245679	124	note(s)
6096		3	9	25	2	27	27	156	
6097	di-1	3	9	17	3	1		2	
6097	di-2	3	9	17	3	5		7	
6098		6	9	25	2	1		357	
60FX5		3	20	23	2	1	25	2+567	
60HL5		4	20	21	2	3	12	1+279	
6111	tri-1	3	9	26	2	5		78	
6111	tri-2	3	9	26	2	4		12	
6112	tri-1	3	9	26	2	5		78	
6112	tri-2	3	9	26	2	4		12	
6135		3	9	8	1	7	15	1+56	
6136		3	9	5	1	7		1256	
6137		2	9	9	1	5		3468	
6146		2	9	5	1	146	146	350	
6159		2	18	5	1	146	146	350	
6187		3	9	4	1	2		1567	
6188	tri-1	7	9	10	1	3		12	
6188	tri-2	7	9	10	1	6		45	
6189	tri-1	9	9	8	1	3	45	12	
6189	tri-2	9	9	8	1	8		67	
6197		4	9	22	2	1	2389	2+93+8	
6201	tri-1	9	9	4	1	8	45	67	
6201	tri-2	9	9	4	1	3		12	
6202	pl-1	3	9	12	1	7		6	
6202	pl-2	3	9	12	1			1	
6203	di-1	4	9	18	3	7		9	
6203	di-2	4	9	18	3			1	
6205		3	9	24	2	28	28	1457	
6206		3	9	24	2	28	28	1457	
6211	tri-1	9	9	23	2	8	45	67	
6211	tri-2	9	9	23	2	3		12	
6216A		4	9	23	2	38	1368	1+267	
6217		4	9	24	9	2		1267	
6227		4	9	22	2	3	16	278	
6265		3	9	4	1	2		156	
6267		4	9	26	2	3	27	169	
6336	tri-1	7	9	22	2	6		45	
6336	tri-2	7	9	22	2	3		12	
6350	tri-1	9	9	24	2	7		68	
6350	tri-2	9	9	24	2	2		13	
6360	tet-1	9	9	5	1	2		378	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
6360	tet-2	9	9	5	1			167	
6386	tri-1	1	9	25	2	8		67	
6386	tri-2	1	9	25	2	2		34	
6394	tri-1	7	18	24	2	6		45	
6394	tri-2	7	18	24	2	3		12	
6417		4	13	4	1	7	89	1368+9	
6463	tri-1	9	9	24	2	7	45	68	
6463	tri-2	9	9	24	2	2		13	
6485		3	9	3	1	7		1256	
6550		2	9	24	2	8		345	
6660		3	9	5	1	7		1256	
6661		3	9	4	1	2		156	
6662		3	9	5	1	2		1567	
6663	di-1	3	9	17	3	1		7	
6663	di-2	3	9	17	3	5		2	
6669		3	9	7	1	2	17	1+756	
6677		4	9	22	2	1	2389	2+93+8	
6678	pen	4	9	24	2			236	
6678	tri	4	9	24	2	8		19	
6679	tri-1	9	9	4	1	8	45	67	
6679	tri-2	9	9	4	1	3		12	
6680	tri-1	9	9	8	1	8	45	67	
6680	tri-2	9	9	8	1	3		12	
6681	tri-1	9	9	8	1	8	45	67	
6681	tri-2	9	9	8	1	3		12	
6686		4	9	24	2	3	16	2789	
6688		4	9	22	2	13	13	279	
6689		4	9	23	2	3		126	
6829	tri-1	9	9	22	2	8	45	67	
6829	tri-2	9	9	22	2	3		12	
6883		2	13	24	2	146	146	350	
6919	di-1	3	9	19	3	1		7	
6919	di-2	3	9	19	3	5		2	
6922	tri-1	4	9	21	2	8		67	
6922	tri-2	4	9	21	2	3		12	
6939	pen-1	9	9	22	2	2		368	
6939	pen-2	9	9	22	2			167	
6973	pen	4	9	7	1	7	1368	3+6,1+8,,9	note(s)
6A3		1	9	8	1			23	
6A4		1	9	12	1			234	
6A5		8	5	5	1		27	35	
6A6	tri-1	1	9	10	1	4		23	
6A6	tri-2	1	9	10	1			56	
6A7	tot	1	9	9	1	6		23450	
6A7	tri	1	9	11	1			45	
6A8	tot	2	9	9	1	8		34560	
6A8	tri	2	9	11	1			56	
6AB4		3	9	23	2	7		16	
6AB5	eye	1	9	0	4			24	note(s)
6AB5	tri	1	9	19	1	5		23	
6AB7		2	9	5	1	5		3468	
6AB8	pen	4	9	6	1	3		6789	
6AB8	tri	4	9	11	1			12	
6AC10	tri-1	4	9	21	2	9		12	note(s)
6AC10	tri-2	4	9	21	2	6		57	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
6AC10	tri-3	4	9	21	2	6		15	
6AC5		2	9	11	1	8		5,3	
6AC7		2	9	3	1	5		3468	
6AC9	di	1	9	19	3	3	3	2	note(s)
6AC9	pen	6	9	20	2	6		345	
6AD10	pen-1	1	9	20	2	4		589	
6AD10	pen-2	5	9	21	2	2		134	
6AD4		3	8	11	2	5		12	
6AD5		2	9	7	1	8		35	
6AD6	eye	2	9	0	4	8		345	note(s)
6AD7	pen	2	9	11	1			345	
6AD7	tri	2	9	31	1	8		16	
6AE5		2	9	6	1	8		35	
6AE6	tri-1	2	9	14	1	8		35	
6AE6	tri-2	2	9	14	1			45	
6AE7	tri-1	2	9	10	1	8		36	
6AE7	tri-2	2	9	10	1	5		34	
6AF11	pen	6	9	25	2	1		237	note(s)
6AF11	tri-1	1	9	24	2	5		68	
6AF11	tri-2	1	9	25	2	7		34	
6AF3		4	9	18	3	0	29	2+9	
6AF4		3	9	23	2	5	1267	1+72+6	
6AF5		2	9	7	1	8		35	
6AF6	eye	2	9	0	4	8		345	note(s)
6AF9	pen-1	5	9	20	2	7		890	note(s)
6AF9	pen-2	5	9	20	2	2		134	
6AG11	di-1	9	9	24	2	6		5	note(s)
6AG11	di-2	3	9	24	2	4		5	
6AG11	tri-1	9	9	22	2	4		23	
6AG11	tri-2	3	9	22	2	6		78	
6AG12		8	9	20	1	5	27	2	
6AG5		3	9	24	2	27	27	156	
6AG6		2	9	24	2	8		345	
6AG7		2	9	3	1	5		1468	
6AG9	pen	5	9	21	2	2		348	note(s)
6AG9	tri	1	9	21	2	6		57	
6AH4		2	9	4	1	8		15	
6AH5		2	9	7	1	8		146	
6AH6		3	9	3	1	7		1256	
6AH9	pen	6	9	21	2	1		250	note(s)
6AH9	tri	1	9	23	2	4	56	23	
6AJ4		7	9	22	2	2	13469	1+3+4+6+95	
6AJ5		3	9	5	1	27	27	156	
6AJ7		2	9	3	1	5		3468	
6AJ8	hep	5	9	24	2	3		1267	
6AJ8	tri	5	9	27	2			89	
6AJ9	pen	5	9	22	2	2		378	
6AJ9	tri	5	9	23	2	1		90	
6AK10	tri-1	7	9	22	2	0		45	note(s)
6AK10	tri-2	1	9	22	2	6		57	
6AK10	tri-3	5	9	22	2	9		48	
6AK4		3	9	23	2	5		18	
6AK5		3(4)	9	25	2	2+7	27	1,6,(k),5	
6AK6		3	9	10	1	7		1256	
6AK7		2	9	3	1	5		1468	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
6AK8	di-1	4	9	25	3			6	
6AK8	di-2	4	9	18	3	3		2	
6AK8	di-3	4	9	18	3			1	
6AK8	tri	4	9	7	1	7		89	
6AK9	pen	7	9	22	2	2		34	note(s)
6AK9	tri-1	7	9	24	2	2		56	
6AK9	tri-2	0	9	26	2	7		23	
6AL11	pen-1	1	9	18	3	4	3	5689	note(s)
6AL11	pen-2	5	9	18	3	2	7	134	
6AL3		4	9	23	2	0	1236789	3+8+9	
6AL5	di-1	3	9	17	3	1		7	
6AL5	di-2	3	9	17	3	5		2	
6AL6		2	9	7	1	8		450	
6AL7	eye	2	9	0	4	8		13456	note(s)
6AL9	pen	4	9	22	2	1		2379	note(s)
6AL9	tri	3	9	21	2	8		79	
6AM4		7	9	22	2	2	13469	1+3+4+6+95	
6AM5		3	9	25	2	2		157	
6AM6		3	9	23	2	2		1567	
6AM8	di	4	9	17	3	7		8	
6AM8	pen	4	9	23	2	1		2369	
6AN4		3	9	22	2	5	1267	1+72+6	
6AN5		3	9	4	1	27	27	156	
6AN6	di-1	1	9	20	3	6		2	
6AN6	di-2	1	9	18	3			3	
6AN6	di-3	1	9	20	3			4	
6AN6	di-4	1	9	21	3			5	
6AN8	pen	4	9	26	2	9		678	
6AN8	tri	4	9	27	2	3		12	
6AQ4		3	9	21	2	25	1256	1+56	
6AQ5		3	9	7	1	2	17	1+756	
6AQ6	di-1	3	9	27	3			5	
6AQ6	di-2	3	9	27	3			6	
6AQ6	tri	3	9	28	2	2		17	
6AQ7	di-1	7	9	23	3	2		3	
6AQ7	di-2	7	9	23	3			1	
6AQ7	tri	7	9	10	1	6		45	
6AQ8	tri-1	4	9	22	2	8		67	
6AQ8	tri-2	4	9	22	2	3		12	
6AR11	pen-1	9	9	21	2	6		2345	note(s)
6AR11	pen-2	3	9	21	2	8		4567	
6AR5		3	9	9	1	2		156	
6AR6		6	9	25	2	1		357	
6AR8	pen-1	4	9	24	2	7		369	
6AR8	pen-2	4	9	24	2			368	
6AS11	pen	6	9	22	2	1		237	note(s)
6AS11	tri-1	1	9	23	2	5		68	
6AS11	tri-2	1	9	24	2	7		34	
6AS5		3	9	6	1	1	25	2+567	
6AS6		3	9	4	1	2		1567	
6AS7	tri-1	7	9	3	1	3		12	
6AS7	tri-2	7	9	3	1	6		45	
6AS8	di	6	9	17	3	8		6	
6AS8	pen	4	9	23	2	3		129	
6AT6	di-1	3	9	26	3			5	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
6AT6	di-2	3	9	26	3			6	
6AT6	tri	3	9	8	1	2		17	
6AT8	pen	4	9	23	2			6789	
6AT8	tri	4	9	24	2	3		12	
6AU4		7	9	22	2	3		5	
6AU5		2	9	6	1	3		158	
6AU6		3	9	5	1	7		1256	
6AU7	tri-1	9	5	8	1	8	45	67	
6AU7	tri-2	9	5	8	1	3		12	
6AU8	pen	4	9	24	2	6		789	
6AU8	tri	4	9	24	2	1		23	
6AV11	tri-1	6	9	26	2	9		12	note(s)
6AV11	tri-2	3	9	26	2	8		79	
6AV11	tri-3	6	9	26	2	8		37	
6AV5		2	9	5	1	3		158	
6AV6	di-1	3	9	27	3			5	
6AV6	di-2	3	9	27	3			6	
6AV6	tri	3	9	27	2	2		17	
6AW6		3	9	5	1	2		1567	
6AW8	pen	4	9	23	2	6		789	
6AW8	tri	4	9	25	2	1		23	
6AX3		6	9	24	2	0	29	2+9	note(s)
6AX4		7	9	7	1	3		5	
6AX5	pl-1	2	9	4	4	8		5	
6AX5	pl-2	2	9	4	4			3	
6AX7	tri-1	9	5	8	1	8	45	67	
6AX7	tri-2	9	5	8	1	3		12	
6AX8	pen	4	9	22	2	7		236	
6AX8	tri	4	9	22	2	8		19	
6AY11	di-1	3	9	25	2	2		1	note(s)
6AY11	di-2	1	9	25	2	2		3	
6AY11	tri-1	1	9	26	2	9		78	
6AY11	tri-2	1	9	25	2	4		56	
6AY3		4	9	24	2	9	27	2+7	
6AZ5	di-1	3	9	18	3	7		8	
6AZ5	di-2	3	9	18	3	2		1	
6AZ6	di-1	3	9	18	3	4		2	
6AZ6	di-2	3	9	18	3	5		7	
6AZ8	pen	4	9	23	2	3		126	
6AZ8	tri	4	9	25	2	7		89	
6B10	di-1	7	9	18	3	2		3	note(s)
6B10	di-2	7	9	18	3			1	
6B10	tri-1	1	9	25	2	7		56	
6B10	tri-2	1	9	25	2	2		34	
6B32	di-1	3	9	17	3	1		7	
6B32	di-2	3	9	17	3	5		2	
6B4		2	9	8	1			35	
6B5	inp	1	9	24	1	5		34	
6B5	outp	1	9	16	1			24	
6B6	di-1	2	9	27	3			4	
6B6	di-2	2	9	27	3			5	
6B6	tri	2	9	11	1	8		30	
6B7	di-1	1	9	27	3			5	
6B7	di-2	1	9	27	3			4	
6B7	pen	1	9	19	1	6		230	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
6B8	di-1	2	9	27	3			4	
6B8	di-2	2	9	27	3			5	
6B8	pen	2	9	19	1	8		360	
6BA11	pen-1	3	9	24	2	0		678	note(s)
6BA11	pen-2	1	9	24	2	8		346	
6BA11	tri	7	9	26	2	5		46	
6BA3		4	9	4	1	9	27	2	note(s)
6BA5		4	9	24	2	2		135	
6BA6		3	9	5	1	7		1256	
6BA7	tot	4	9	4	1	3		12679	
6BA7	tri	4	9	4	1			12	
6BA8	pen	4	9	22	2	6		789	
6BA8	tri	4	9	5	1	1		23	
6BB14		4	9	20	2	38	123678	1+26+70	
6BC4		4	9	22	2	6	123789	1+2+3+7+89	
6BC5		3	9	23	2	27	27	156	note(s)
6BC7	di-1	4	9	16	3	9		8	
6BC7	di-2	4	9	16	3	7		6	
6BC7	di-3	4	9	16	3	1		2	
6BC8	tri-1	4	9	23	2	8		67	
6BC8	tri-2	4	9	23	2	3		12	
6BD11	pen	4	9	25	2	1		237	note(s)
6BD11	tri-1	1	9	24	2	5		68	
6BD11	tri-2	1	9	25	2	7		34	
6BD4A		2	9	22	3	1		50	
6BD5		2	9	5	1	3		158	
6BD6		3	9	8	1	7		1256	
6BD7A	di-1	4	9	29	3			8	
6BD7A	di-2	4	9	26	3			6	
6BD7A	tri	4	9	7	1	3	79	12	
6BE3		1	9	23	2	9	60	60	note(s)
6BE6	tot	3	9	24	2	2		1567	
6BE6	tri	3	9	25	2			16	
6BE7		4	9	23	2	38	38	167	
6BE8	pen	4	9	23	2	8		679	
6BE8	tri	4	9	22	2	3		12	
6BF11	pen-1	1	9	28	2	2		3567	note(s)
6BF11	pen-2	7	9	23	2	4		356	
6BF5		3	9	3	1	2	17	1+756	
6BF6	di-1	3	9	27	3			5	
6BF6	di-2	3	9	27	3			6	
6BF6	tri	3	9	11	1	2		17	
6BF7	tri-1	3	9	24	2	5		78	
6BF7	tri-2	3	9	24	2	4		12	
6BF8	di-1	4	9	25	2	6		9	
6BF8	di-2	4	9	25	2			8	
6BF8	di-3	4	9	25	2			7	
6BF8	di-4	4	9	25	2			3	
6BF8	di-5	4	9	25	2			2	
6BF8	di-6	4	9	25	2			1	
6BG6		2	9	6	1	3		580	
6BG7	tri-1	3	9	24	2	5		78	
6BG7	tri-2	3	9	24	2	4		12	
6BH11	pen	6	9	20	2	5		234	note(s)
6BH11	tri-1	1	9	20	2	2		34	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
6BH11	tri-2	1	9	20	2	5		67	
6BH3		4	9	24	2	9	27	2+7	
6BH6		3	9	4	1	2		156	
6BH8	pen	4	9	24	2	6		789	
6BH8	tri	4	9	23	2	1		23	
6BJ3		1	9	24	2	7		4	note(s)
6BJ6		3	9	23	2	2		1567	
6BJ7	di-1	4	9	17	3	9		8	
6BJ7	di-2	4	9	17	3	7		6	
6BJ7	di-3	4	9	17	3	1		2	
6BJ8	di-1	4	9	18	3	3		6	
6BJ8	di-2	4	9	18	3	2		1	
6BJ8	tri	4	9	26	2	9		78	
6BK11	tri-1	6	9	24	2	9		12	note(s)
6BK11	tri-2	3	9	24	2	8		79	
6BK11	tri-3	6	9	24	2	8		37	
6BK4		2	9	22	3	13468	13468	50	
6BK5		4	9	24	2	6	37	13+78	
6BK6	di-1	3	9	23	3			6	
6BK6	di-2	3	9	23	3			5	
6BK6	tri	3	9	7	1	2		17	
6BK7	tri-1	4	9	22	2	8		67	
6BK7	tri-2	4	9	22	2	3		12	
6BK8		4	9	26	2	3	27	169	
6BL4		7	9	0	1	3		1+5	note(s)
6BL7	tri-1	7	9	5	1	3		12	
6BL7	tri-2	7	9	5	1	6		45	
6BL8	pen	4	8	22	2	7		236	
6BL8	tri	4	8	23	2	8		19	
6BM8	pen	4	9	23	2	2		367	
6BM8	tri	4	9	23	2	8		19	
6BN11	pen-1	6	9	20	2	2		135	note(s)
6BN11	pen-2	1	9	20	2	4		567	
6BN4		3	9	23	2	16	1267	2+75	
6BN5		4	9	6	1	3	1268	1+26+879	
6BN6		3	9	41	3	1		2567	
6BN7	tri-1	4	9	3	1	6		79	
6BN7	tri-2	4	9	27	2	3		12	
6BN8	di-1	4	9	17	3	3		6	
6BN8	di-2	4	9	17	3	2		1	
6BN8	tri	4	9	25	2	9		78	
6BQ5		4	9	5	1	3	12	1+279	
6BQ6		2	9	5	1	8		450	
6BQ7	tri-1	4	9	24	2	8		67	
6BQ7	tri-2	4	9	24	2	3		12	
6BR3	di-2	9	5	18	3			6	
6BR3		4	9	18	3	0	29	2+9	
6BR5	eye	4	9	0	4			79	note(s)
6BR5	tri	4	9	13	1	2		17	
6BR7	di-1	9	5	18	3	8		7	
6BR7	tri	9	5	23	2	3	45	12	
6BR8	pen	4	9	23	2	8		679	
6BR8	tri	4	9	23	2	3		12	
6BS3		4	9	16	3	9	27	2+7	
6BS8	tri-1	4	9	24	2	8		67	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
6BS8	tri-2	4	9	24	2	3		12	
6BT3	di-2	3	9	26	3			6	
6BT6	di-1	3	9	26	3			5	
6BT6	tri	3	9	24	2	2		17	
6BT8	di-1	4	9	20	3	3		2	
6BT8	di-2	4	9	20	3			1	
6BT8	pen	4	9	23	2	9		678	
6BU6	di-1	3	9	23	3			6	
6BU6	di-2	3	9	23	3			5	
6BU6	tri	3	9	10	1	2		17	
6BU8	sec-1	4	9	24	2	1		2789	
6BU8	sec-2	4	9	24	2			2367	
6BV11	pen-1	6	9	21	2	2		134	note(s)
6BV11	pen-2	1	9	21	2	7		568	
6BV8	di-1	4	9	17	3	7		9	
6BV8	di-2	4	9	17	3	8		6	
6BV8	tri	4	9	23	2	1		23	
6BW11	pen-1	6	9	21	2	4		235	note(s)
6BW11	pen-2	1	9	20	2	4		567	
6BW3		1	9	17	3	7		4	note(s)
6BW4	pl-1	4	9	14	1	9		7	
6BW4	pl-2	4	9	14	1			1	
6BW6		4	9	24	2	3	12	1278	
6BW8	di-1	4	9	18	3	2		3	note(s)
6BW8	di-2	4	9	18	3	2		1	
6BW8	pen	4	9	23	2	7		689	
6BX6		4	9	22	2	13	13	278	note(s)
6BX7	tri-1	7	9	23	2	6		45	
6BX7	tri-2	7	9	23	2	3		12	
6BX8	tri-1	4	9	24	2	8		67	
6BX8	tri-2	4	9	24	2	3		12	
6BY11	pen-1	1	9	21	2	2		3567	note(s)
6BY11	pen-2	7	9	21	2	4		356	
6BY5	pl-1	2	9	7	1	8		8	
6BY5	pl-2	2	9	7	1	1		4	
6BY6	sec-1	3	9	5	1	2		16	
6BY6	sec-2	3	9	5	1			1567	
6BY7		4	9	22	2	13	13	278	note(s)
6BY8	di	4	9	17	3	3		6	
6BY8	pen	4	9	5	1	9		178	
6BZ3		1	9	16	3	7		4	note(s)
6BZ6		3	9	23	2	2		1567	
6BZ7	tri-1	4	9	23	2	8		67	
6BZ7	tri-2	4	9	23	2	3		12	
6BZ8	tri-1	4	9	22	2	3		12	
6BZ8	tri-2	4	9	22	2	8		67	
6C10	tri-1	6	9	26	2	9		12	note(s)
6C10	tri-2	1	9	26	2	6		57	
6C10	tri-3	6	9	26	2	8		37	
6C16	pen	4	9	22	2	7		236	
6C16	tri	4	9	23	2	8		19	
6C18	pen	4	9	19	2			237	
6C18	tri	4	9	21	2	68	68	19	
6C4		3	9	8	1	7	15	1+56	
6C5		2	9	12	1	8		35	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
6C6		1	9	10	1	5		2340	
6C7	di-1	1	9	27	3			4	
6C7	di-2	1	9	27	3			5	
6C7	tri	1	9	12	1	6		20	
6C8	tri-1	2	9	12	1	4		30	
6C8	tri-2	2	9	12	1	8		56	
6C9	tet-1	4	9	24	2	6		789	
6C9	tet-2	4	9	24	2	0		123	
6CA11	pen	7	9	21	2	4		356	note(s)
6CA11	tri-1	1	9	24	2	7		23	
6CA11	tri-2	1	9	24	2	5		46	
6CA4	pl-1	4	9	6	1	3		1	
6CA4	pl-2	4	9	6	1			7	
6CA5		3	9	5	1	1	25	2+567	
6CA7		7	9	4	1	8		1+34+5	
6CB6		3	9	23	2	2		1567	
6CC31	tri-1	3	9	24	2	7		25	
6CC31	tri-2	3	9	24	2			16	
6CC42	tri-1	1	9	24	2	8		67	
6CC42	tri-2	1	9	24	2	2		34	
6CC43	tri-1	5	9	22	2	8		67	
6CC43	tri-2	5	9	22	2	3		12	
6CD3		1	9	20	2	7		4	note(s)
6CD6		2	9	4	1	3		580	
6CD7		2	9	0	4	8		365	note(s)
6CE3		1	9	20	2	7		4	note(s)
6CE5		3	9	23	2	27	27	156	
6CF6		3	9	23	2	2		1567	
6CF8		4	9	26	2	3	27	169	
6CG3		1	9	16	3	7		4	note(s)
6CG7	tri-1	4	9	10	1	8		67	
6CG7	tri-2	4	9	10	1	3		12	
6CG8	pen	4	9	23	2			679	
6CG8	tri	4	9	24	2	38	38	12	
6CH3		4	9	20	2	9	27	2+7	
6CH6		4	9	3	1	3		278	
6CH7	tri-1	4	9	24	2	89	89	67	
6CH7	tri-2	4	9	24	2	3		12	
6CH8	pen	4	9	23	2	6		237	
6CH8	tri	4	9	25	2	1		89	
6CJ3		4	9	20	2	9	27	2	note(s)
6CJ6		4	9	20	2	3	16789	27+80	
6CK3		4	9	20	2	9	27	2+7	
6CK4		2	9	21	2	8	13	1+35	
6CK5									as EL41
6CK6		4	9	22	2	3		127	
6CL3		4	9	20	2	9	27	2+7	
6CL5		2	9	2	1	36	134568	1+84+50	
6CL6		4	9	22	2	1	2389	2+93+8	
6CL8	tet	4	9	23	2	8		679	
6CL8	tri	4	9	23	2	3		12	
6CM3		4	9	22	2	9	27	2+7	
6CM4		4	9	20	2	37		1+2+6+8+9	note(s)
6CM5		2	9	23	2	38	1348	459	note(s)
6CM6		4	9	25	2	7	36	13+69	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
6CM7	tri-1	4	9	8	1	3		67	
6CM7	tri-2	4	9	24	2	9		18	
6CM8	pen	4	9	23	2	3		267	
6CM8	tri	4	9	26	2	8		19	
6CN6		2	8	3	1	8		450	
6CN7	di-1	9	5	17	3	3		2	
6CN7	di-2	9	5	17	3			1	
6CN7	tri	9	5	28	2	6	45	78	
6CQ4		7	9	18	3	3		5	
6CQ6		3	9	6	1	2		1567	
6CQ8	tet	4	9	24	2	7		236	
6CQ8	tri	4	9	24	2	8		19	
6CR6	di	3	9	26	3	1		2	
6CR6	pen	3	9	26	2			567	
6CR8	pen	4	9	21	2	3		267	
6CR8	tri	4	9	22	2	8		19	
6CS6	tot	3	9	24	2			1567	
6CS6	tri	3	9	24	2	2		16	
6CS7	tri-1	4	9	5	1	9		13	
6CS7	tri-2	4	9	10	1	8		67	
6CT3		4	9	23	2	9	26	2+6	
6CT7									as EAF42
6CU5		3	9	4	1	1	25	2+567	
6CU6		2	9	4	1	8		450	
6CU7	hex	1	9	5	1			256	
6CU7	osc	1	9	9	1			24	
6CU7	tri	1	9	7	1	7		34	
6CU8	pen	4	9	23	2	6		237	note(s)
6CU8	tri	4	9	3	1	1		89	
6CV7	di-1	1	9	23	3			5	
6CV7	di-2	1	9	23	3			6	
6CV7	tri	1	9	26	2	7		23	
6CW4		4	9	17	3	3		12	
6CW5		4	8	21	2	3		1+26+97+8	note(s)
6CW7	tri-1	4	9	24	2	78	78	69	
6CW7	tri-2	4	9	24	2	1		23	
6CX8	pen	4	9	24	2	6		789	
6CX8	tri	4	9	25	2	1		23	
6CY5		3	9	23	2	27	27	156	
6CY7	sec-1	4	9	28	2	8		7,6	
6CY7	sec-2	4	9	23	2	9	23	2+3,1	
6CZ5		4	9	9	1	7	36	13+69	
6D1		3	9	24	2	7	15	1+56	
6D10	tri-1	6	9	22	2	9		12	note(s)
6D10	tri-2	1	9	22	2	6		57	
6D10	tri-3	6	9	22	2	8		37	
6D4		3	9	7	1	5		17	
6D5		2	9	11	1	8		35	
6D6		1	9	11	1	5		2340	
6D7		1	9	10	1	6		2340	
6D8	tot	2	9	10	1	8		34560	
6D8	tri	2	9	13	1			56	
6DA4		7	9	4	1	3		5	
6DA5	eye	4	9	0	4			73+8+9	note(s)
6DA5	tri	4	9	32	2	2	389	17	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
6DA6		4	9	25	2	3	16	2789	
6DB5		4	9	6	1	27	2367	13+69	
6DB6		3	9	23	2	2		1567	
6DC6		3	9	24	2	2		156	
6DC8	di-1	4	9	23	3			7	
6DC8	di-2	4	9	23	3			8	
6DC8	pen	4	9	23	2	3		126	
6DE4		7	8	4	1	3		5	
6DE6		3	9	22	2	2		156	
6DE7	tri-1	4	9	9	1	8	23	67	
6DE7	tri-2	4	9	3	1	9		12+3	
6DG6		2	9	5	1	8		345	
6DJ8	tri-1	4	9	21	2	8		67	
6DJ8	tri-2	4	9	21	2	3		12	
6DK3		4	9	23	2	0	27	2+7	
6DK6		3	9	23	2	2		1567	
6DL3		4	9	21	2	0	27	27	
6DL4		4	9	21	2	2	13679	18	note(s)
6DL5		3	8	23	2	2	17	1+756	
6DM4		7	9	24	2	3		5	
6DN3		5	9	20	2	9	27	27	
6DN6		2	9	23	2	3		580	
6DN7	tri-1	7	9	25	2	6		45	
6DN7	tri-2	7	9	25	2	3		12	
6DQ3		1	9	16	3	7		4	note(s)
6DQ4		2	9	18	3	3		5	
6DQ5		2	9	2	1	36	154836	1+54+80	
6DQ6	pen	2	9	4	1	8		5,4,(k),0	
6DR4		3	9	24	2	7	15	1+56	
6DR7	tri-1	4	9	28	2	8		67	
6DR7	tri-2	4	9	23	2	9		12+3	
6DR8	di-1	4	9	23	3			7	
6DR8	di-2	4	9	23	3			8	
6DR8	pen	4	9	24	2	3		126	
6DS4		4	9	18	2	3		12	
6DS5		3	9	25	2	2	17	1+756	
6DS8	hep	4	9	18	2	3		1267	
6DS8	tri	4	9	18	2			89	
6DT3		1	9	16	3	7		4	note(s)
6DT4		7	9	4	1	3	15	5	note(s)
6DT5		4	9	28	2	7	36	13+69	
6DT6		3	9	24	2	2		1567	
6DT8	tri-1	4	9	23	2	8		67	
6DT8	tri-2	4	9	23	2	3		12	
6DU3		1	9	16	3	7		4	note(s)
6DV4		3	9	19	2	7	1246	1+24+6	
6DW4		4	9	4	1	9	27	2	note(s)
6DW5		4	9	24	2	7	36	13+69	
6DX8	pen	4	9	23	2	7		689	
6DX8	tri	4	9	23	2	3		12	
6DY5		2	9	24	2	3		279	
6DY7	pen-1	2	9	25	2	8		56	
6DY7	pen-2	2	9	25	2			13	
6DZ4		3	9	24	2	5		1267	note(s)
6DZ7	pen-1	2	9	5	1	8		456	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
6DZ7	pen-2	2	9	5	1			134	
6DZ8	pen	4	9	23	2	2		367	
6DZ8	tri	4	9	28	2	8		19	
6E5	eye	1	9	0	4			24	note(s)
6E5	tri	1	9	18	1	5		23	
6E6	tri-1	1	9	12	1	4		23	
6E6	tri-2	1	9	12	1			56	
6E7		1	9	11	1	6		2340	
6E8	tot	2	9	9	1	8		34560	
6E8	tri	2	9	11	1			56	
6EA4		1	9	26	3	47	47	80	note(s)
6EA5		3	9	23	2	27	27	156	
6EA7	tri-1	7	9	26	2	6		45	
6EA7	tri-2	7	9	3	1	3		12	
6EA8	pen	4	9	22	2	7		236	
6EA8	tri	4	9	23	2	8		19	
6EB5	di-1	3	9	19	3	1		7	
6EB5	di-2	3	9	19	3	5		2	
6EB8	pen	4	9	24	2	6		789	
6EB8	tri	4	9	23	2	1		23	
6EC4		4	9	20	2	0	278	2+7+8	
6ED4		4	9	32	2	1	123679	80	
6EF4		2	9	34	2	8		90	note(s)
6EH4		1	9	26	3	47	47	80	note(s)
6EH5		3	9	24	2	1	25	2+567	
6EH7		4	9	22	2	13	13	2789	
6EH8	pen	4	9	2	1	16	16	789	
6EH8	tri	4	9	0	1			23	
6EJ4		2	9	35	2	8	15	90	note(s)
6EJ7		4	9	21	2	13	13	2789	
6EL4		2	9	22	3	13468	13468	50	
6EM5		4	9	4	1	7	36	13+69	
6EM7	tri-1	7	9	26	2	6		45	
6EM7	tri-2	7	9	22	2	3		12	
6EN4		2	9	22	3	1348	12345678	560	note(s)
6EQ7	di	4	9	29	3	3		8	
6EQ7	pen	4	9	23	2			1267	
6ER5		3	9	22	2	17	17	256	
6ES5		3	9	22	2	17	17	25	
6ES6		3	9	23	2	2		156	
6ES8	tri-1	4	9	22	2	8		67	
6ES8	tri-2	4	9	22	2	3		12	
6ET6		3	8	23	2	2		156	
6ET7	di-1	4	9	27	3	1		3	
6ET7	di-2	4	9	28	3			2	
6ET7	pen	4	9	24	2	6		789	
6EU7	tri-1	1	9	19	3	9		78	
6EU7	tri-2	1	9	19	3	4		56	
6EU8	pen	4	9	22	2	8		179	
6EU8	tri	4	9	22	2	6		23	
6EV5		3	9	18	3	27	27	157	
6EV7	tri-1	4	9	23	2	8		67	
6EV7	tri-2	4	9	23	2	3		12	
6EW6		3	9	20	2	2		156	
6EW7	sec-1	4	9	27	2	8		67	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
6EW7	sec-2	4	9	23	2	9	23	12+3	
6EX6		2	9	22	2	3		580	
6EY6		2	9	24	2	8		345	
6EZ5		2	9	3	1	8		345	
6EZ8	tri-1	4	9	27	2			89	
6EZ8	tri-2	4	9	27	2			67	
6EZ8	tri-3	4	9	23	2	1		23	
6F19		4	9	22	2	13	13	278	
6F21		3	9	6	1	2		1567	
6F22		4	9	26	2	3	27	169	
6F26		4	9	22	2	13	13	278	
6F29		4	9	22	2	13	13	2789	
6F30		4	9	21	2	13	13	2789	
6F33		3	9	4	1	2		1567	
6F35		3	9	5	1	27	27	159	
6F4		1	9	3	1	5	2378	2+37+8	
6F5		2	9	8	1	8		40	
6F6	pen	2(7)	9	11	1	8		5,4,(k),3	
6F7	pen	1(7)	9	18	1	6		0,3,(k),2	
6F7	tri	1(7)	9	32	1	6		5,4	
6F8	tri-1	2	9	8	1	4		30	
6F8	tri-2	2	9	8	1	8		56	
6FA7	di	4	9	28	3	6		3	
6FA7	tet	4	9	25	2			1789	
6FD10		3	10	23	2	7		1256	
6FD6		3	9	23	2	7		1256	
6FD7	tri-1	4	9	8	1	8		67	
6FD7	tri-2	4	9	22	2	9	23	12+3	
6FE5		2	9	23	2	8		345	
6FG5		3	9	23	2	27	27	156	
6FG6	eye	5	9	0	4			7,2+6+8	note(s)
6FG6	tri	5	9	21	3	3	268	1,9	
6FG7	pen	4	9	22	2			679	
6FG7	tri	4	9	22	2	38	38	12	
6FG7	tri-2	4	9	23	2	3		26	
6FH5		3	9	23	2	17	17	25	
6FH6		2	9	22	2	8		450	
6FH8	tet-1	5	9	22	2			679	
6FH8	tet-2	5	9	22	2			678	
6FH8	tet-3	5	9	22	2			167	
6FH8	tri	5	9	22	2			23	
6FJ7	tri-1	7	9	28	2	2		34	note(s)
6FJ7	tri-2	1	9	24	2	7		35	
6FM7	tri-1	6	9	19	3	3		45	note(s)
6FM7	tri-2	1	9	18	3	9		57	
6FM8	di-1	4	9	18	3	3		2	
6FM8	di-2	4	9	18	3	1		6	
6FM8	tri	4	9	9	1	7		89	
6FQ5		3	9	22	2	17	17	25	
6FQ7	tri-1	4	9	7	1	8		67	
6FQ7	tri-2	4	9	7	1	3		12	
6FR7	tri-1	4	9	7	1	8	23	67	
6FR7	tri-2	4	9	20	2	9		12+3	
6FS5		3	9	22	2	27	27	156	
6FV5		3	9	23	2	7		156	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
6FV8	pen	4	9	22	2	8		679	
6FV8	tri	4	9	22	2	3		12	
6FW5		2	9	23	2	3		158	
6FW8	tri-1	4	9	22	2	8		67	
6FW8	tri-2	4	9	22	2	3		12	
6FY5		3	9	22	2	17	17	25	
6FY7	tri-1	4	9	8	1	1		23	note(s)
6FY7	tri-2	1	9	22	2	9		57	
6FY8	pen	4	9	22	2	2		367	
6FY8	tri	4	9	24	2	8		19	
6G11	pen-1	7	9	23	2	2		134	note(s)
6G11	pen-2	1	9	25	2	4		5689	
6G5	eye	1	9	0	4			24	note(s)
6G5	tri	1	9	19	1	5		23	
6G6		2	9	11	1	8		345	
6GA7	di	3	9	24	2	0		2	note(s)
6GA7	pen	1	9	35	2	5	10	237	
6GB3		2	9	18	3	8		450	
6GB5		4	9	22	2	38	123678	160	note(s)
6GB6		2	9	18	3	8		450	
6GB7		2	9	4	1	8		450	
6GB9		2	9	4	1	8		450	
6GC5		4	9	23	2	7	1368	1+83+69	
6GC6		2	9	23	2	3	48	4+589	
6GD7	pen	4	9	20	2			679	
6GD7	tri	4	9	20	2	38	38	12	
6GE5		6	9	23	2	29	2389	73+80	note(s)
6GE8	pen	4	9	24	2	7		189	
6GE8	tri	4	9	23	2	2		36	
6GF5		6	9	23	2	29	2389	73+80	note(s)
6GF7	tri-1	4	9	29	2	1		89	
6GH8	pen	4	9	22	2	7		236	
6GH8	tri	4	9	22	2	8		19	
6GJ5		4	9	24	2	3	1267	670	note(s)
6GJ7	pen	4	9	20	2			267	
6GJ7	tri	4	9	21	13	13	89		
6GK17		7	9	22	2	3		5	
6GK5		3	9	22	2	17	17	25	
6GK6	pen	4	9	23	2	1	39	2,8,3+9,7	
6GL7	tri-1	7	9	26	2	6		45	
6GL7	tri-2	7	9	22	2	3		12	
6GM5		4	9	25	2	7		169	
6GM6		3	9	21	2	2		1567	
6GM8	tri-1	4	9	23	2	8		67	
6GM8	tri-2	4	9	23	2	3		12	
6GN8	pen	4	9	22	2	6		789	
6GN8	tri	4	9	24	2	1		23	
6GQ7	di-1	4	9	17	3	9		8	
6GQ7	di-2	4	9	17	3	7		6	
6GQ7	di-3	4	9	17	3	1		2	
6GS7	pen	4	9	19	2			679	
6GS7	tri	4	9	21	2	38	38	12	
6GS8	sec-1	4	9	24	2	1		2789	
6GS8	sec-2	4	9	24	2			2367	
6GT5		4	9	23	2	3	1267	1+2+679	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
6GU5		3	9	21	2	27	27	156	note(s)
6GU7	tri-1	4	9	24	2	8	5	67	
6GU7	tri-2	4	9	24	2	3		12	
6GV5		3	9	24	2	18	1278	2790	note(s)
6GV7	pen	4	9	19	2			237	note(s)
6GV7	tri	4	9	21	2	68	68	19	
6GV8	pen	4	9	22	2	8		679	
6GV8	tri	4	9	24	2	3		12	
6GW5		3	9	20	2	5	26	12+6	
6GW6		2	9	18	3	8		450	
6GW8	pen	4	9	23	2	7		368	
6GW8	tri	4	9	26	2	2		19	
6GX6		3	9	23	2	2		1567	
6GX7	pen	4	9	20	2			267	
6GX7	tri	4	9	21	2	13	13	89	
6GX8	eye	4	9	0	4	3		67	note(s)
6GX8	tri	4	9	21	2	9		18	
6GY5		3	9	22	2	18	1278	2790	note(s)
6GY6		3	9	21	2	2		1567	
6GY8	tri-1	4	9	28	2	7		6	
6GY8	tri-2	4	9	22	2	8		39	
6GY8	tri-3	4	9	27	2			12	
6GZ5		3	9	21	2	1	25	2+567	
6H5	eye	1	9	0	4			24	note(s)
6H5	tri	1	9	20	1	5		23	
6H6	di-1	2(7)	9	18	3	8		3	
6H6	di-2	2(7)	9	18	3	4		5	
6HA5		3	9	21	2	27	27	15	note(s)
6HA6		4	9	22	2	1	3689	26+87	
6HB5		1	9	22	2	4		237	note(s)
6HB6		4	9	22	2	1	3689	3+96+827	
6HB7	pen	4	9	24	2	13	13	267	note(s)
6HB7	tri	4	9	23	2	13	13	89	
6HC8	pen	4	9	18	3	2		367	
6HC8	tri	4	9	18	3	8		19	
6HD5		1	9	20	2	4	59	357	note(s)
6HD7	pen	4	9	22	2			267	
6HD7	tri	4	9	21	2	13	13	89	
6HE5		1	9	19	3	6	0	4580	note(s)
6HE7	di	1	9	16	3	4		2	note(s)
6HE7	pen	7	9	16	2	3		46	
6HF5		3	9	23	2	18	1278	2790	note(s)
6HF8	pen	4	9	22	2	6		789	
6HF8	tri	4	9	24	2	1		23	
6HG5		3	9	7	1	2	17	1+756	
6HG8	pen	4	9	22	2	1	13	289	
6HG8	tri	4	9	23	2	3	13	67	
6HJ5		1	9	20	2	4	59	35+7+9	note(s)
6HJ7	pen	4	9	20	2			267	
6HJ7	tri	4	9	19	2	13	13	89	
6HJ8	di	4	9	24	2	7		8	
6HJ8	pen	4	9	23	2	1		2369	
6HK5		3	9	21	2	27	27	15	
6HL5		4	9	21	2	3	12	1+279	
6HL7		6	9	20	2	1	3459	3+9278	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
6HL8	pen	4	9	21	2	7		236	
6HL8	tri	4	9	22	2	8		19	
6HM5		3	9	22	2	27	27	15	note(s)
6HM6		4	9	20	2	13	13	278	
6HQ5		3	9	20	2	27	27	15	
6HR5		3	9	7	1	2	17	1+756	
6HR6		3	9	21	2	7		156	
6HS5		1	9	20	2	4		27	note(s)
6HS6		3	9	22	2	7		1256	
6HS8	pen-1	4	9	23	2	1		2789	
6HS8	pen-2	4	9	23	2			2367	
6HT6		4	9	22	2	13		278	note(s)
6HU6	eye	4	9	0	4			67	note(s)
6HU6	tri	4	9	29	2	3	268	19	
6HU8	pen-1	4	9	22	2	7		123	
6HU8	pen-2	4	9	22				689	
6HV5		1	9	20	2	4		27	note(s)
6HW8		4	9	24	2	7		123689	
6HZ5		1	6	21	2	4		27	note(s)
6HZ6		4	9	17	3	2		156	
6HZ8	pen	4	9	23	2	6		789	
6HZ8	tri	4	9	24	2	1		23	
6J10	pen-1	0	9	26	4	8	1	4567	note(s)
6J10	pen-2	5	9	18	3	9	7	248	
6J11	pen-1	9	9	22	2	3		2456	note(s)
6J11	pen-2	3	9	22	2	8		4567	
6J4		3	9	4	1	2	156	1+5+67	
6J5	tri	2(7)	9	8	1	8		5,3	
6J6	tri-1	3	9	24	2	7		25	
6J6	tri-2	3	9	24	2			16	
6J7	pen	2	9	11	1	8		0,4,(5),3	
6J8	hep	2	9	8	1			340	
6J8	tri	2	9	28	2	8		56	
6J9	tri-1	4	9	20	2	0		78	
6J9	tri-2	4	9	20	2			69	
6J9	tri-3	4	9	20	2	3		12	
6JA5		1	9	21	2	6	0	4580	note(s)
6JA8	tet	4	9	24	2	6		789	
6JA8	tri	4	9	24	2	1		23	
6JB5		1	9	19	3	6	0	4580	note(s)
6JB6		4	9	18	3	3	1267	670	note(s)
6JC5		1	9	18	3	6	0	4580	note(s)
6JC6		4	9	22	2	13	13	278	
6JC8	pen	4	9	18	3			236	note(s)
6JC8	tri	4	9	18	3	17	7	89	
6JD5		1	6	21	2	4		27	note(s)
6JD6		4	9	22	2	13	13	278	
6JE6		4	9	23	2	3	1267	1+2+6780	
6JE8	pen	4	9	23	2	6		789	
6JE8	tri	4	9	23	2	1		23	
6JF6		4	9	20	2	3	1267	1+2+670	
6JG5		4	9	21	2	6		789	
6JG6		4	9	17	3	3	17	279	note(s)
6JH5		1	9	20	2	4	78	2378	note(s)
6JH6		3	9	22	2	2		1567	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
6JH8	sec-1	4	9	24	2	7	5	369	
6JH8	sec-2	4	9	24	2			368	
6JK5		1	9	20	2	4	78	2378	note(s)
6JK6		3	9	21	2	2		156	
6JK8	tri-1	4	9	18	3	8		67	
6JK8	tri-2	4	9	18	3	3		12	
6JL6		3	9	22	2	2		156	
6JM6		2	9	21	2	5		680	note(s)
6JN6		6	9	21	2	7	29	380	note(s)
6JN8	pen	4	9	23	2	8		679	
6JN8	tri	4	9	22	2	3		12	
6JQ6	di	4	9	32	2			6	note(s)
6JQ6	pen	4	9	22	2	9	78	1237+8	
6JR6		4	9	28	3	3	17	279	note(s)
6JS6		4	9	20	2	5	16	1+680	
6JT6		4	9	23	2	3	17	279	note(s)
6JT8	pen	4	9	21	2	6		789	
6JT8	tri	4	9	23	2	1		23	
6JU6		4	9	20	2	3	1267	1+2+6+70	
6JU8	di-1	4	9	24	2	9		78	note(s)
6JU8	di-2	4	9	24	2	98		7	
6JU8	di-3	4	9	24	2	3		12	
6JU8	di-4	4	9	24	32		1		
6JV8	pen	4	9	17	3			789	
6JV8	tri	4	9	18	3	1		23	
6JW8	pen	4	9	21	2	7		236	
6JW8	tri	4	9	22	2	8		19	
6JX8	hep	4	9	21	2			267	
6JX8	tri	4	9	23	2	3		89	
6JY8	pen	4	9	24	2	6		789	
6JY8	tri	4	9	23	2	1		23	
6JZ6		2	9	20	2	5		780	note(s)
6JZ8	pen	9	9	23	2	4	12	1+230	note(s)
6JZ8	tri	6	9	26	2	3		27	
6K11	tri-1	6	9	7	1	9		12	note(s)
6K11	tri-2	1	9	7	1	6		57	
6K11	tri-3	6	9	7	1	8		37	
6K5		2	9	7	1	8		30	
6K6	pen	2(7)	9	9	1	8		5,4,(k),3	
6K7	pen	2(7)	9	12	1	8		0,4,(5),3	
6K8	hex	2(7)	9	5	1	8		5,4,0,(4),3	
6K8	tri	2(7)	9	5	1	8		5,6	
6KA8	pen	4	9	22	2	3		6789	
6KA8	tri	4	9	24	2	3		12	
6KD6		3	9	20	2	6	1278	2+790	note(s)
6KD8	pen	4	9	22	2	7		236	
6KD8	tri	4	9	22	2	8		19	
6KE8	pen	4	9	23	2	7		236	
6KE8	tri	4	9	24	2	8		19	
6KF8	pen-1	4	9	21	2	1		278	
6KF8	pen-2	4	9	21	2			237	
6KG6		4	9	20	2	9	123678	689	note(s)
6KH8		4	9	23	2	7		12	
6KH8		4	9	23	2			239	
6KH8		4	9	23	2			689	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
6KL8	di	4	9	28	3			8	
6KL8	pen	4	9	24	2	3		1267	
6KM6		4	9	21	2	3	1267	670	note(s)
6KM8	di	4	9	27	3	6		3	
6KM8	tet-1	4	9	5	1			178	
6KM8	tet-2	4	9	5	1			978	
6KM8	tet-2	4	9	6	1			278	
6KN6		5	9	20	2	8	49	24+90	
6KN8	tri-1	4	9	20	2	8		67	
6KN8	tri-2	4	9	20	2	3		12	
6KR8	pen	4	9	20	2	6		789	
6KR8	tri	4	9	20	2	1		23	
6KS6		3	9	41	3	1		2567	
6KS8	pen	4	9	23	2	6		789	
6KS8	tri	4	9	25	2	1		23	
6KT6		4	9	21	2	13	13	278	
6KT8	pen	4	9	20	2	6		789	
6KT8	tri	4	9	21	2	1		23	
6KU8	di-1	4	9	25	3	1		3	
6KU8	di-2	4	9	25	3	1		2	
6KU8	pen	4	9	22	2	6		678	
6KV6		4	9	20	2	3	17	279	note(s)
6KV8	pen	4	9	21	2	6		789	
6KV8	tri	4	9	23	2	1		23	
6KX8	tri-1	4	9	24	2	8		79	
6KX8	tri-2	4	9	24	2	2		13	
6KY6		4	9	20	2	1	39	278	
6KY8	pen	4	9	21	2	3		267	
6KY8	tri	4	9	25	2	1		89	
6KZ8	pen	4	9	22	2	3		267	
6KZ8	tri	4	9	22	2	8		19	
6L5		2	9	13	1	8		35	
6L6		2	9	7	1	8		345	
6L7	hep	2(7)	9	8	1	8		0,4,5,(4),(k),3	
6LB6		3	9	21	2	6	1278	2+790	note(s)
6LB8	pen	4	9	22	2	6		789	
6LB8	tri	4	9	29	2	1		23	
6LC6		2	9	35	2	6	134	50	
6LC8	pen	4	9	22	2	7	5	689	note(s)
6LC8	tri	4	9	24	2	3	5	12	
6LD6		4	9	20	2	1	3689	26+87	
6LE8	pen-1	4	9	22	2	3		189	
6LE8	pen-2	4	9	22	2			689	
6LF6		3	9	21	2	6	1278	2+790	
6LF8	pen	4	9	21	2	6		789	
6LF8	tri	4	9	24	2	1		23	
6LG6		3	9	22	2	18	1278	790	note(s)
6LH6		2	9	32	2	6	134	50	
6LJ6		2	9	36	2	6	134	50	
6LJ8	pen	4	9	20	2			679	
6LJ8	tri	4	9	21	2	38	38	12	
6LM8	pen	4	9	23	2	7		236	
6LM8	tri	4	9	23	2	8		19	
6LN8	pen	4	9	22	2	7		236	
6LN8	tri	4	9	23	2	8		19	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
6LQ6		4	9	23	2	3	1267	1+2+6780	
6LQ8	pen	4	9	20	2	6		789	
6LQ8	tri	4	9	20	2	1		23	
6LR6		4	9	22	2	5	16	1+680	note(s)
6LR8	pen	4	9	20	2	3		267	
6LR8	tri	4	9	21	2	1		89	
6LT8	di-1	4	9	16	3	7		8	note(s)
6LT8	di-2	4	9	16	3	7		6	
6LT8	pen	4	9	19	2	1		239	
6LU6		4	9	20	2	2		1567	
6LU8	pen	9	9	21	2	4	12	1+230	note(s)
6LU8	tri	6	9	21	2	3		27	
6LV6		3	9	21	2	6	1278	2+790	note(s)
6LW6		7	9	21	2	26	1256	1+350	
6LX6		4	9	23	2	5	16	1+680	note(s)
6LX8	pen	4	9	21	2	7		236	
6LX8	tri	4	9	22	2	8		19	
6LY8	pen	4	9	20	2	6		789	
6LY8	tri	4	9	22	2	1		23	note(s)
6LZ6		4	9	23	2	3	1267	1+2+679	
6M11	pen	5	9	23	2	1		267	note(s)
6M11	tri-1	1	9	22	2	9		78	
6M11	tri-2	1	9	22	2	4		56	
6M3		8	9	2	1	0	12357	3+5+7	
6MA6		3	9	20	3	7	2458	60	
6MB6		6	9	19	3	7	2389	123890	note(s)
6MB8	pen	4	9	19	2	8		679	
6MB8	tri	4	9	20	2	3		12	
6MC6		4	9	20	2	3	1267	120	note(s)
6MD8	tri-1	4	9	22	2	7		36	
6MD8	tri-2	4	9	22	2			28	
6MD8	tri-3	4	9	22	2			19	
6ME6		4	9	20	2	4	1267	120	note(s)
6ME8	sec-1	4	9	21	2	7		369	
6ME8	sec-2	4	9	21	2			368	
6MF8	pen	9	9	22	2	4	12	1+230	note(s)
6MF8	tri	6	9	21	2	3		27	
6MG8	pen	4	9	21	2	7		236	
6MG8	tri	4	9	21	2	8		19	
6MH1		3	9	4	1	2	156	1+5+67	
6MH6		3	9	21	2	6	1278	2+790	note(s)
6MHH3	tri	3	9	24	2			16	
6MHH3	tri	3	9	24	2	7		25	
6MJ6		4	9	23	2	3	1267	1+2+6780	
6MJ8	tri-1	1	9	22	2	3		68	note(s)
6MJ8	tri-2	3	9	22	2	7		18	
6MJ8	tri-3	3	9	22	2			26	
6MK8	pen-1	4	9	22	2	1		237	
6MK8	pen-2	4	9	22	2			278	
6ML4		3	9	24	2	5		1267	note(s)
6ML8	tri-1	4	9	22	2	7		36	
6ML8	tri-2	4	9	22	2			28	
6ML8	tri-3	4	9	22	2			19	
6MN8	tri-1	7	9	24	2			48	note(s)
6MN8	tri-2	6	9	24	2			29	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
6MN8	tri-3	1	9	24	2	3		68	
6MP17		4	9	25	2	2		156	
6MP18		3	9	3	1	2	17	1+567	
6MP20		3	5	25	2	2		156	
6MQ8	pen	4	9	23	2	7		236	
6MQ8	tri	4	9	24	2	8		19	
6MU8	pen	4	9	24	2	7		236	
6MU8	tri	4	9	24	2	8		19	
6MV8	pen	4	9	22	2	6		789	
6MV8	tri	4	9	21	2	1		23	
6MX8	pen	4	9	21	2	3		267	
6MX8	tri	4	9	25	2	1		89	
6MY8	pen	9	9	21	2	4	12	1+230	note(s)
6MY8	tri	6	9	21	2	3		27	
6N3		4	9	24	2	3		9	
6N4		3	9	5	1	26	1267	1+75	
6N5	eye	1	9	0	4			24	note(s)
6N5	tri	1	9	19	1	5		23	
6N6		2	9	12	1	8		345	
6N7	tri-1	2	9	11	1	8		34	
6N7	tri-2	2	9	11	1			56	
6N8	di-1	5	9	25	3			7	
6N8	di-2	5	9	23	3			8	
6N8	pen	5	9	5	1	3		1269	
6P5		2	9	13	1	8		35	
6P7	pen	2	9	18	1			450	
6P7	tri	2	9	32	1	8		67	
6PL12	pen	4	9	23	2			367	
6PL12	tri	4	9	23	2	8		19	
6Q11	tri-1	6	9	25	2	9		12	note(s)
6Q11	tri-2	3	9	25	2	8		79	
6Q11	tri-3	6	9	25	2	8		37	
6Q4		1	9	3	1	5	2378	2+37+8	
6Q5		2	9	8	1	8		35	
6Q7	di-1	2	9	27	3			4	
6Q7	di-2	2	9	27	3			5	
6Q7	tri	2	9	9	1	8		30	
6Q8	tot	2	9	9	1	8		34560	
6Q8	tri	2	9	9	1			56	
6R3		4	9	22	2	0		29	note(s)
6R4		4	9	23	2	3		18	
6R6		2	9	13	1	8		350	
6R7	di-1	2	9	27	3			4	
6R7	di-2	2	9	27	3			5	
6R7	tri	2	9	11	1	8		30	
6R8	di-1	4	9	16	3	3		2	
6R8	di-2	4	9	16	3			1	
6R8	di-3	4	9	16	3			6	
6R8	tri	4	9	11	1	7		89	
6RA6		5	9	17	3	1	27	279	note(s)
6RA9		4	9	23	2	1	27	279	note(s)
6RB11		4	9	25	2	7	36	1396	
6RHH2	tri	4	9	24	2	3		12	
6RHH2	tri	4	9	24	2	8		67	
6RHH8	tri-1	4	9	20	2	8		67	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
6RHH8	tri-2	4	9	20	2	8		67	
6RK19		4	9	18	3	0	29	2+9	
6RP15		4	9	25	2	3	12	1+279	
6RP22		4	9	20	2	1	2389	2+36	note(s)
6S2		258	9	21	4		1469	0	
6S4		4	9	6	1	2	36	3+69	
6S7		2	9	10	1	8		3450	
6S8	di-1	7	9	27	3	5		3	note(s)
6S8	di-2	7	9	27	3			4	
6S8	di-3	7	9	27	3			1	
6S8	tri	7	9	10	1	2		60	
6SA7	tot	2	9	6	1	6		5,4,8,(4),(k),3	
6SA7	tri	2	9	6	1			5,4	
6SB7	tot	2	9	4	1	6		3458	
6SB7	tri	2	9	4	1			45	
6SC7	tri-1	7	9	12	1	6		45	
6SC7	tri-2	7	9	12	1			23	
6SD7		2	9	5	1	5		3468	
6SF5	tri	7(8)	9	8	1	2		3,5	
6SF7	di	7	9	27	3			5	
6SF7	pen	7	9	12	1	3		246	
6SG7		2	9	5	1	35	35	468	
6SH7		2	9	5	1	35	35	468	
6SJ7	pen	2(7)	9	8	1	5		4,6,(3),8	
6SK7	pen	2(7)	9	9	1	5		4,6,(3),8	
6SL7	tri-1	7	9	11	1	3		12	
6SL7	tri-2	7	9	11	1	6		45	
6SN7	tri-1	7(8)	9	9	1	3		1,2	
6SN7	tri-2	7(8)	9	9	1	6		4,5	
6SQ7	di-1	7(8)	9	27	3	3		5	
6SQ7	di-2	7(8)	9	27	3	3		4	
6SQ7	tri	7(8)	9	10	1	3		2,6	
6SR7	di-1	7	9	27	3			5	
6SR7	di-2	7	9	27	3			4	
6SR7	tri	7	9	11	1	3		26	
6SS7		2	9	11	1	5		3468	
6ST7	di-1	7	9	27	3			5	
6ST7	di-2	7	9	27	3			4	
6ST7	tri	7	9	11	1	3		26	
6SU7	tri-1	7	9	10	1	3		12	
6SU7	tri-2	7	9	10	1	6		45	
6SV7	di	7	9	18	3			5	
6SV7	pen	7	9	6	1	3		246	
6SZ7	di-1	7	9	27	3			5	
6SZ7	di-2	7	9	27	3			4	
6SZ7	tri	7	9	11	1	3		26	
6T10	pen-1	5	9	19	3	2		134	note(s)
6T10	pen-2	1	9	19	3	4		5789	
6T4		3	9	22	2	5	1267	1+72+6	
6T5	eye	1	9	0	4			24	note(s)
6T5	tri	1	9	21	1	5		23	
6T7	di-1	2	9	27	3			5	
6T7	di-2	2	9	27	3			4	
6T7	tri	2	9	12	1	8		30	
6T8	di-1	4	9	16	3			6	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
6T8	di-2	4	9	16	3	3		2	
6T8	di-3	4	9	16	3			1	
6T8	tri	4	9	10	1	7		89	
6T9	pen	7	9	3	1	4		356	note(s)
6T9	tri	3	9	25	2	9		68	
6U10	tri-1	4	9	26	2	9		12	note(s)
6U10	tri-2	1	9	26	2	6		57	
6U10	tri-3	4	9	26	2	6		15	
6U3		4	9	24	2	3		9	
6U4		7	9	5	1	3		5	
6U5	eye	1	9	0	4			24	note(s)
6U5	tri	1	9	21	1	5		23	
6U6		2	9	6	1	8		345	
6U7	pen	2	9	11	1	8		0,4,(5),3	
6U8	pen	4	9	24	2	7		236	
6U8	tri	4	9	24	2	8		19	
6U9	pen	5	9	20	2	2		378	
6U9	tri	5	9	22	2	1		90	
6V3		4	9	3	1	0	279	2+7+9	
6V4	pl-1	4	9	11	1	3		1	
6V4	pl-2	4	9	11	1			7	
6V6	pen	2	9	8	1	8		5,4,(k),3	
6V7	di-1	2	9	26	3			4	
6V7	di-2	2	9	26	3			5	
6V7	tri	2	9	15	1	8		30	
6V8	di-1	4	9	24	3			9	
6V8	di-2	4	9	16	3	8		7	
6V8	di-3	4	9	16	3			2	
6V8	tri	4	9	26	2	3		16	
6V9	hep	5	9	21	2	1		347	
6V9	tri	5	9	20	2	9		80	
6W4		7	8	4	1	3		5	note(s)
6W5	pl-1	2	9	8	1	8		3	
6W5	pl-2	2	9	8	1			5	
6W6		2	9	24	2	8		345	
6W7		2	9	10	1	8		3450	
6X2		2	9	18	4			0	note(s)
6X4	pl-1	3	9	11	1	7		1	
6X4	pl-2	3	9	11	1			6	
6X5	pl-1	2	9	10	1	8		3	
6X5	pl-2	2	9	10	1			5	
6X8	pen	4	9	24	2			1789	
6X8	tri	4	9	24	2	6		23	
6X9	pen	5	9	20	2	2		378	
6X9	tri	5	9	22	2	1		90	
6Y10	pen-1	5	9	21	2	2		134	note(s)
6Y10	pen-2	1	9	20	2	4		5789	
6Y5	pl-1	1	9	9	1	4		3	
6Y5	pl-2	1	9	9	1			5	
6Y6		2	9	5	1	8		345	
6Y7	tri-1	2	9	9	1	8		34	
6Y7	tri-2	2	9	9	1			56	
6Y9	pen-1	5	9	20	2	7		890	
6Y9	pen-2	5	9	20	2	2		134	
6Z10	pen-1	0	9	26	4	8	1	4567	note(s)

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
6Z10	pen-2	5	9	18	3	9	7	248	
6Z3		1	9	6	1	3		2	
6Z4	pl-1	1	9	9	1	4		2	
6Z4	pl-2	1	9	9	1			3	
6Z5	pl-1	1	9	8	1	4	26	3	
6Z5	pl-2	1	9	8	1			5	
6Z6	pl-1	2	9	9	1	8		3	
6Z6	pl-2	2	9	9	1	4		5	
6Z7	tri-1	2	9	8	1	8		34	
6Z7	tri-2	2	9	8	1			56	
6ZY5	pl-1	2	9	11	1	8		3	
6ZY5	pl-2	2	9	11	1			5	
7025	tri-1	9	9	27	2	8	45	67	
7025	tri-2	9	9	27	2	3		12	
7027		7	9	24	2	8	1456	31+45+6	
7036	tet	3	9	5	1	2		1567	
7036	tri	3	9	5	1			16	
7054		4	13	22	2	1	39	278	
7055	di-1	3	13	17	3	1		7	
7055	di-2	3	13	17	3	5		2	
7056		4	13	23	2	2		1567	
7057	tri-1	4	13	23	2	8		67	
7057	tri-2	4	13	23	2	3		12	
7058	tri-1	4	13	27	2	8		67	
7058	tri-2	4	13	27	2	3		12	
7059	pen	4	13	24	2	7		236	
7059	tri	4	13	24	2	8		19	
7060	pen	4	13	24	2	6		789	
7060	tri	4	13	24	2	1		23	
7061		4	13	8	1	7	1368	1+83+69	
70A7	amp	2	21	5	1	8	67	345	
70A7	rec	2	21	3	1	1			note(s)
70L7	amp	2	21	4	1	6		345	
70L7	rec	2	21	4	1	1		8	
71		1	8	14	1			23	
7119	tri-1	8	9	23	2	6	45	79	
7119	tri-2	8	9	23	2	3		12	
713A		2	9	24	2	35	35	468	
7167		3	13	23	2	27	27	156	
717A		2	9	24	2	35	35	468	
7189		4	9	22	2	3		1279	note(s)
7199	pen	4	9	21	2	6		7,3,(k),2	
7199	tri	4	9	22	2	8		9,1	
7233		4	9	17	3	8	123679	123679	
7247	tri-1	9	9	7	1	8		67	
7247	tri-2	9	9	7	1	3		12	
7258	pen	4	13	26	2	9		678	
7258	tri	4	13	27	2	3		12	
7308	tri-1	4	9	17	3	8		7,6	
7308	tri-2	4	9	17	3	3		2,1	
7320		4	9	5	1	3	12	1+279	
7355		2	9	3	1	5		368	
7360		4	9	24	2	1		2367	
7370	tri-1	8	16	25	2	6	45	79	
7370	tri-2	8	16	24	2	3		12	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
7408		2	9	8	1	8		345	
75	di-1	1	9	27	3			3	
75	di-2	1	9	27	3			4	
75	tri	1	9	10	1	5		20	
7551		4	13	25	2	19	1389	23+867	
7558		4	9	25	2	19	1389	23+867	
7581		2	8	24	2	8		345	
7586		2	9	17	3	3	5	12	
7587		4	9	24	3	3		12	
7591		2	9	24	2	5	48	4+836	
76		1	9	11	1	4		23	
7643	pen	4(5)	9	24	2	7		2,3,(k),6	
7643	tri	4(5)	9	24	2	8		9,1	
7687	pen	4	9	23	2	7		236	
7687	tri	4	9	25	2	8		19	
7695		4	20	23	2	7		169	
77		1	9	10	1	5		2340	
7701		4	13	26	2	138	13789	267+9	
7716	pen	4	13	23	2	6		789	
7716	tri	4	13	24	2	1		23	
7728	tri-1	9	9	4	1	8	45	67	
7728	tri-2	9	9	4	1	3		12	
7729	tri-1	9	9	27	2	8	45	67	
7729	tri-2	9	9	27	2	3		12	
7730	tri-1	9	9	8	1	8	45	67	
7730	tri-2	9	9	8	1	3		12	
7731	pen	4	9	24	2	7		236	
7731	tri	4	9	24	2	8		19	
7733		6	9	22	2	1	3459	278	
7754		4	9	23	2	7		169	
7788		4	9	19	2	13	1369	2679	
78		1	9	11	1	5		2340	
7802	tri-1	7	9	23	2	6		45	
7802	tri-2	7	9	23	2	3		12	
7868		4	9	23	2	3	1267	1+2+679	
7895		4	9	16	3	3		12	
7898	tri-1	4	13	17	3	8		67	note(s)
7898	tri-2	4	13	17	3	3		12	
79	tri-1	1	9	9	1	4		23	
79	tri-2	1	9	9	1			50	
7984		6	13	24	2	239	23915	450	note(s)
7A4		1	9	7	1	7		26	
7A5		1	9	5	1	7		236	
7A6	di-1	1	9	19	3	2		3	
7A6	di-2	1	9	10	3	7		6	
7A7		1	9	9	1	7		2346	
7A8	tot	1	9	9	1	7		23456	
7A8	tri	1	9	11	1			34	
7AD7		1	9	4	1	7		2346	
7AF7	tri-1	1	9	9	1	2		34	
7AF7	tri-2	1	9	9	1	7		56	
7AG7		1	9	4	1	7		2346	
7AH7		1	9	4	1	7		2346	
7AJ7		1	9	7	1	7		2346	
7AK7		1	9	5	1	7		2346	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
7AN7	tri-1	4	10	23	2	78	78	69	
7AN7	tri-2	4	10	23	2	1		23	
7AU7	tri-1	9	5	8	1	8	45	67	
7AU7	tri-2	9	5	8	1	3		12	
7B4		1	9	7	1	7		26	
7B5		1	9	12	1	7		236	
7B6	di-1	1	9	27	3			5	
7B6	di-2	1	9	27	3			6	
7B6	tri	1	9	11	1	47	47	23	
7B7		1	9	11	1	7		2346	
7B8	tot	1	9	7	1	7		23456	
7B8	tri	1	9	9	1			34	
7C4	di	1	9	21	3	7		4	
7C5	pen	1	9	6	1	7		6,3,(k),2	
7C6	di-1	1	9	26	3			5	
7C6	di-2	1	9	26	3			6	
7C6	tri	1	9	14	1	47	47	23	
7C7		1	9	8	1	7		2346	
7D10		4	9	3	1	3		278	
7DJ8	tri-1	4	9	23	2	8		67	
7DJ8	tri-2	4	9	23	2	3		12	
7E5		2	9	5	1	46	134567	1+53+7	
7E6	di-1	1	9	27	3			5	
7E6	di-2	1	9	27	3			6	
7E6	tri	1	9	11	1	47	47	23	
7E7	di-1	1	9	27	3			3	
7E7	di-2	1	9	27	3			4	
7E7	pen	1	9	13	1	7		256	
7ES8	tri-1	4	10	22	2	8		67	
7ES8	tri-2	4	10	22	2	3		12	
7EY6		2	10	24	2	8		345	
7F7	tri-1	1	9	10	1	2		34	
7F7	tri-2	1	9	10	1	7		56	
7F8	tri-1	2	9	24	2	4		13	
7F8	tri-2	2	9	24	2	5		68	
7G7		1	9	4	1	7		2346	
7G8	sec-1	1	9	7	1	6		357	
7G8	sec-2	1	9	6	1			234	
7GS7	pen	4	10	20	2			679	
7GS7	tri	4	10	21	2	38	38	12	
7GV7	pen	4	10	19	2			237	note(s)
7GV7	tri	4	10	21	2	68	68	19	
7H7		1	9	4	1	7		2346	
7HG8	pen	4	10	22	2	1	13	289	
7HG8	tri	4	10	23	2	3	13	67	
7J7	hex	1	9	7	1	7		256	
7J7	tri	1	9	11	1			34	
7K7	di-1	1	9	27	3	7		5	
7K7	di-2	1	9	27	3			6	
7K7	tri	1	9	10	1	2		34	
7KY6		4	10	20	2	1	39	278	
7KZ6		4	10	21	2	1	39	278	
7L7		1	9	4	1	7		2346	
7MP18		3	9	3	1	2	17	1+567	
7N7	tri-1	1	9	8	1	2		34	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
7N7	tri-2	1	9	8	1	7		56	
7Q7	tot	1	9	5	1	7		23456	
7Q7	tri	1	9	5	1			34	
7R7	di-1	1	9	26	3			3	
7R7	di-2	1	9	26	3			4	
7R7	pen	1	9	6	1	7		256	
7S7	hep	1	9	5	1	7		256	
7S7	tri	1	9	28	2			34	
7T7		1	9	5	1	7		2346	
7V7		1	9	5	1	7		2346	
7W7		1	9	4	1	47	47	2356	
7X6	pl-1	1	9	5	1	2		3	
7X6	pl-2	1	9	5	1	7		6	
7X7	di-1	1	9	26	3	4		5	
7X7	di-2	1	9	26	3	7		6	
7X7	tri	1	9	10	1	4		23	
7Y4	pl-1	1	9	10	1	7		3	
7Y4	pl-2	1	9	10	1			6	
7Z4	pl-1	1	9	15	1	7		3	
7Z4	pl-2	1	9	15	1			6	
80	pl-1	1	8	18	1			2	
80	pl-2	1	8	18	1			3	
801		1	10	20	1			23	
8016									as 1B3
802		1	9	11	1	6		3450	
8032		2	13	25	2	146	146	350	
8056		4	9	16	3	3		12	
807		1	9	7	1	4		230	
8077		4	13	22	2	1	39	278	
809		1	9	10	1			30	
81		1	10	30	1			2	
8102	pen	4	13	22	2	8		679	
8102	tri	4	13	22	2	2		13	
8106		4	13	18	3	269	23689	1378	note(s)
8113		3	9	22	2	27	27	156	note(s)
811A		4	9	12	1			30	
812		1	9	4	4			30	
8136		3	9	23	2	2		1567	
8156		3	13	26	2	60	67890	129	note(s)
82	pl-1	1	4	7	1			2	
82	pl-2	1	4	7	1			3	
8203		4	9	17	3	3	5	12	
8233		4	9	20	2	79	2679	318	
8278		4	9	21	2	26	123678	1+3+7+89	
8298		2	9	22	2	146	146	350	
83	pl-1	1	8	7	1			2	
83	pl-2	1	8	7	1			3	
837		1	13	7	1	6		3450	
83V	pl-1	1	8	5	1			2	
83V	pl-2	1	8	5	1			3	
84	pl-1	1	9	9	1	4		2	
84	pl-2	1	9	9	1			3	
841		1	10	17	1			23	
8417		2	9	21	2	8		345	
842		1	10	23	1			23	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
8425		3	9	23	2	7		1256	
843		1	4	16	1	4		23	
8441		4	9	18	3	3		12	
85	di-1	1	9	26	3			3	
85	di-2	1	9	26	3			4	
85	tri	1	9	16	1	5		20	
8532		3	9	4	1	2	156	1+5+67	
8552		2	13	25	2	146	146	350	
864		1	2	37	2			23	
866JR		1	4	4	4			2	
879									as 2X2
884		2	9	8	1	8		35	
885		1	4	7	1	4		23	
89		1	9	9	1	5		2340	
8908		7	9	20	2	4	1256	3560	note(s)
8950		2	13	23	2	59	1269	1+678	note(s)
8A8	pen	4	12	24	2	7		236	
8A8	tri	4	12	24	2	8		19	
8AC10	tri-1	4	11	21	2	9		12	note(s)
8AC10	tri-2	1	11	21	2	6		57	
8AC10	tri-3	4	11	21	2	6		15	
8AC9	di	1	11	16	3	3	3	2	note(s)
8AC9	pen	6	11	20	2	6		345	
8AL9	pen	4	11	22	2	1		2379	note(s)
8AL9	tri	3	11	21	2	8		79	
8AR11	pen-1	9	11	21	2	6		2345	note(s)
8AR11	pen-2	3	11	21	2	8		4567	
8AU8	pen	4	11	24	2	6		789	
8AU8	tri	4	11	24	2	1		23	
8AV11	tri-1	6	11	26	2	9		12	note(s)
8AV11	tri-2	3	11	26	2	8		79	
8AV11	tri-3	6	11	26	2	8		37	
8AW8	pen	4	11	23	2	6		789	
8AW8	tri	4	11	25	2	1		23	
8B10	di-1	7	11	18	3	2		3	note(s)
8B10	di-2	7	11	18	3			1	
8B10	tri-1	1	11	25	2	7		56	
8B10	tri-2	1	11	25	2	2		34	
8B8	pen	4	19	23	2	2		367	
8B8	tri	4	10	25	2	8		19	
8BA11	pen-1	3	11	24	2	0		678	note(s)
8BA11	pen-2	1	11	24	2	8		346	
8BA11	tri	7	11	26	2	5		46	
8BA8	pen	4	11	22	2	6		789	
8BA8	tri	4	11	5	1	1		23	
8BH8	pen	4	11	24	2	6		789	
8BH8	tri	4	11	23	2	1		23	
8BM11	pen-1	7	11	21	2	5		246	note(s)
8BM11	pen-2	1	11	21	2	5		236	
8BN11	pen-1	6	11	20	2	2		135	note(s)
8BN11	pen-2	1	11	20	2	4		567	
8BN8	di-1	4	11	17	3	3		6	
8BN8	di-2	4	11	17	3	2		1	
8BN8	tri	4	11	25	2	9		78	
8BQ11	pen-1	9	11	19	2	6		345	note(s)

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
8BQ11	pen-2	3	11	19	2	8		457	
8BQ5		4	11	5	1	3	12	1+279	
8BQ7	tri-1	4	10	24	2	8		67	
8BQ7	tri-2	4	10	24	2	3		12	
8BU11	pen	6	10	21	2	5		234	note(s)
8BU11	tri-1	1	10	21	2	2		34	
8BU11	tri-2	1	10	21	2	5		67	
8CB11	pen-1	9	11	21	2	6		2345	note(s)
8CB11	pen-2	3	11	21	2	8		4567	
8CG7	tri-1	4	11	10	1	8		67	
8CG7	tri-2	4	11	10	1	3		12	
8CL8	tet	4	10	23	2	8		679	
8CL8	tri	4	10	23	2	3		12	
8CM7	tri-1	4	11	24	2	3		67	
8CM7	tri-2	4	11	24	2	9		18	
8CN7	di-1	9	6	17	3	3		2	
8CN7	di-2	9	6	17	3			1	
8CN7	tri	9	6	28	2	6		78	
8CW5		4	10	21	2	3		1+26+97+8	note(s)
8CX8	pen	4	10	24	2	6		789	
8CX8	tri	4	10	25	2	1		23	
8CY5		3	11	23	2	27	27	156	
8CY7	tri-1	4	11	28	2	8		67	
8CY7	tri-2	4	11	23	1	9	23	12+3	
8D8		4	11	26	2	3	27	1689	
8DX8	pen	4	11	23	2	7		689	
8DX8	tri	4	11	23	2	3		12	
8EB8	pen	4	11	24	2	6		789	
8EB8	tri	4	11	23	2	1		23	
8EM5		4	11	4	1	7	36	13+69	
8ET7	di-1	4	10	27	3	1		3	
8ET7	di-2	4	10	28	3			2	
8ET7	pen	4	10	24	2	6		789	
8FQ7	tri-1	4	11	6	1	8		67	
8FQ7	tri-2	4	11	6	1	3		12	
8GJ7	pen	4	11	20	2			267	
8GJ7	tri	4	11	21	2	13	13	89	
8GM6		3	11	21	2	2		1567	
8GN8	pen	4	11	22	2	6		789	
8GN8	tri	4	11	24	2	1		23	
8GU7	tri-1	4	11	24	2	8		67	
8GU7	tri-2	4	11	24	2	3		12	
8GX7	pen	4	10	20	2			267	
8GX7	tri	4	10	21	2	13	13	89	
8HA6		4	11	22	2	1	3689	26+87	
8HG8	pen	4	11	22	2	1	13	289	
8HG8	tri	4	11	23	2	3	13	67	
8JE8	pen	4	10	23	2	6		789	
8JE8	tri	4	10	23	2	1		23	
8JK8	tri-1	4	11	18	3	8		67	
8JK8	tri-2	4	11	18	3	3		12	
8JT8	pen	4	10	21	2	6		789	
8JT8	tri	4	10	23	2	1		23	
8JU8	di-1	4	11	24	2	9		78	note(s)
8JU8	di-2	4	11	24	2	98		7	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
8JU8	di-3	4	11	24	2	3		12	
8JU8	di-4	4	11	24	2	32		1	
8JV8	pen	4	11	17	3			789	
8JV8	tri	4	11	18	3	1		23	
8K11	tri-1	6	10	7	1	9		12	
8K11	tri-2	1	10	7	1	6		57	note(s)
8K11	tri-3	6	10	7	1	8		37	
8KA8	pen	4	11	22	2	3		6789	
8KA8	tri	4	11	24	2	3		12	
8KR8	pen	4	10	20	2	6		789	
8KR8	tri	4	10	20	2	1		23	
8KS8	pen	4	10	23	2	6		789	
8KS8	tri	4	10	25	2	1		23	
8KT8	pen	4	11	20	2	6		789	
8KT8	tri	4	11	21	2	1		23	
8LC8	pen	4	10	22	2	7	5	689	note(s)
8LC8	tri	4	10	24	2	3	5	12	
8LE8	pen-1	4	11	22	2	3		189	
8LE8	pen-2	4	11	22	2			689	
8LS6		4	10	22	2	1	39	2379	
8LT8	di-1	4	11	16	3	7		8	note(s)
8LT8	di-2	4	11	16	3	7		6	
8LT8	pen	4	11	19	2	1		239	
8LX8	pen	4	10	21	2	7		236	
8LX8	tri	4	10	22	2	8		19	
8MD8	tri-1	4	10	22	2	7		36	
8MD8	tri-2	4	10	22	2			28	
8MD8	tri-3	4	10	22	2			19	
8MU8	pen	4	11	24	2	7		236	
8MU8	tri	4	11	24	2	8		19	
8RHP1	pen	4	10	23	2	2		367	
8RHP1	tri	4	10	25	2	8		19	
8SC7	tri-1	4	11	5	1	9		13	
8SC7	tri-2	4	11	10	1	8		67	
8SN7	tri-1	7	11	9	1	3		12	
8SN7	tri-2	7	11	9	1	6		45	
8U9	pen	5	10	20	2	2		378	
8U9	tri	5	10	22	2	1		90	
8X9	pen	5	10	20	2	2		378	
8X9	tri	5	10	22	2	1		90	
9001		3	9	9	1	27	27	156	
9002		3	9	11	1	27	1257	1+56	
9003		3	9	8	1	27	27	156	
9004	di	1	9	17	3	3		2	
9005	di	1	5	17	3	2	45	3	
9006	di	3	9	20	3	27	1257	1+5	
932		1	3	17	1			230	
950		1	3	31	1			234	
954		1	9	10	1	5		2360	
955		1	9	8	1	5		23	
956		1	9	8	1	5		2360	
957		1	2	23	1		45	23	
958		1	2	13	1		45	23	
959		1	2	18	1		45	2360	
99		1	5	41	2			23	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
9A8	pen	4	12	24	2	7		236	
9A8	tri	4	12	24	2	8		19	
9AB4		3	12	22	2	7		16	
9AH9	pen	1	11	21	2	1		250	note(s)
9AH9	tri	1	11	23	2	4	56	23	
9AK10	tri-1	5	12	22	2	9		48	note(s)
9AK10	tri-2	1	12	22	2	6		57	
9AK10	tri-3	7	12	22	2	0		45	
9AK8	di-1	4	12	25	3			6	
9AK8	di-2	4	12	18	3			2	
9AK8	di-3	4	12	18	3			1	
9AK8	tri	4	12	6	1	7		89	
9AM10	tri-1	5	12	22	2	9		48	note(s)
9AM10	tri-2	1	12	22	2	6		57	
9AM10	tri-3	7	12	22	2	0		45	
9AQ8	tri-1	4	11	22	2	8		67	
9AQ8	tri-2	4	11	22	2	3		12	
9AU7	tri-1	9	7	8	1	3	45	12	
9AU7	tri-2	9	7	8	1	8		67	
9BJ11	pen-1	7	12	16	2	5		246	note(s)
9BJ11	pen-2	1	12	16	2	5		236	
9BR7	di-1	9	7	18	3	8		7	
9BR7	di-2	9	7	18	3			6	
9BR7	tri	9	7	23	2	3	45	12	
9CG8	pen	4	12	23	2			679	
9CG8	tri	4	12	24	2	38	38	12	
9CL8	tet	4	11	23	2	8		679	
9CL8	tri	4	11	23	2	3		12	
9DZ8	pen	4	12	23	2	2		367	
9DZ8	tri	4	12	28	2	8		19	
9EA8	pen	4	12	22	2	7		236	
9EA8	tri	4	12	22	2	8		19	
9ED4		4	10	32	2	1	123679	80	
9FG6	eye	4	6	0	4			67	note(s)
9FG6	tri	4	6	34	2	3	268	19	
9GH8	pen	4	12	22	2	7		236	
9GH8	tri	4	12	22	2	8		19	
9GV8	pen	4	12	22	2	8		679	
9GV8	tri	4	12	24	2	3		12	
9JW8	pen	4	12	21	2	7		236	
9JW8	tri	4	12	22	2	8		19	
9KC6		4	11	20	2	1		279	
9KG6		4	12	20	2	9	123678	680	note(s)
9KV8	pen	4	11	21	2	6		789	
9KV8	tri	4	11	23	2	1		23	
9KX6		4	11	20	2	1	39	278	
9KZ8	pen	4	12	22	2	3		267	
9KZ8	tri	4	12	22	2	8		19	
9LA6		4	11	21	2	1	39	278	
9MHH3	tri-1	3	11	23	2	7		25	
9MHH3	tri-2	3	11	23	2			16	
9ML8	tri-1	4	11	22	2	7		36	
9ML8	tri-2	4	11	22	2			28	
9ML8	tri-3	4	11	22	2			19	
9MN8	tri-1	7	11	24	2			48	note(s)

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
9MN8	tri-2	6	11	24	2			29	
9MN8	tri-3	1	11	24	2	3		68	
9MP12		3	11	22	2	2		156	
9RA6		5	11	17	3	1	27	279	note(s)
9RAL1	tri-1	4	11	25	2	8	23	67	
9RAL1	tri-2	4	11	21	2	9		12+3	
9RHR2	pen	4	12	22	2	7		236	
9RHR2	tri	4	12	22	2	8		19	
9U8	pen	4	12	24	2			236	
9U8	tri	4	12	24	2	8		19	
9V9	hep	5	12	21	2	1		347	
9V9	tri	5	12	20	2	9		80	
9X8	pen	4	12	24	2			1789	
9X8	tri	4	12	24	2	6		23	
A442	tet	2(3)	6	<38	2			4,1,5	
AB1	di-1	2(3)	6	<23	3	5		1	
AB1	di-2	2(3)	6	<23	3	5		0	
AB2	di-1	2(3)	6	<29	2	4		5	
AB2	di-2	2(3)	6	<29	2	4		1	
ABC1	di-1	2(3)	6	<23	3	4		6	
ABC1	di-2	2(3)	6	<23	3	4		5	
ABC1	tri	2(3)	6	<28	2	4		0,8	
AF2	pen	2(3)	6	<25	2	5		4,1,,0	
AF7	pen	2(3)	6	<26	2	4		0,7,(5),8	
AL2	pen	2(3)	6	<9	1	4		0,7,(k),8	
AL4	pen	2(3)	6	<25	2	4		6,7,(k),8	
AR8	di-1	1(8)	3	<29	3			5	
AR8	di-2	1(8)	3	<29	3			7	
AR8	tri	1(8)	3	<32	2			0,3	
ARP12	pen	1(8)	3	<30	2			0,4,(5),3	
AS494	tet	2(3)	6	<28	2	5		4,1,0	=E442
ATP4	pen	8(1)	3	<27	2			5,4,(1),0	
AX50	pl-1	2(3)	7	<6	1			1	
AX50	pl-1	2(3)	7	<6	1			3	
AZ1	pl-1	2(3)	6	<22	1			5	
AZ1	pl-2	2(3)	6	<22	1			8	
AZ4	pl-1	2(3)	6	<16	1			5	
AZ4	pl-2	2(3)	6	<16	1			8	
AZ41	pl-1	7(8)	6	<23	1			2+1	note(s)
AZ41	pl-1	7(8)	6	<23	1			6+5	
CF50	pen	2(3)	19	<24	2	1+4	14	0,7,(k),8	
CK1013			1	12	4	1267	1267	0	
CK501AX		3	2	32	2			124	
CK502AX		1	2	32	2			245	
CK503AX		1	2	33	2			245	
CK505AX		3	1	43	3			124	
CK506AX		3	2	32	2			124	
CK507AX		3	2	32	2			124	
CK511AXA	di	4	2	47	3			3	
CK511X		3	2	31	2			1245	
CK512AX		3	1	50	3			124	
CK521AX		3	2	31	2			124	
CK522AX		3	2	32	2			124	
CK527AX		3	2	34	3			124	
CK532DX		3	2	33	3			124	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
CK536AX		3	2	33	3			124	
CK542DX		3	2	20	3			124	
CK5517			1	12	4	1267	1267	0	
CK551AXA	pen	4	2	47	3			125	
CK553AXA		3	2	29	2			124	
CK556AX		2	2	28	2			13	
CK5608	tri-1	7	4	9	1	4		56	
CK5608	tri-2	7	4	9	1			23	
CK568AX		2	2	30	2			13	
CK5694	tri-1	2	9	9	1	1		34	
CK5694	tri-2	2	9	9	1	8		56	
CK569AX		3	2	28	2			124	
CK573AX		2	2	28	2			13	
CK5755	tri-1	5	9	20	3	7		69	
CK5755	tri-2	4	9	20	3	2	59	13	
CK5829	di-1	3	9	17	3	7		6	
CK5829	di-2	3	9	17	3	2		1	
CK5854		3	2	29	3			124	
CK5889		3	2	37	3			120	note(s)
CK605CX		3	9	22	2	6		1257	
CK606BX		2	9	16	3	4		1	
CK608CX		3	9	5	1	6		15	
CK619CX		2	9	25	2	5		14	
CK6293		2	9	21	2	146	146	350	
CK6397		5	2	7	1		17	368	
CK6526		5	2	26	2			124	
CV118									as SP61
CV187									as U19
DA90	di	1	2	27	3	3	26	2+6	note(s)
DAC32	di	2	2	27	3			5	
DAC32	tri	2	2	35	2			30	
DAF91	di	1	2	29	3			3	
DAF91	pen	1	2	34	2			456	
DAF92	di	1	2	29	3			4	
DAF92	pen	1	2	34	2			236	
DAF96	di	7	2	30	3			3	
DAF96	pen	7	2	44	2			456	
DC90	tri	7	2	33	1		2356	2+35+6	
DC96	tri	1	2	30	2		2356	2+35+6	
DCC90	tri-1	4	2	28	2		17	23	
DCC90	tri-2	4	2	28	2			56	
DF33	pen	2	2	31	2			340	
DF904		7	2	31	2		15	236	
DF91	pen	7	2	31	2		15	236	
DF92	pen	7	2	32	2		15	236	
DF96	pen	7	2	32	2		15	632	
DF97	pen	7	2	17	1		15	2346	
DK32	tot	2	2	33	2			34560	
DK32	tri	2	2	38	2			56	
DK40		1	2	21	3			34	
DK91	tot	7	2	32	2		15	2346	
DK91	tri	7	2	32	2			34	
DK92	amp	7	2	12	1			23456	
DK92	osc	7	2	29	2			345	
DK96	tot	7	2	20	1			23456	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
DL33	pen	8	2	28	2		27	345	
DL35	pen	2	2	30	2			345	
DL41	pen	1	2	27	2		378	256	
DL92	pen	5	2	29	2		1267	2+634	
DL93	pen	5	2	30	2		1267	2+634	
DL94	pen	5	2	28	2		17	236	
DL95	pen	5	2	29	2		1267	2+634	
DL96	pen	5	2	28	2		17	236	
DL98	pen	26	2	29	2		45	137	
DM70	eye	4	2	0	3			18	note(s)
DM71	eye	4	2	0	3			18	note(s)
DY80		258	2	24	4			0	note(s)
DY86	Rec	258	2	20	4		1469	0	
DY87	rec	258	2	21	4		1469	0	
E180F	pen	4	9	22	2	13	13	279	
E182CC	tri-1	8	9	23	2	6	45	79	
E182CC	tri-2	8	9	23	2	3		12	
E188CC									as 7308
E235L	pen	2	9	22	2	8	14	1345	
E424	tri	2(3)	6	<30	2	5		4,1	
E428	tri	2	6	28	2	5		4,1	
E443	pen	2(3)	6	<15	1			4,5,,1	
E446	pen	2(3)	6	<26	2	5		4,1,,0	
E453	pen	2	5	37	2			4,5,1	
E55L	pen	4	9	20	2	79	2679	138	
E80CC	tri-1	9	9	7	1	3	45	12	note(s)
E80CC	tri-2	9	9	7	1	8		67	
E80CF									as 7643
E80F	pen	4(5)	9	25	2	3	27	9,1,(8),6	
E80L	pen	4(5)	9	22	2	3	16	2,8,(9),7	
E810F	pen	4	9	19	2	13	1369	2679	
E81L	pen	4	9	24	2	3	16	2,8,(9),7	
E83F	pen	4	9	23	2	3		126	
E84L	pen	4	9	5	1	3	12	1+279	
E88CC	tri-1	4(5)	9	21	2	8		7,6	
E88CC	tri-2	4(5)	9	21	2	3		2,1	
EAA11	di-1	2	9	17	3	4		5	
EAA11	di-2	2	9	17	3	7		6	
EAA901	di-1	3	9	17	3	1		7	
EAA901	di-2	3	9	17	3	5		2	
EAA91	di-1	3	9	17	3	1		7	
EAA91	di-2	3	9	17	3	5		2	
EABC80	di-1	4(5)	9	25	3	7		6	
EABC80	di-2	4(5)	9	16	3	3		2	
EABC80	di-3	4(5)	9	16	3	7		1	
EABC80	tri	4(5)	9	10	1	7		8,9	
EAC91	di	3	9	18	3	2		1	
EAC91	tri	3	9	7	1	5		67	
EAF41	di	1(8)	9	<40	3	7+4	47	3	
EAF41	tri	1(8)	9	<30	2	7+4	47	6,5,(k),2	
EAF42	di	1	9	<25	3	7		3	
EAF42	pen	1	9	<25	2	7		6,5,(4),2	
EAF801	di	4	9	23	3	3		8	
EAF801	pen	4	9	17	3	3		1269	
EAM86	di	4	9	?	?	3		2	note(s)

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
EAM86	eye	4	9	0	4	3		67	
EAM86	tri	4	9	21	2	9		8,1	
EB34	di-1	2(7)	9	<21	3	4		3	
EB34	di-2	2(7)	9	<21	3	8		5	
EB4	di-1	2(3)	9	<21	3	4		5	
EB4	di-2	2(3)	9	<21	3	8		7	
EB41	di-1	1(8)	9	<20	3	3		4	
EB41	di-2	1(8)	9	<20	3	7		6	
EB91	di-1	3	9	18	3	5		2	
EB91	di-2	3	9	18	3	1		7	
EBC11	di-1	2	9	21	3			5	
EBC11	di-2	2	9	21	3			4	
EBC11	tri	2	9	6	1	8		67	
EBC3	di-1	2(3)	9	<23	3	4		5	
EBC3	di-2	2(3)	9	<23	3	4		6	
EBC3	tri	2(3)	9	<27	2	4		0,8	
EBC33	di-1	2(7)	9	21	3			5	
EBC33	di-2	2(7)	9	21	3			4	
EBC33	tri	2(7)	9	7	1	8		0,3	
EBC41	di-1	1(8)	9	23	3	7		6	
EBC41	di-2	1(8)	9	23	3	7		5	
EBC41	tri	1(8)	9	26	2	7		3,2	
EBC81	di-1	4	9	29	3			8	
EBC81	di-2	4	9	26	3			6	
EBC81	tri	4	9	7	1	3	79	12	
EBC90	di-1	3	9	26	3	2		5	
EBC90	di-2	3	9	26	3	2		6	
EBC90	tri	3	9	8	1	2		17	
EBC91	di-1	3	9	27	3	2		5	
EBC91	di-1	3	9	27	3	2		6	
EBC91	tri	3	9	27	2	2		17	
EBF15	di-1	2	9	21	3	8		4	
EBF15	di-2	2	9	21	3	8		5	
EBF15	pen	2	9	23	2	8		167	
EBF80	di-1	5	9	25	3	3		7	
EBF80	di-2	5	9	23	3	3		8	
EBF80	pen	5	9	5	1	3		2,1,9,6	
EBF83	di-1	4	9	23	3	3		7	
EBF83	di-2	4	9	23	3	3		8	
EBF83	pen	4	9	24	2	3		2,1,,6	
EBF89	di-1	4	9	23	3	3		7	
EBF89	di-2	4	9	23	3	3		8	
EBF89	pen	4	9	23	2	3		2,1,9,6	
EBL1	di-1	2(3)	9	<23	3	4		5	
EBL1	di-2	2(3)	9	<23	3	4		6	
EBL1	pen	2(3)	9	<25	4	4		0,7,(4),8	
EBL21	di-1	1	9	<25	3	7		5	
EBL21	di-2	1	9	<25	3	7		6	
EBL21	pen	1	9	<26	2	7		3,4,(k),2	
EC80	tri	1	9	3	1	5	2378	2+37+8	
EC81	tri	4	9	23	2	3		18	
EC86	tri	4(5)	9	20	2	3+7	1236789	2+6+8,1+9	
EC88	tri	4(5)	9	21	2	2	13679	1+3+6+7+9,8	
EC900	tri	3	9	21	2	27	27	15	
EC91	tri	3	9	21	2	25	1256	1+67	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
EC92	tri	3	9	23	2	7		6,1	
EC95	tri	3	9	22	2	17	17	256	
EC97	tri	3	9	22	2	17	17	25	
ECC189	tri-1	4	9	22	2	8		7,6	
ECC189	tri-2	4	9	22	2	3		2,1	
ECC33	tri-1	7	9	5	1	6		4,5	
ECC33	tri-2	7	9	5	1	3		1,2	
ECC34	tri-1	7	8	7	1	6		45	
ECC34	tri-2	7	8	7	1	3		12	
ECC35	tri-1	7	9	6	1	6		4,5	
ECC35	tri-2	7	9	6	1	3		1,2	
ECC40	tri-1	1(8)	9	<25	2	4		3,2	
ECC40	tri-2	1(8)	9	<25	2	7		6,5	
ECC801S	tri-1	9	9	4	1	8	45	67	
ECC801S	tri-2	9	9	4	1	3		12	
ECC802S	tri-1	9	9	8	1	3	45	12	
ECC802S	tri-2	9	9	8	1	8		67	
ECC808	tri-1	4	9	24	2	8		79	
ECC808	tri-2	4	9	24	2	2		13	
ECC81	tri-1	9(5)	9	4	1	8	45	7,6	
ECC81	tri-2	9(4)	9	4	1	3		2,1	
ECC82	tri-1	9(5)	9	8	1	8	45	7,6	
ECC82	tri-2	9(4)	9	8	1	3		2,1	
ECC83	tri-1	9(5)	9	27	2	8		7,6	
ECC83	tri-2	9(4)	9	27	2	3		2,1	
ECC84	tri-1	4(5)	9	24	2	78	78	6,9	
ECC84	tri-2	4(5)	9	24	2	1		2,3	
ECC85	tri-1	4(5)	9	22	2	8		7,6	
ECC85	tri-2	4(5)	9	22	2	3		2,1	
ECC86	tri-1	4(5)	9	23	2	8		7,6	
ECC86	tri-2	4(5)	9	23	2	3		2,1	
ECC88	tri-1	4(5)	9	21	2	8		7,6	
ECC88	tri-2	4(5)	9	21	2	3		2,1	
ECC91	tri-1	3	9	24	2	7		5,2	
ECC91	tri-2	3	9	24	2	7		6,1	
ECF12	pen	2	9	26	2	8		167	
ECF12	tri	2	9	27	2	8		45	
ECF200	pen	5	9	20	2	2		378	
ECF200	tri	5	9	22	2	1		90	
ECF201	pen	5	9	20	2	2		378	
ECF201	tri	5	9	22	2	1		90	
ECF202	pen	5	9	22	2	2		378	
ECF202	tri	5	9	23	2	1		90	
ECF80	pen	4	8	22	2	7		2,3,,6	
ECF80	tri	4	8	23	2	8		9,1	
ECF801	pen	4	9	20	2			267	
ECF801	tri	4	9	21	2	13	13	89	
ECF802	pen	4	9	21	2	7		236	
ECF802	tri	4	9	22	2	8		19	
ECF805	pen	4	9	19	2			237	note(s)
ECF805	tri	4	9	21	68	68	19		
ECF82	pen	4	9	24	2	7		2,3,,6	
ECF82	tri	4	9	24	2	8		9,1	
ECF83	pen	4	9	19	3	8		679	
ECF83	tri	4	9	19	2	1		23	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
ECF86	pen	4	9	22	2	13	13	2,9,,8	
ECF86	tri	4	9	23	2	13		6,7	
ECH11G	hex	5(6)	9	<29	2	3		2,1,(7),(1),4	
ECH11G	tri	5(6)	9	<33	2	3		7,8	
ECH200	hep	5	9	21	2	1		347	
ECH200	tri	5	9	20	2	9		80	
ECH21	hep	1(8)	9	23	2	9		6,5,7,,,2	
ECH21	tri	1	9	23	2	9		4,3	
ECH3	tot	2(3)	9	<25	2	4		0,7,6,(7),8	
ECH3	tri	2(3)	9	<28	2	4		6,5	
ECH35	hep	2	9	26	2			3456	
ECH35	tri	2	9	26	2	8		56	
ECH4	hep	2(3)	9	<24	2	1		0,7,5,(7),(1),8	
ECH4	tri	2(3)	9	<26	2	1		6,4	
ECH42	hex	1(8)	9	<26	2	7		6,5,(4),(5),2	
ECH42	tri	1(8)	9	<27	2	7		4,3	
ECH81	hep	4(5)	9	24	2	3		2,1,7,,,6	
ECH81	tri	4(5)	9	27	2	3		9,8	
ECH83	hep	4(5)	9	18	2	3		2,1,7,,,6	
ECH83	tri	4(5)	9	18	2	3		9,8	
ECH84	hep	4(5)	9	21	2	3		2,7,1,,,6	
ECH84	tri	4(5)	9	23	2	3		9,8	
ECL113	pen	1(8)	9	<25	2	7		4,5,(k),3	
ECL113	tri	1(8)	9	<29	2	7		6,2	
ECL80	pen	4(5)	9	6	1	3		9,8,7,6	
ECL80	tri	4(5)	9	11	1	3		2,1	
ECL82	pen	4(5)	9	23	2	2		3,7,,6	
ECL82	tri	4(5)	9	23	2	8		1,9	
ECL84	pen	4(5)	9	23	2	7		8,9,,6	
ECL84	tri	4(5)	9	23	2	3		1,2	
ECL85	pen	4(5)	9	22	2	8		679	
ECL85	tri	4(5)	9	24	2	3		12	
ECL86	pen	4(5)	9	23	2	7		8,3,(k),6	
ECL86	tri	4(5)	9	26	2	2		1,9	
ECLL800	pen-1	4(5)	9	23	2	7		2,9,,3	
ECLL800	pen-2	4(5)	9	23	2	7		6,9,,8	
ECLL800	tri	4(5)	9	23	2	7		2,1	
ED500	tri	4	9	32	2	1	123679	8,0	
EEP1		2(3)	9	<27	2	4		0,7,5,8	
EF11	pen	5(6)	9	<32	2	3		2,1,(3),8	
EF183	pen	4	9	22	2	13	13	2,8,9,7	
EF184	pen	4	9	21	2	13	13	2,8,9,7	
EF22	pen	1	9	<27	2	7		6,3,4,2	
EF22	pen	1	9	4	1	7		6,3,4,2	
EF37A	pen	2	9	25	2	8	27	340	
EF39	pen	2(7)	9	5	1	8		0,4,(5),3	
EF40	pen	1(8)	9	<27	2	7+3	37	5,6,(4),2	
EF41	pen	1(8)	9	<25	2	7+3+4		6,5,(k),2	
EF42	pen	1(8)	9	<23	2	7		6,5,(4),2	
EF43	pen	1(8)	9	<24	2	7		6,5,(4),2	
EF50	pen	1(9)	9	<23	2	6	58	7,2,(4),3	
EF54	pen	1(9)	9	<24	2	4+5+7+8	4578	6,3,(k),2	
EF6	pen	2(3)	9	<26	2	4		0,7,(5),8	
EF8	'pen'	3(4)	9	<28	2	4		0,6,7,(5),8	
EF80	pen	4	9	22	2	13	13	2,8,,7	note(s)

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
EF804	pen	4	9	23	2	3	26	9,8,1,7	
EF806S	pen	4	9	26	2	3	27	9,1,8,6	
EF83	pen	4	9	26	2	3	27	9,1,8,6	
EF85	pen	4	9	22	2	1+3	13	2,8,9,7	
EF86	pen	4	9	26	2	3	27	9,1,8,6	
EF89	pen	4	9	25	2	3	16	2,8,9,7	
EF9	pen	2(3)	9	<26	2	4		0,7,(5),8	
EF91	pen	3	9	23	2	2		1,7,6,5	
EF92	pen	3	9	6	1	2		1,7,6,5	
EF93	pen	3	9	5	1	7		1,6,2,5	
EF94	pen	3	9	5	1	7		1,6,2,5	
EF95	pen	3	9	25	2	27	27	1,6,,5	
EF97	pen	3	9	23	2	2		1,6,7,5	
EF98	pen	3	9	23	2	2		1,6,7,5	
EFL200	pen-F	5	9	20	2	2		1,3,,4	
EFL200	Pen-L	5	9	20	2	7		8,9,,0	
EFM11	eye	5(6)	9	<	4	3		4/4&8	
EFM11	pen	5(6)	9	<27	2	3		2,8,(k),1	
EH90	hep	3	9	24	2	2		1,6,7,,,5	note(s)
EH90	tri ?	3	9	24	2	2		16	
EH900S	tot	3	9	5	1	2		1567	
EH900S	tri	3	9	5	1			16	
EK11	oct ?	6	13	24	3	2	19	10	
EK2	oct	2(3)	9	<29	2	4		6,5,7,0,(7),(4),8	
EK90	hep	3	9	24	2	2		1,6,7,,,5	
EK90	tri	3	9	25	2	2		16	
EL12	pen	2	9	24	2	8		567	
EL13	Pen ?	2	9	23	2	8		567	
EL3	pen	2(3)	9	<5	1	4		6,7,(k),8	
EL32	pen	2(7)	9	6	1	8		0,4,,3	
EL33	pen	2	9	24	2	8		5,4,,3	
EL34	pen	2	9	4	1	8		5,4,1,3	
EL36	pen	2	9	23	2	38	1348	5,4,,0	note(s)
EL37	pen	2	9	24	2	8		5,4,,3	
EL38	pen	2	8	3	1	8		5,4,1,0	
EL41	pen	1(8)	9	<4	1	7+3	37	6,5,(k),2	
EL42	pen	1(8)	9	<27	2	7+3	37	6,5,(k),2	
EL500	pen	4	9	22	2	38	123678	1+2,6+7,,0	
EL503	pen	4	9	21	2	26	123678	3+7,1+8,,9	
EL504	pen	4	9	22	2	38	123678	1+2,6+7,,0	
EL505	Pen ?	4	9	20	2	9	123678	680	note(s)
EL51	pen	2(3)	9	<6	1	4		6,7,,0	
EL802	pen	4	9	20	2	1	3689	2,6+8,3+9,7	
EL81	pen	4	9	20	2	3		2,7+8,1+6+9,0	
EL82	pen	4	9	24	2	3		2,9,,7	
EL821		4	9	3	1	3		278	
EL83	pen	4	9	22	2	3		2,1,6,7	
EL84	pen	4	9	5	1	3	12	1+2,9,,7	
EL85	Pen ?	4	9	6	1	3	1268	1+26+879	
EL86	pen	4	9	21	2	3		1+2,6+9,(k),7+8	note(s)
EL90	pen	3	9	7	1	2	17	1+7,6,,5	
EL91	pen	3	9	25	2	2		1,7,,5	
EL95	pen	3	8	23	2	2	17	1+7,6,,5	
ELL80	Pen-1	4	9	22	2	7		2,1,,3	
ELL80	Pen-2	4	9	22	2	7		6,9,,8	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
EM1	eye	2(3)	9	<	4	4		7/7&8	
EM1	tri	2(3)	9	<30	2	4		6,8	
EM11	eye	5(6)	9	<	4	3		4/4&8/4&1	
EM11	eye	2	9	0	4			561	note(s)
EM11	tri	5(6)	9	<30	2	3		2,1&8	
EM11	tri	2	9	6	1	8		57	
EM34	eye-1	2	9	0	4	8		3,5	
EM34	eye-2	2	9	0	4	8		6,5	
EM34	tri-1	2	9	25?	2	8		4,3	
EM34	tri-2	2	9	25?	2	8		4,6	
EM35	eye	2	9	0	4			365	note(s)
EM35	tri	2	9	27	2	8		34	
EM4	eye	2(3)	9	<	4	4		7/7&5/7&8	
EM4	tri	2(3)	9	<30	2	4		6,8&5	
EM71	eye	1(8)	9		4	2+4	2,4	2&4/2&4&5	
EM71	tri	1(8)	9	<30	2	2+4	2,4	6,5	
EM80	eye	4	9	0	4	2		7,3+8+9	note(s)
EM80	tri	4	9	13	1	2	389	1,7	
EM81	eye	4	9	0	4	2		7,3+8+9	note(s)
EM81	tri	4	9	32	2	2	389	1,7	
EM84	eye	5	9	0	4	3		7,2+8+6	note(s)
EM84	tri	5	9	24	1	3	268	1,9	
EM85	eye	4	9	0	4	3		7,2+8+6	note(s)
EM85	tri	4	9	29	2	3	268	1,9	
EM87	eye	4	9	0	4	3		7,2+8+6	note(s)
EM87	tri	4	9	29	2	3	268	1,9	
EN32	thy	1	9	27	2	28		356	
EQ80	oct	4	9	23	2	38	38	7,1,2,,9,,,6	
EY500	rec	4	9	20	2	0	278	2+7+8	
EY51	Rec	2	9	18	4			0	note(s)
EY80	rec	4	9	24	2	3		9	
EY81	rec	4	9	22	2	0		29	note(s)
EY82	rec	4	9	24	2	3		9	
EY86	Rec	258	9	21	4		1469	0	
EY87	Rec	258	9	21	4		1469	0	
EY88	rec	4	9	23	2	0	1236789	3+8+9	
EZ2	pl-1	2(3)	9	<12	1	4		5	
EZ2	pl-2	2(3)	9	<12	1	4		8	
EZ35	pl-1	2	9	10	1	8		3	
EZ35	pl-2	2	9	10	1	8		5	
EZ41	pl-1	1(8)	9	<10	1	7		2	note(s)
EZ41	pl-2	1(8)	9	<10	1	7		6	
EZ80	pl-1	4	9	11	1	3		1	
EZ80	pl-2	4	9	11	1	3		7	
EZ81	pl-1	4	9	6	1	3		1	
EZ81	pl-2	4	9	6	1	3		7	
EZ90	pl-1	3	9	11	1	7		1	
EZ90	pl-2	3	9	11	1	7		6	
FDD20	pen-1	2(3)	13	9	1	4		7,8	
FDD20	pen-2	2(3)	13	9	1	4		6,5	
FM1000	tot	1	9	3	1	3		24567	
FM1000	tri	1	9	4	1			25	
GL866A		1	4	31	2			0	
GY501	Rec	248	4	20	4		14589	0	
GZ30	pl-1	2	8	5	1			4	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
GZ30	pl-2	2	8	5	1			6	
GZ32	pl-1	2	8	6	1			4	
GZ32	pl-2	2	8	6	1			6	
GZ34	pl-1	2	8	3	1			4	
GZ34	pl-1	2	8	3	1			6	
HBC90	di-1	3	13	26	3	2		5	
HBC90	di-2	3	13	26	3	2		6	
HBC90	tri	3	13	8	1	2		17	
HBC91	di-1	3	13	27	3			5	
HBC91	di-2	3	13	27	3			6	
HBC91	tri	3	13	27	2	2		17	
HCC85	tri-1	5	15	22	2	8		67	
HCC85	tri-2	5	15	22	2	3		12	
HCH81	hep	4	13	23	2	3		126	
HCH81	tri	4	13	25	2	3		89	
HF93		3	13	4	1	7		1256	
HK90	tot	3	13	4	1	2		1567	
HK90	tri	3	13	4	1	2		16	
HL23DD									as AR8
HL92		3	20	3	1	1	25	2+567	
HL94	pen	3	19	21	2	1	25	2+567	
HY1269		4	9	10	1		15	230	
HY69		1	9	14	1			230	
HY90		3	19	4	1	7	46	5	
KL1	pen	2(3)	3	<30	2			4,5,,1	
KT66		2	9	5	1	8		345	
KT88		2	8	3	1	8		345	
L63	tri	2	9	<28	2	8		5,3	
LC900	tri	3	4	21	2	27	27	15	note(s)
LCF200	pen	5	9	20	2	2		378	
LCF200	tri	5	9	22	2	1		90	
LCF201	pen	5	9	22	2	1		90	
LCF201	tri	5	9	22	2	1		90	
LCF80	pen	4	9	22	2	7		236	
LCF80	tri	4	9	23	2	8		19	
LCF801	pen	4	9	20	2			267	
LCF801	tri	4	9	21	2	13	13	89	
LCF802	pen	4	9	21	2	7		236	
LCF802	tri	4	9	22	2	8		19	
LCH200	hep	5	8	21	2	1		347	
LCH200	tri	5	8	20	2	9		80	
LCL80	pen	4	6	22	2			689	
LCL80	tri	4	6	25	2	3		12	
LCL84	pen	4	12	23	2	7		689	
LCL84	tri	4	12	23	2	3		12	
LCL85	pen	4	12	22	2	8		679	
LCL85	tri	4	12	24	2	3		12	
LF183	pen	4	6	22	2	13	13	2789	
LF184	pen	4	6	21	2	13	13	2789	
LFL200	pen-F	5	12	20	2	2		134	
LFL200	Pen-L	5	12	20	2	7		890	
LL505	pen	4	18	20	2	9	123678	680	note(s)
LL509	pen	4	18	20	2	9	123678	680	note(s)
LL521	Pen ?	4	17	20	2	9	123678	1+30	note(s)
LL802	Pen ?	4	12	20	2	1	3689	26+87	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
LL86	pen	4	12	21	2	3		1+26+7+89	note(s)
LY81	rec	4	12	22	2	0		29	note(s)
LY88	rec	4	17	24	3	0	123678	9	note(s)
M8096		4	9	4	1	7	89	1368+9	
MU14	pl-1	2	6	<11	1			1	
MU14	pl-2	2	6	<11	1			4	
N22LL		4	16	20	2	3	17	1+6+79	
NF2	pen	2(3)	13	<26	2	4		0,7,(5),8	
PABC80	di-1	4	12	25	3			6	
PABC80	di-2	4	12	18	3			2	
PABC80	di-3	4	12	18	3			1	
PABC80	tri	4	12	6	1	7		8,9	
PC86	tri	4(5)	5	22	2	3+7	1236789	2+6+8,1+9	
PC88	tri	4(5)	6	20	2	2	13679	1+3+6+7+9,8	
PC900	tri	3	6	21	2	2+7	27	1,5	
PC92	tri	3(4)	5	<28	2	7		6,1	
PC95	tri	3	5	20	2	17	17	25	
PCC189	tri-1	4	10	22	2	8		67	
PCC189	tri-2	4	10	22	2	3		12	
PCC84	tri-1	4	10	23	2	78	78	69	
PCC84	tri-2	4	10	23	2	1		23	
PCC85	tri-1	4	11	22	2	8		67	
PCC85	tri-2	4	11	22	2	3		12	
PCC88	tri-1	4	9	23	2	8		67	
PCC88	tri-2	4	9	23	2	3		12	
PCF200	pen	5(6)	10	20	2	2		3,8,(4),7	
PCF200	tri	5(6)	10	22	2	1		0,9	
PCF201	pen	5(6)	10	20	2	2		3,8,(4),7	
PCF201	tri	5(6)	10	22	2	1		0,9	
PCF80	pen	4	11	22	2	7		2,3,(k),6	
PCF80	tri	4	11	24	2	8		9,1	
PCF801	pen	4	11	20	2	13	13	2,7,(k),6	
PCF801	tri	4	11	21	2	13	13	9,8	
PCF802	pen	4(5)	12	21	2	7		2,3,(k),6	
PCF802	tri	4(5)	12	22	2	8		9,1	
PCF805	pen	4	10	19	2			237	
PCF805	tri	4	10	21	2	68	68	19	
PCF82	pen	4	12	24	2			236	
PCF82	tri	4	12	24	2	8		19	
PCF86	pen	4	10	22	2	1+3	13	2,9,(k),8	
PCF86	tri	4	10	23	2	1+3	13	6,7	
PCH200	hep	5	11	21	2	1		3,4,2,,,7	
PCH200	tri	5	11	20	2	9		8,0	
PCL805									as PCL85
PCL81	pen	4	13	23	2			269	
PCL81	tri	4	13	26	2	38	38	17	
PCL82	pen	4	15	21	2	2		367	
PCL82	tri	4	15	24	2	8		19	
PCL84	pen	4	14	24	2	7		8,9,(k),6	
PCL84	tri	4	14	23	2	3		1,2	
PCL85	pen	4	16	22	2	8		9,7,(k),6	
PCL85	tri	4	16	24	2	3		2,1	
PCL86	pen	4	14	23	2	7		8,3,(k),6	
PCL86	tri	4	14	26	2	2		1,9	
PD500	tri	4	10	32	2	1	23679	8,0	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
PD510	tri	4	10	32?	2	1	23679	8,0	
PF86	pen	4(5)	7	23	2	3	27	9,1,(8),6	
PFL200	pen-F	5	15	20	2	2		1,3,(k),4	
PFL200	pen-L	5	15	20	2	7		8,9,,0	
PJ8		1	8	20	1			23	
PL21	thy	3(4)	9	<28	2	2		1,5+7,6	as 2D21
PL36	pen	2	18	2	4	3+8	1348	5,1+4,(k),0	
PL500	pen	4	18	22	2	3+8	123678	1+2,6+7,(k),0	note(s)
PL504	pen	4	18	22	2	3+8	123678	1+2,6+7,(k),0	note(s)
PL508	pen	4	15	<25	2	7		1+8,3,(k),6	
PL511	pen	4(5)	18	<2	1	3+8		1+2,6+7,,0	
PL519	pen	4	19	<23	2	9	123678	1+8,3+6,(2+7),0	
PL521	pen	4	19	20	2	9	123678	1+30	
PL6574		1	9	27	2	8		356	
PL81	pen	4	17	21	2	3	16789	2,7+8,(1+6+9),0	
PL82	pen	4	5?	21	2	3		2,9,(k),7	
PL83	pen	4	14	25	2	3		2,1,6,7	
PL84	pen	4(5)	14	18	3	3	1278	1+2,9,(k),7+8	
PL95	pen	3(4)	5	<23	2	2	17	1+7,6,(k),5	
PM84	eye	4	6	0	4			67	note(s)
PM84	tri	4	6	34	2	3	268	19	
PV495	pl-1	2(3)	6	<18	1			1	
PV495	pl-2	2(3)	6	<18	1			4	
PY500	rec	4	19	22	2	0		2+7+8	
PY500A	rec	4	19	22	2	0		2+7+8	
PY80	rec	4	16	3	1	3		9	
PY81	rec	4	13	4	1	0	29	2+9	
PY82	rec	4	13	3	1	3		9	
PY83	rec	4	16	2	4	0		9	
PY88	rec	4(5)	19	23	2	0	1236789	2+7+9	
RE134	Tri	2	5	30	3			4,1	
REN1004	tri	2	6	30	2	5		4,1	
REN904	tri	2	6	27	2	5		4,1	
RK61		2	2	30	2			13	
SP61	pen	1(8)	9	<23	2	2		0,4,(5),3	
TJ880		4	9	22	2	16	1369	278	
TS383		4	9	17	4			1	
U19	pl	2(3)	6	<11	1			0	
UAA91	di-1	3	16	18	3	1		7	
UAA91	di-2	3	16	18	3	5		7	
UABC80	di-1	4	18	25	3			6	
UABC80	di-2	4	18	17	3	3		2	
UABC80	di-3	4	18	17	3			1	
UABC80	tri	4	18	25	2	7		89	
UBC41	di-1	1	13	27	3	7		6	
UBC41	di-2	1	13	27	3	7		5	
UBC41	tri	1	13	26	2	7		23	
UBC81	di-1	4	13	26	3	3		8	note(s)
UBC81	di-2	4	13	26	3	3		6	
UBC81	tri	4	13	8	1	3	79	12	
UBF80	di-1	4	15	25	3	3		8	
UBF80	di-2	4	15	25	3	3		7	
UBF80	pen	4	15	25	2	3		1269	
UBF89	di-1	4	16	21	3	3		7	
UBF89	di-2	4	16	21	3	3		8	

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
UBF89	pen	4	16	24	2	3		1269	
UC92	tri	3	12	22	2	7		16	
UCC85	tri-1	4	18	22	2	8		67	
UCC85	tri-2	4	18	22	2	3		12	
UCF12	pen	2	17	19	3			167	
UCF12	tri	2	17	19	3	8		45	
UCH21	hep	1	16	23	2	0		6,5,7,,,2	
UCH21	tri	1	16	23	2	0		4,3	
UCH42	hex	1	13	24	2	7		2456	
UCH42	tri	1	13	26	2	7		34	
UCH81	hep	4	16	23	2	3		126	
UCH81	tri	4	16	24	2	3		89	
UCL81	pen	4	19	23	2			269	
UCL81	tri	4	19	26	2	38	38	17	
UCL82	pen	4	20	19	3	2		367	
UCL82	tri	4	20	19	3	8		19	
UF80	pen	4	16	21	2	13	13	2897	
UF85	pen	4	16	23	2	13	13	2789	
UF89	pen	4	13	24	2	3	16	278	
UL84	pen	4	19	23	2	3	12689	1+26+97	
UM35	eye	1	13	0	4			364	note(s)
UM35	tri	1	13	25	2	7		56	
UM80	eye	4	16	0	4			7369	note(s)
UM80	tri	4	16	7	1	2	369	17	
UY1	rec	1(8+5)		<4	7			3	
UY1N	rec	1(8+5)		<4	7			3	
UY41	rec	1	19	2	4	7		2	
UY85	rec	4	19	24	2	3		1+6+9	
VR136									as EF54
VR54									as EB34
VR55									as EBC33
VR65									as SP61
VT52									as EL32
X155	tri-1	4	9	22	2	3		12	
X155	tri-2	4	9	22	2	8		67	
XC900	tri	3	3	21	2	27	27	15	note(s)
XC95	tri	3	4	22	2	17	17	256	
XC97	tri	3	4	22	2	17	17	25	
XCC189	tri-1	4	6	22	2	8		67	
XCC189	tri-2	4	6	22	2	3		12	
XCF80	pen	4	6	22	2	7		236	
XCF80	tri	4	6	23	2	8		19	
XCF801	pen	4	6	20	2			267	
XCF801	tri	4	6	21	2	13	13	89	
XCL82	pen	4	10	23	2	2		367	
XCL82	tri	4	10	25	2	8		19	
XCL84	pen	4	11	23	2	7		689	
XCL84	tri	4	11	23	2	7		689	
XCL85	pen	4	12	22	2	8		679	
XCL85	tri	4	12	24	2	3		12	
XF183	pen	4	5	22	2	13	13	2789	
XF184	pen	4	5	21	2	13	13	2789	
XF86	pen	4	4	23	2	3	27	169	
XL36	pen	2	13	23	2	38	1348	459	note(s)
XL500	pen	4	13	22	2	38	123678	160	note(s)

Tube	Section	A	B	C	D	Cath	Cont	Test	Notes
XL504	pen	4	13	22	2	38	123678	160	note(s)
XL84	pen	4	11	5	1	3	12	1+279	
XL86	pen	4	11	21	2	3		1+26+7+89	note(s)
XXB	tri-1	7	2	33	2			56	
XXB	tri-2	7	2	33	2			34	
XXD	tri-1	1	13	10	1	7		56	
XXD	tri-2	1	13	10	1	2		34	
XXFM	di-1	1	9	26	3			5	
XXFM	di-2	1	9	26	3	7		6	
XXFM	tri	1	9	10	1	4		23	
XXL		1	9	7	1	7		26	
XY88	rec	4	14	23	2	0	1234789	3+8+9	
YC97	tri	3	5	22	2	17	17	25	
YC98	tri	246	7	0	0			19	
YF183	pen	4	6	22	2	13	13	2789	
YF184	pen	4	6	21	2	13	13	2789	
YL1210	Tet-1	4	13	<25	2	2		1,7,6	note(s)
YL1210	Tet-2	4	13	<25	2	2		3,7,8	
YL1370		2	9	22	2	146	146	350	
YL1371		2	13	25	2	146	146	350	